| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| ANDERSON LED50UHD610 | x | x | 1.3 | |
| Andersson 512FHD PVR DVD | x | x | 1.2 | |
| Andersson B3211HD | x | x | 1.2 | |
| Andersson B4011FHD | x | x | 1.2 | |
| Andersson ED32511FHD PVR | x | x | 1.2 | |
| Andersson ED42511FHD PVR | x | x | 1.2 | |
| Andersson L32510FHD | x | x | 1.2 | |
| Andersson L32510FHD PVR DVD | x | x | 1.2 | |
| Andersson L32511FHD | x | x | 1.2 | |
| Andersson L32512FHD PVR DVD | x | x | 1.2 | |
| ANDERSSON L32522FHD DVD-K | x | x | 1.3 | |
| ANDERSSON L32522FHDDVD | x | x | 1.3 | |
| Andersson L42510FHD PVR | x | x | 1.2 | |
| Andersson L42511FHD | x | x | 1.2 | |
| Andersson L42511FHD PVR | x | x | 1.2 | |
| ANDERSSON L43UHD610 WHITE | x | x | 1.3 | |
| ANDERSSON L43UHD610 WHITE-K | x | x | 1.3 | |
| ANDERSSON L43UHD610S | x | x | 1.3 | |
| ANDERSSON L50522UHDS | x | x | 1.3 | |
| ANDERSSON L55-292UHDS-BLACK | x | x | 1.3 | |
| ANDERSSON L55UHD610 WHITE | x | x | 1.3 | |
| ANDERSSON L55UHD610 WHITE-K | x | x | 1.3 | |
| ANDERSSON L65UHD630 | x | x | 1.3 | |
| ANDERSSON LD40UHD610 | x | x | 1.3 | |
| Andersson LED22510HD PVR | x | x | 1.2 | |
| Andersson LED22510HD PVR DVD | x | x | 1.2 | |
| Andersson LED22511FHD | x | x | 1.2 | |
| Andersson LED22511FHD PVR | x | x | 1.2 | |
| Andersson LED22511FHDPVRD. | x | x | 1.2 | |
| Andersson LED22511HD | x | x | 1.2 | |
| Andersson LED22511HD PVR DVD | x | x | 1.2 | |
| Andersson LED22512FHD PVR DVD | x | x | 1.2 | |
| Andersson LED2432 FDC/DVD | x | x | 1.2 | |
| Andersson LED24510HD PVR | x | x | 1.2 | |
| Andersson LED24510HD PVR DVD | x | x | 1.2 | |
| Andersson LED24510HD PVR DVD WHITE | x | x | 1.2 | |
| Andersson LED24511HD | x | x | 1.2 | |
| Andersson LED24511HD PVR | x | x | 1.2 | |
| Andersson LED24511HD PVR DVD | x | x | 1.2 | |
| Andersson LED24511HD PVR DVD WHITE | x | x | 1.2 | |
| Andersson LED24511HDP.D. | x | x | 1.2 | |
| Andersson LED24511HDP.D.W | x | x | 1.2 | |
| ANDERSSON LED24521HD PVR | x | x | 1.3 | |
| ANDERSSON LED24521HD PVR WHITE | x | x | 1.3 | |
| ANDERSSON LED24522HD DVD | x | x | 1.3 | |
| ANDERSSON LED24522HDS | x | x | 1.3 | |
| ANDERSSON LED24522HDS WHITE | x | x | 1.3 | |
| ANDERSSON LED24525HDS | x | x | 1.3 | |
| ANDERSSON LED24525HDS WHITE | x | x | 1.3 | |
| Andersson LED3232FD | x | x | 1.2 | |
| Andersson LED32510FHD PVR | x | x | 1.2 | |
| Andersson LED32510FHD PVR WHITE | x | x | 1.2 | |
| Andersson LED32511F.P.W. | x | x | 1.2 | |
| Andersson LED32511FHD | x | x | 1.2 | |
| Andersson LED32511FHD PVR | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Andersson LED32511FHD PVR WHITE | x | x | 1.2 | |
| ANDERSSON LED32512FHD PVR | x | x | 1.3 | |
| ANDERSSON LED32513FHD PVR WHITE | x | x | 1.2 | |
| Andersson LED42510F.P.W. | x | x | 1.2 | |
| Andersson LED42510FHD | x | x | 1.2 | |
| Andersson LED42510FHD PVR | x | x | 1.2 | |
| Andersson LED42510FHD PVR WHITE | x | x | 1.2 | |
| Andersson LED42511FHD PVR | x | x | 1.2 | |
| ANDERSSON LED43511FHD PVR | x | x | 1.3 | |
| ANDERSSON LED43512UHD PVR | x | x | 1.3 | |
| ANDERSSON LED43522FHDS | x | x | 1.3 | |
| ANDERSSON LED43UHD610 | x | x | 1.3 | |
| ANDERSSON LED43UHD620-K | x | x | 1.3 | |
| ANDERSSON LED49UHD610-UNB | x | x | 1.3 | |
| ANDERSSON LED49UHDBİS | x | x | 1.3 | |
| Andersson LED50010UHD PVR | x | x | 1.2 | |
| Andersson LED50510FHD | x | x | 1.2 | |
| Andersson LED50510FHD PVR | x | x | 1.2 | |
| ANDERSSON LED50UHD610-K | x | x | 1.3 | |
| Andersson LED55510FHD PVR | x | x | 1.2 | |
| ANDERSSON LED-55UHD610-UNB | x | x | 1.3 | |
| ANDERSSON LED55UHD620-K | x | x | 1.3 | |
| Andersson LED65510FHD PVR | x | x | 1.2 | |
| Andersson LED65511FHD PVR | x | x | 1.2 | |
| Arena A22LEDWD2 | x | x | 1.2 | |
| Arena A22LEDWD2W | x | x | 1.2 | |
| Arena A26LEDLD2 | x | x | 1.2 | |
| Arena A32LEDWD2 | x | x | 1.2 | |
| Arena A32LEDWD4 | x | x | 1.2 | |
| Arena A32LEDWD4W | x | x | 1.2 | |
| ARENA A39SFDVS8 | x | x | 1.3 | |
| ARENA A40FDVS8 | x | x | 1.3 | |
| ARENA A43SFDVS7 | x | x | 1.3 | |
| ARENA A43SFDVS7-1 | x | x | 1.3 | |
| ARENA A48SFDVS7 | x | x | 1.3 | |
| ARENA A49SFDVS7 | x | x | 1.3 | |
| ARENA A49SUEUS8 | x | x | 1.3 | |
| ARENA A55SFDVS7 | x | x | 1.3 | |
| ARENA A55SFDVS7-1 | x | x | 1.3 | |
| ARENA A55SUDVS9 | x | x | 1.3 | |
| ARENA A55SUEUS7 | x | x | 1.3 | |
| B&O PLAY BeoPlay V1-32 (9503, CS2) | x | x | 1.2 | x |
| B&O PLAY BeoPlay V1-32 (9503, T2C) | x | x | 1.2 | x |
| B&O PLAY BeoPlay V1-40 (9501, CS2) | x | x | 1.2 | x |
| B&O PLAY BeoPlay V1-40 (9501, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (7710, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (7710, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (7712, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (7712, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (9600, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (9600, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (9602, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (9602, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (9615, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (9615, T2C) | x | x | 1.2 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Bang & Olufsen BeoSystem 3, (9617, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoSystem 3, (9617, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-32, (9576, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-32, (9576, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-40, (9570, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-40, (9570, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-40, (9572, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-40, (9572, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-46, (9565, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-46, (9565, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-46, (9566, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 10-46, (9566, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9171, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9171, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9178, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9178, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9181, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9181, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9188, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9188, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9331, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9331, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9338, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9338, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9341, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9341, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9348, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-32, (9348, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9361, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9361, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9368, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9368, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9376, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9376, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9383, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9383, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9440, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9440, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9447, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9447, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9641, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9641, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9649, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-40, (9649, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (7724, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (7724, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (7732, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (7732, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (9480, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (9480, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (9487, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 7-55, (9487, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 8-40, (9560, CS2) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 8-40, (9560, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision 8-40, (9562, CS2) | x | x | 1.2 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Bang & Olufsen BeoVision 8-40, (9562, T2C) | x | x | 1.2 | x |
| Bang & Olufsen BeoVision Avant 55 | x | x | 1.2 | x |
| Bang & Olufsen BeoVision Avant 75 | x | x | 1.2 | x |
| Bang & Olufsen BeoVision Avant 85 | x | x | 1.2 | x |
| BLAUPUNKT B215K189D-W | x | x | 1.2 | |
| BLAUPUNKT B215K189D-W7 | x | x | 1.2 | |
| BLAUPUNKT B22K189D | x | x | 1.2 | |
| BLAUPUNKT B22K189D-7 | x | x | 1.2 | |
| BLAUPUNKT B245K189 | x | x | 1.2 | |
| BLAUPUNKT B245K189-7 | x | x | 1.2 | |
| BLAUPUNKT B24K189D-7 | x | x | 1.2 | |
| BLAUPUNKT B40K68 | x | x | 1.2 | |
| BLAUPUNKT B40K68-7 | x | x | 1.2 | |
| Blaupunkt BLA-215/207O | x | x | 1.3 | |
| Blaupunkt BLA-23/207O | x | x | 1.3 | |
| Blaupunkt BLA-236/207O | x | x | 1.3 | |
| Blaupunkt BLA-32/133O | x | x | 1.3 | |
| Blaupunkt BLA-32/133Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-32/133Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-32/133Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-32/133Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-32/133Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-32/136O | x | x | 1.3 | |
| Blaupunkt BLA-32/148M | x | x | 1.3 | |
| Blaupunkt BLA-32/148O | x | x | 1.3 | |
| Blaupunkt BLA-32/148Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-32/148Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-32/148Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-32/148Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-32/148Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-32/233Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-32/233Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-32/233Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-32/233Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-32/233Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-32/234Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-32/234Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-32/234Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-32/234Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-32/234Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-39/148O | x | x | 1.3 | |
| Blaupunkt BLA-40/133O | x | x | 1.3 | |
| Blaupunkt BLA-40/133Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-40/133Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-40/133Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-40/133Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-40/133Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-40/148M | x | x | 1.3 | |
| Blaupunkt BLA-40/148O | x | x | 1.3 | |
| Blaupunkt BLA-40/148Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-40/148Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-40/148Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-40/148Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-40/148Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-40/233Z-GB | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Blaupunkt BLA-40/233Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-40/233Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-40/233Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-40/233Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-40/234Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-40/234Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-40/234Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-40/234Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-40/234Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-43/134M | x | x | 1.3 | |
| Blaupunkt BLA-43/134O | x | x | 1.3 | |
| Blaupunkt BLA-43/137M | x | x | 1.3 | |
| Blaupunkt BLA-48/148M | x | x | 1.3 | |
| Blaupunkt BLA-48/148O | x | x | 1.3 | |
| Blaupunkt BLA-49/148M | x | x | 1.3 | |
| Blaupunkt BLA-49/148O | x | x | 1.3 | |
| Blaupunkt BLA-50/148Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-50/148Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-50/148Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-50/148Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-50/148Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-50/149Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-50/149Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-50/149Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-50/149Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-50/149Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-50/234Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-50/234Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-50/234Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-50/234Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-50/234Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-50/238Z-GB | x | x | 1.3 | |
| Blaupunkt BLA-50/238Z-GW | x | x | 1.3 | |
| Blaupunkt BLA-50/238Z-WB | x | x | 1.3 | |
| Blaupunkt BLA-50/238Z-WS | x | x | 1.3 | |
| Blaupunkt BLA-50/238Z-WW | x | x | 1.3 | |
| Blaupunkt BLA-55/148M | x | x | 1.3 | |
| Champion CHLED124 | x | x | 1.2 | |
| Champion CHLED143EUNB | x | x | 1.2 | |
| Champion CHLED240 | x | x | 1.2 | |
| CHAMPION CHLED240W | x | x | 1.3 | |
| CHAMPION CHLED243 | x | x | 1.3 | |
| Champion CHLED32W | x | x | 1.2 | |
| CHAMPION CHLED50SW | x | x | 1.3 | |
| CHAMPION CHLED55EUNB4K | x | x | 1.3 | |
| CHAMPION CHLED65EUNB4K | x | x | 1.3 | |
| DANTAX 19LED DV801DC T2 | x | x | 1.2 | |
| Dantax 19LEDDV 810DC T2 | x | x | 1.2 | |
| DANTAX 19LEDDV801DCT2WHITE | x | x | 1.2 | |
| DANTAX 20LED 810 T2/C | x | x | 1.2 | |
| DANTAX 20LED 810T2 SVART | x | x | 1.2 | |
| Dantax 20LED DV 820 S2 | x | x | 1.2 | |
| DANTAX 20LED DV800DV T2 | x | x | 1.2 | |
| Dantax 20LED DV820DC | x | x | 1.2 | |
| Dantax 20LED DV820DC | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| DANTAX 20LEDDV820S2 White | x | x | 1.2 | |
| Dantax 20LEDDV82S5-DCT2/S2 | x | x | 1.2 | |
| Dantax 22LED DV803DC T2 | x | x | 1.2 | |
| Dantax 22LED DV825-DC T2/C | x | x | 1.2 | |
| DANTAX 24LED DV800DC T2 | x | x | 1.2 | |
| Dantax 24LED DV803DC T2 | x | x | 1.2 | |
| Dantax 24LED DV825-DCT2/C | x | x | 1.2 | |
| DANTAX 24LED DV935DC T2/C | x | x | 1.2 | |
| DANTAX 24LEDDV800DCT2WHITE | x | x | 1.2 | |
| Dantax 28LEDDV 800 T2 | x | x | 1.2 | |
| Dantax 28LEDDV803 T2 | x | x | 1.2 | |
| DANTAX 32LED 610 | x | x | 1.2 | x |
| DANTAX 32LED 800 T2 | x | x | 1.2 | |
| DANTAX 32LED 800 T2WHITE | x | x | 1.2 | |
| DANTAX 32LED 810S T2 | x | x | 1.2 | |
| DANTAX 32LED 820 S2 | x | x | 1.2 | |
| Dantax 32LED 820 T2 | x | x | 1.2 | |
| Dantax 32LED 821 T2/S2 | x | x | 1.2 | |
| DANTAX 32LED 825 T2/C | x | x | 1.2 | |
| DANTAX 32LED 825 T2/C SVART | x | x | 1.2 | |
| DANTAX 32LED 825T2/C | x | x | 1.2 | |
| DANTAX 32LED DV800 T2 | x | x | 1.2 | |
| DANTAX 32LED DV800T2 WH | x | x | 1.2 | |
| Dantax 32LEDDV 801 T2 | x | x | 1.2 | |
| Dantax 32LEDDV803 T2 | x | x | 1.2 | |
| DANTAX 32LV 410 T2 | x | x | 1.2 | x |
| DANTAX 39LED 612-2 PVR | x | x | 1.2 | |
| DANTAX 40LED 800 T2 | x | x | 1.2 | |
| DANTAX 40LED 800T2 White | x | x | 1.2 | |
| DANTAX 40LED 820 S2 | x | x | 1.2 | |
| DANTAX 40LED 820S2 WHITE | x | x | 1.2 | |
| Dantax 42LED 855 T2/C/S2 | x | x | 1.2 | |
| DANTAX 43LED 855 T2/C/S2 | x | x | 1.3 | |
| DANTAX 43LED 855 T2/C/S2 SMART WIFI S | x | x | 1.3 | |
| DANTAX 46LED 610 FHD | x | x | 1.2 | x |
| Dantax 48LED 855 T2/C/S2 | x | x | 1.2 | |
| Dantax 50LED 820 S2 | x | x | 1.2 | |
| Dantax Dantax 19LEDDV 810DC T2 | x | x | 1.2 | |
| Dantax Dantax 20LED DV820DC | x | x | 1.2 | |
| Dantax Dantax 20LED DV820DC WHITE | x | x | 1.2 | |
| Dantax Dantax 22LED DV803DC T2 | x | x | 1.2 | |
| Dantax Dantax 24LED DV803DC T2 | x | x | 1.2 | |
| Dantax Dantax 28LEDDV803 T2 | x | x | 1.2 | |
| Dantax Dantax 32LEDDV803 T2 | x | x | 1.2 | |
| Dantax Dantax24LEDDV803T2 | x | x | 1.2 | |
| Dantax Dantax32LED830T2 | x | x | 1.2 | |
| DIGIHOME 20H161DVD | x | x | 1.2 | |
| Digihome 22FH151DVD | x | x | 1.2 | |
| DIGIHOME 22FH181 | x | x | 1.3 | |
| DIGIHOME 22FH182 | x | x | 1.3 | |
| DIGIHOME 22FH191DVD | x | x | 1.3 | |
| DIGIHOME 22FW191 | x | x | 1.3 | |
| Digihome 24H151 | x | x | 1.2 | |
| Digihome 24H151DVD | x | x | 1.2 | |
| DIGIHOME 24H151DVD/2 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| DIGIHOME 24H152 | x | x | 1.2 | |
| DIGIHOME 24H152/2 | x | x | 1.3 | |
| DIGIHOME 24HW171DVD | x | x | 1.3 | |
| DIGIHOME 24HW181 | x | x | 1.3 | |
| DIGIHOME 24HW191 | x | x | 1.3 | |
| Digihome 32FH153DVD | x | x | 1.2 | |
| DIGIHOME 32FHS162 | x | x | 1.3 | |
| DIGIHOME 32H161 | x | x | 1.3 | |
| Digihome 32HS151W | x | x | 1.2 | |
| Digihome 32HS152 | x | x | 1.2 | |
| DIGIHOME 32HS152/2 | x | x | 1.3 | |
| Digihome 32HW171 | x | x | 1.3 | |
| DIGIHOME 32HW171/2 | x | x | 1.3 | |
| DIGIHOME 32HW181W | x | x | 1.3 | |
| DIGIHOME 32HW181W/2 | x | x | 1.3 | |
| DIGIHOME 39FH181 | x | x | 1.3 | |
| Digihome 40FH161 | x | x | 1.2 | |
| DIGIHOME 40FW171W | x | x | 1.3 | |
| Digihome 40US161 | x | x | 1.2 | |
| DIGIHOME 43FHS161 | x | x | 1.3 | |
| DIGIHOME 43FHS161/2 | x | x | 1.3 | |
| Digihome 43FHS161W | x | x | 1.2 | |
| DIGIHOME 43FHS171 | x | x | 1.3 | |
| DIGIHOME 43FHS171/2 | x | x | 1.3 | |
| DIGIHOME 43FW181 | x | x | 1.3 | |
| DIGIHOME 43FW181/2 | x | x | 1.3 | |
| Digihome 43US161 | x | x | 1.2 | |
| DIGIHOME 43US181/2 | x | x | 1.3 | |
| DIGIHOME 43US181/3 | x | x | 1.3 | |
| DIGIHOME 43UW181W | x | x | 1.3 | |
| DIGIHOME 48FHS161 | x | x | 1.2 | |
| Digihome 48US161 | x | x | 1.2 | |
| DIGIHOME 49FHS151 | x | x | 1.3 | |
| DIGIHOME 49FHS191 | x | x | 1.3 | |
| DIGIHOME 49FW172 | x | x | 1.3 | |
| DIGIHOME 49FW191 | x | x | 1.3 | |
| DIGIHOME 49US171 | x | x | 1.3 | |
| DIGIHOME 49UW172 | x | x | 1.3 | |
| DIGIHOME 49UW181 | x | x | 1.3 | |
| DIGIHOME 50FH171 | x | x | 1.2 | |
| DIGIHOME 50FH171/2 | x | x | 1.3 | |
| DIGIHOME 50FHS151 | x | x | 1.3 | |
| DIGIHOME 50FHS151v2 | x | x | 1.3 | |
| Digihome 50FHS171W | x | x | 1.3 | |
| DIGIHOME 50FHS181 | x | x | 1.3 | |
| DIGIHOME 50FW181 | x | x | 1.3 | |
| DIGIHOME 55FHS161 | x | x | 1.3 | |
| Digihome 55FHS161 | x | x | 1.2 | |
| DIGIHOME 55FW172 | x | x | 1.3 | |
| Digihome 55US161 | x | x | 1.2 | |
| DIGIHOME 55US171 | x | x | 1.3 | |
| DIGIHOME 55US174/2 | x | x | 1.3 | |
| DIGIHOME 55UW172 | x | x | 1.3 | |
| DIGIHOME 55UW181 | x | x | 1.3 | |
| Digihome 65FHS141 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Digihome 65FHS162 | x | x | 1.2 | |
| Digihome 65FHS163 | x | x | 1.2 | |
| Digihome 65US161 | x | x | 1.2 | |
| DIGIHOME 65US171 | x | x | 1.3 | |
| DIGIHOME 65US172 | x | x | 1.3 | |
| DIGIHOME 65US172/2 | x | x | 1.3 | |
| DIGIHOME 65US172/3 | x | x | 1.3 | |
| DIGIHOME 65UW172 | x | x | 1.3 | |
| DIGIHOME 75UW181 | x | x | 1.3 | |
| DMTECH LED24T | x | x | 1.2 | |
| DMTECH LED28DVDT | x | x | 1.2 | |
| ELETRA LED20T2BK | x | x | 1.2 | |
| ELETRA LED32STOMPA | x | x | 1.2 | |
| ELETRA LED39HYENA | x | x | 1.3 | |
| ELETRA LED42STOMPA | x | x | 1.2 | |
| Fimlux 24FLHMR185SV | x | x | 1.2 | |
| FINLUX 20-FHA-4750 | x | x | 1.2 | |
| FINLUX 20-FMA-4110 | x | x | 1.2 | |
| FINLUX 20-FMC-5160 | x | x | 1.3 | |
| FINLUX 22-FDMA-4110 | x | x | 1.2 | |
| FINLUX 22-FDMC-5161 | x | x | 1.3 | |
| FINLUX 22-FDMD-5160 | x | x | 1.3 | |
| FINLUX 22-FFDMC-5165 | x | x | 1.3 | |
| FINLUX 22-FFMD-4220 | x | x | 1.3 | |
| FINLUX 22-FFMD-4221 | x | x | 1.3 | |
| FINLUX 22-FFMD-5620 | x | x | 1.3 | |
| Finlux 22FLHKR185LV | x | x | 1.2 | |
| Finlux 22FLHTR160LV | x | x | 1.2 | |
| FINLUX 22-FMA-4110 | x | x | 1.2 | |
| FINLUX 22-FMC-5161 | x | x | 1.3 | |
| FINLUX 22-FMD-5160 | x | x | 1.3 | |
| FINLUX 23FLMR274S | x | x | 1.2 | |
| FINLUX 23FLMR274SV | x | x | 1.2 | |
| FINLUX 24-FDMA-4110 | x | x | 1.2 | |
| FINLUX 24-FDMA-5660 | x | x | 1.3 | |
| FINLUX 24-FDMD-5660 | x | x | 1.3 | |
| FINLUX 24-FFMD-4220 | x | x | 1.3 | |
| FINLUX 24-FFMD-5621 | x | x | 1.3 | |
| Finlux 24-FHA-4750 | x | x | 1.2 | |
| Finlux 24-FHDA-4750 | x | x | 1.2 | |
| FINLUX 24-FHDMC-5165 | x | x | 1.3 | |
| FINLUX 24-FHDMD-5620 | x | x | 1.3 | |
| FINLUX 24-FHDMD-5621 | x | x | 1.3 | |
| FINLUX 24-FHMD-4220 | x | x | 1.3 | |
| FINLUX 24-FHMD-5620 | x | x | 1.3 | |
| FINLUX 24-FHMD-5621 | x | x | 1.3 | |
| FINLUX 24-FHWMD-5621 | x | x | 1.3 | |
| Finlux 24FLHKR185LV | x | x | 1.2 | |
| Finlux 24FLHTR160L | x | x | 1.2 | |
| Finlux 24FLMR274S | x | x | 1.2 | |
| Finlux 24FLMR277S | x | x | 1.2 | |
| FINLUX 24-FMA-4110 | x | x | 1.2 | |
| FINLUX 24-FMD-5660 | x | x | 1.3 | |
| FINLUX 24-FWMA-4210 | x | x | 1.3 | |
| FINLUX 28-FHD-5660 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| FINLUX 28-FHMC-5165 | x | x | 1.3 | |
| FINLUX 32-FDA-4750 | x | x | 1.3 | |
| FINLUX 32-FDD-5660 | x | x | 1.3 | |
| FINLUX 32-FFA-5650 | x | x | 1.2 | |
| FINLUX 32-FFB-5660 | x | x | 1.3 | |
| FINLUX 32-FFD-5520 | x | x | 1.3 | |
| FINLUX 32-FHA-4010 | x | x | 1.2 | |
| FINLUX 32-FHA-5511 | x | x | 1.3 | |
| FINLUX 32-FHA-5660 | x | x | 1.3 | |
| FINLUX 32-FHB-4110 | x | x | 1.2 | |
| FINLUX 32-FHC-4660 | x | x | 1.3 | |
| FINLUX 32-FHD-4120 | x | x | 1.3 | |
| FINLUX 32-FHD-5120 | x | x | 1.3 | |
| FINLUX 32-FHD-5520 | x | x | 1.3 | |
| FINLUX 32-FHD-5620 | x | x | 1.3 | |
| Finlux 32-FHWA-4750 | x | x | 1.2 | |
| Finlux 32FLHFR185BV | x | x | 1.2 | |
| Finlux 32FLHKR160L | x | x | 1.2 | |
| FINLUX 32FLHKR249B | x | x | 1.2 | |
| Finlux 32FLHMR185BV | x | x | 1.2 | |
| Finlux 32FLHMR185S | x | x | 1.2 | |
| Finlux 32FLHMR242B | x | x | 1.2 | |
| Finlux 32FLKR160B | x | x | 1.2 | |
| Finlux 32FLKR160LV | x | x | 1.2 | |
| Finlux 32FLKR185B | x | x | 1.2 | |
| Finlux 32FLKR185D | x | x | 1.2 | |
| Finlux 32FLKR185S | x | x | 1.2 | |
| Finlux 32FLMR274S | x | x | 1.2 | |
| FINLUX 32FLMR274SV | x | x | 1.2 | |
| Finlux 32FLMR277S | x | x | 1.2 | |
| Finlux 32FLTR160V | x | x | 1.2 | |
| FINLUX 32-FWA-4015 | x | x | 1.2 | |
| FINLUX 32-FWA-5511 | x | x | 1.2 | |
| FINLUX 32-FWD-5520 | x | x | 1.3 | |
| Finlux 39FLHKR185B | x | x | 1.2 | |
| Finlux 39FLHKR185L | x | x | 1.2 | |
| Finlux 39FLHKR185S | x | x | 1.2 | |
| Finlux 39FLSMR185B | x | x | 1.2 | |
| FINLUX 40-FFA-4010 | x | x | 1.2 | |
| FINLUX 40-FFA-5511 | x | x | 1.2 | |
| FINLUX 40-FFB-4111 | x | x | 1.2 | |
| FINLUX 40-FFC-4661 | x | x | 1.3 | |
| FINLUX 40-FFD-5620 | x | x | 1.3 | |
| FINLUX 40-FFD-5660 | x | x | 1.3 | |
| Finlux 40FLHKR185B | x | x | 1.2 | |
| Finlux 40FLHKR982 | x | x | 1.2 | |
| Finlux 40FLSMR274B | x | x | 1.2 | |
| Finlux 40FLSMR277B | x | x | 1.2 | |
| Finlux 40FLSMR277BC | x | x | 1.2 | |
| FINLUX 40FLSMR277BC | x | x | 1.3 | |
| FINLUX 40-FWA-4015 | x | x | 1.2 | |
| FINLUX 40-FWA-5511 | x | x | 1.2 | |
| FINLUX 42FLHK249B | x | x | 1.2 | |
| FINLUX 42FLHK249BW | x | x | 1.2 | |
| Finlux 42FLHTR930 | x | x | 1.2 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Finlux 42FLHTR982LU | x | x | 1.2 | x |
| FINLUX 43-FFC-5661 | x | x | 1.3 | |
| FINLUX 43-FUA-8050 | x | x | 1.3 | |
| FINLUX 43-FUA-8060 | x | x | 1.3 | |
| FINLUX 43-FUC-8021 | x | x | 1.3 | |
| FINLUX 43-FUC-8022 | x | x | 1.3 | |
| FINLUX 43-FUD-8051 | x | x | 1.3 | |
| FINLUX 43-FUD-8060 | x | x | 1.3 | |
| Finlux 46FLSTR985L | x | x | 1.2 | x |
| FINLUX 47FLHKR242BHCDN-W | x | x | 1.2 | |
| FINLUX 47FLHKR250LHCD | x | x | 1.2 | |
| FINLUX 48-FFB-4010 | x | x | 1.2 | |
| FINLUX 48-FFD-5661 | x | x | 1.3 | |
| FINLUX 48FLHMR242BC | x | x | 1.2 | |
| FINLUX 49-FFB-4020 | x | x | 1.3 | |
| FINLUX 49-FFB-4121 | x | x | 1.3 | |
| FINLUX 49-FFB-5560 | x | x | 1.3 | |
| FINLUX 49-FFD-5660 | x | x | 1.3 | |
| FINLUX 49-FUA-8060 | x | x | 1.3 | |
| FINLUX 49-FUB-5520 | x | x | 1.3 | |
| FINLUX 49-FUB-8060 | x | x | 1.3 | |
| FINLUX 49-FUC-8021 | x | x | 1.3 | |
| FINLUX 49-FUD-8051 | x | x | 1.3 | |
| FINLUX 50FLHKR249B | x | x | 1.2 | |
| FINLUX 50FLHKR249BW | x | x | 1.2 | |
| Finlux 50FLHMR249BCM | x | x | 1.2 | |
| Finlux 50FLKR185L | x | x | 1.2 | |
| FINLUX 50-FUD-7020 | x | x | 1.3 | |
| FINLUX 55FLHKR242BHCDN-W | x | x | 1.2 | |
| Finlux 55FLSTR985L | x | x | 1.2 | x |
| FINLUX 55-FOD-9120 | x | x | 1.3 | |
| FINLUX 55-FUA-8060 | x | x | 1.3 | |
| FINLUX 55-FUB-5520 | x | x | 1.3 | |
| FINLUX 55-FUB-7060 | x | x | 1.3 | |
| FINLUX 55-FUB-8060 | x | x | 1.3 | |
| FINLUX 55-FUC-8021 | x | x | 1.3 | |
| FINLUX 55-FUD-7060 | x | x | 1.3 | |
| FINLUX 65-FBD-8520 | x | x | 1.3 | |
| FINLUX 65-FUB-8060 | x | x | 1.3 | |
| FINLUX 65-FUB-8160 | x | x | 1.3 | |
| FINLUX 65-FUC-8021 | x | x | 1.3 | |
| FINLUX 65-FUC-8060 | x | x | 1.3 | |
| FINLUX 65-FUD-8021 | x | x | 1.3 | |
| FINLUX 65-FUD-8051 | x | x | 1.3 | |
| FINLUX 65-FUD-8060 | x | x | 1.3 | |
| FINLUX 75-FUB-8520 | x | x | 1.3 | |
| FINLUX 75-FUC-8560 | x | x | 1.3 | |
| FINLUX 75-FUD-7051 | x | x | 1.3 | |
| FINLUX 75-FUD-8520 | x | x | 1.3 | |
| FINLUX FIN19DVDBK | x | x | 1.2 | |
| FINLUX FIN19DVDWH | x | x | 1.2 | |
| FINLUX FIN22DVDBK | x | x | 1.3 | |
| FINLUX FIN22DVDWH | x | x | 1.2 | |
| FINLUX FIN22HOLIDAYBK | x | x | 1.3 | |
| FINLUX FIN22HOLIDAYBKMKII | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| FINLUX FIN22HOLIDAYWH | x | x | 1.3 | |
| FINLUX FIN24SMARTBK | x | x | 1.3 | |
| FINLUX FIN24SMARTWH | x | x | 1.3 | |
| FINLUX FIN32BASEBK | x | x | 1.2 | |
| FINLUX FIN32FTV660BK | x | x | 1.3 | |
| Finlux FIN32HD440BK | x | x | 1.2 | |
| FINLUX FIN32PREM | x | x | 1.2 | |
| FINLUX FIN32PREMWH | x | x | 1.2 | |
| Finlux FIN39FHD440BK | x | x | 1.2 | |
| FINLUX FIN40BASEBK | x | x | 1.2 | |
| FINLUX FIN42PREMBK | x | x | 1.2 | |
| FINLUX FIN43FTV660BK | x | x | 1.3 | |
| FINLUX FIN43UTV560BK | x | x | 1.3 | |
| FINLUX FIN43UTV760BK | x | x | 1.3 | |
| FINLUX FIN43UTV850BK | x | x | 1.3 | |
| FINLUX FIN48BASEBK | x | x | 1.2 | |
| FINLUX FIN48PREMBK | x | x | 1.2 | |
| FINLUX FIN48SMARTBK | x | x | 1.2 | |
| FINLUX FIN49FTV660BK | x | x | 1.3 | |
| FINLUX FIN49UTV560BK | x | x | 1.3 | |
| FINLUX FIN49UTV760BK | x | x | 1.3 | |
| Finlux FIN55SMARTBK | x | x | 1.2 | |
| FINLUX FIN55UTV560BK | x | x | 1.3 | |
| FINLUX FIN55UTV760BK | x | x | 1.3 | |
| FINLUX FIN55UTV850BK | x | x | 1.3 | |
| Finlux FIN65PREMBK | x | x | 1.2 | |
| FINLUX FIN65UTV760BK | x | x | 1.3 | |
| FINLUX Finlux FIN55SMARTBK | x | x | 1.2 | |
| FINLUX LED50UHDBi | x | x | 1.3 | |
| GOCAMP 20LED DVB-T2/C | x | x | 1.2 | |
| GOCAMP 20LED Smart-TV | x | x | 1.3 | |
| GOCAMP 20LED/DVD DVB-T2/C | x | x | 1.2 | |
| Gocamp 22 LED-DVD T2 & S2 | x | x | 1.2 | |
| Gocamp 22 LED-DVD T2 & S2 GOCAMP | x | x | 1.2 | |
| Gocamp 22 LED-DVD T2&S2 | x | x | 1.2 | |
| GOCAMP 22LED Smart-TV | x | x | 1.3 | |
| GOCAMP GC T55-55 | x | x | 1.3 | |
| GOCAMP GC T55-67 | x | x | 1.3 | |
| GOCAMP GC T55-86 | x | x | 1.3 | |
| Gocamp Gocamp 20LED SMART-TV | x | x | 1.2 | |
| Gocamp Gocamp 22LED SMART-TV | x | x | 1.2 | |
| GOCAMP T55-55 22 LED-DVD T2/C/S2 | x | x | 1.3 | |
| Gocamp T55-6020L.D.T2/C/S2 | x | x | 1.2 | |
| GOCAMP T55-67 22LED SMART-TV | x | x | 1.3 | |
| GOCAMP T55-86 24LED SMART-TV | x | x | 1.3 | |
| Grundig 19 GLX 2100 T2 | x | x | 1.2 | x |
| Grundig 19 VLC 2101 T2 | x | x | 1.2 | x |
| Grundig 19 VLE 2101 T2 | x | x | 1.2 | x |
| Grundig 22 VLC 2101 DVD T2 | x | x | 1.2 | x |
| Grundig 22 VLC 2101 DVD T2 | x | x | 1.2 | x |
| Grundig 22 VLC 2101 T2 | x | x | 1.2 | x |
| Grundig 22 VLE 2101 DVD T2 | x | x | 1.2 | x |
| Grundig 22 VLE 2101 T2 | x | x | 1.2 | x |
| Grundig 22 VLE 4100 T2 | x | x | 1.2 | x |
| Grundig 22 VLE 4400 BM | x | x | 1.3 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Grundig 22 VLE 4400 WM | x | x | 1.3 | x |
| Grundig 22 VLE 4520 BM | x | x | 1.3 | x |
| Grundig 22 VLE 5400 BN | x | x | 1.3 | x |
| Grundig 22 VLE 5520 BN | x | x | 1.3 | x |
| Grundig 22 VLE 5520 BN | x | x | 1.3 | x |
| Grundig 22 VLE 7120 BM | x | x | 1.2 | x |
| Grundig 22 VLE 7120 WM | x | x | 1.2 | x |
| Grundig 22 VLE 7220 BM | x | x | 1.2 | x |
| Grundig 22 VLE 7220 WM | x | x | 1.2 | x |
| Grundig 22 VLE 8101 T2 | x | x | 1.2 | x |
| Grundig 22 VLE 8120 BM | x | x | 1.2 | x |
| Grundig 22 VLE 8120 CM | x | x | 1.2 | x |
| Grundig 22 VLE 8220 BN | x | x | 1.2 | x |
| Grundig 24 VLE 5720 BN | x | x | 1.3 | |
| Grundig 26 GLX 3100 T2 | x | x | 1.2 | x |
| Grundig 26 VLC 4102 T2 | x | x | 1.2 | x |
| Grundig 26 VLE 7100 BM | x | x | 1.2 | x |
| Grundig 26 VLE 7100 WM | x | x | 1.2 | x |
| Grundig 26 VLE 7200 BM | x | x | 1.2 | x |
| Grundig 26 VLE 7200 WM | x | x | 1.2 | x |
| Grundig 26 VLE 8100 BM | x | x | 1.2 | x |
| Grundig 26 VLE 8100 CM | x | x | 1.2 | x |
| Grundig 28 VLE 4400 BM | x | x | 1.3 | x |
| Grundig 28 VLE 4400 WM | x | x | 1.3 | x |
| Grundig 32 GLX 3100 T2 | x | x | 1.2 | x |
| Grundig 32 GLX 3101 T2 | x | x | 1.2 | x |
| Grundig 32 VLC 4102 T2 | x | x | 1.2 | x |
| Grundig 32 VLC 6122 T2 | x | x | 1.2 | x |
| Grundig 32 VLC 6123 T2 | x | x | 1.2 | x |
| Grundig 32 VLC 9141 T2 | x | x | 1.2 | x |
| Grundig 32 VLE 4100 T2 | x | x | 1.2 | x |
| Grundig 32 VLE 4302 BM | x | x | 1.2 | x |
| Grundig 32 VLE 4322 BM | x | x | 1.2 | x |
| Grundig 32 VLE 4400 BM | x | x | 1.3 | x |
| Grundig 32 VLE 4500 BM | x | x | 1.3 | x |
| Grundig 32 VLE 4520 BM | x | x | 1.3 | x |
| Grundig 32 VLE 4720 BN | x | x | 1.3 | |
| Grundig 32 VLE 5322 BN | x | x | 1.2 | x |
| Grundig 32 VLE 5325 BR | x | x | 1.2 | |
| Grundig 32 VLE 5325 WR | x | x | 1.2 | |
| Grundig 32 VLE 5329 BR | x | x | 1.2 | |
| Grundig 32 VLE 5400 BN | x | x | 1.3 | x |
| Grundig 32 VLE 5520 BN | x | x | 1.3 | x |
| Grundig 32 VLE 5620 BN | x | x | 1.3 | x |
| Grundig 32 VLE 5720 BN | x | x | 1.3 | |
| Grundig 32 VLE 5723 BN | x | x | 1.3 | |
| Grundig 32 VLE 5730 BN | x | x | 1.3 | |
| Grundig 32 VLE 6143 T2 | x | x | 1.2 | x |
| Grundig 32 VLE 6239 BM | x | x | 1.2 | x |
| Grundig 32 VLE 6520 BP | x | x | 1.3 | x |
| Grundig 32 VLE 6520 BP | x | x | 1.3 | x |
| Grundig 32 VLE 6620 BP | x | x | 1.3 | x |
| Grundig 32 VLE 6620 WP | x | x | 1.3 | x |
| Grundig 32 VLE 6625 BP | x | x | 1.3 | x |
| Grundig 32 VLE 6725 BP | x | x | 1.3 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Grundig 32 VLE 6730 BP | x | x | 1.3 | x |
| Grundig 32 VLE 7130 BM | x | x | 1.2 | x |
| Grundig 32 VLE 7130 WM | x | x | 1.2 | x |
| Grundig 32 VLE 7139 BR | x | x | 1.2 | |
| Grundig 32 VLE 8130 BP | x | x | 1.2 | |
| Grundig 32 VLE 8130 CP | x | x | 1.2 | |
| Grundig 32 VLE 8325 BP | x | x | 1.2 | |
| Grundig 32 VLE 8425 BP | x | x | 1.3 | x |
| Grundig 32 VLE 8425 WP | x | x | 1.3 | x |
| Grundig 32 VLE 8429 BP | x | x | 1.3 | x |
| Grundig 32 VLE 9370 BP | x | x | 1.2 | |
| Grundig 32 VLE 9370 BP | x | x | 1.2 | |
| Grundig 32 VLE 9370 WP | x | x | 1.2 | |
| Grundig 32 VLE 9370 WP | x | x | 1.2 | |
| Grundig 37 GLX 3103 T2 | x | x | 1.2 | x |
| Grundig 37 VLC 6122 T2 | x | x | 1.2 | x |
| Grundig 37 VLC 9142 T2 | x | x | 1.2 | x |
| Grundig 37 VLE 9370 BP | x | x | 1.2 | |
| Grundig 37 VLE 9370 BP | x | x | 1.2 | |
| Grundig 40 VLE 4322 BM | x | x | 1.2 | x |
| Grundig 40 VLE 4420 BM | x | x | 1.3 | x |
| Grundig 40 VLE 4520 BM | x | x | 1.3 | x |
| Grundig 40 VLE 4720 BN | x | x | 1.3 | |
| Grundig 40 VLE 5322 BN | x | x | 1.2 | x |
| Grundig 40 VLE 5325 BR | x | x | 1.2 | |
| Grundig 40 VLE 5325 WR | x | x | 1.2 | |
| Grundig 40 VLE 5329 BR | x | x | 1.2 | |
| Grundig 40 VLE 5420 BN | x | x | 1.3 | x |
| Grundig 40 VLE 5429 BP | x | x | 1.3 | x |
| Grundig 40 VLE 5520 BN | x | x | 1.3 | x |
| Grundig 40 VLE 5730 BN | x | x | 1.3 | |
| Grundig 40 VLE 6143 T2 | x | x | 1.2 | x |
| Grundig 40 VLE 6239 | x | x | 1.2 | x |
| Grundig 40 VLE 6239 BM | x | x | 1.2 | x |
| Grundig 40 VLE 6339 BR | x | x | 1.2 | |
| Grundig 40 VLE 6339 WR | x | x | 1.2 | |
| Grundig 40 VLE 6425 BR | x | x | 1.3 | x |
| Grundig 40 VLE 6439 BR | x | x | 1.3 | x |
| Grundig 40 VLE 6510 BR | x | x | 1.3 | x |
| Grundig 40 VLE 6520 BP | x | x | 1.3 | x |
| Grundig 40 VLE 6520 BP | x | x | 1.3 | x |
| Grundig 40 VLE 6730 BP | x | x | 1.3 | x |
| Grundig 40 VLE 7130 BM | x | x | 1.2 | x |
| Grundig 40 VLE 7130 WM | x | x | 1.2 | x |
| Grundig 40 VLE 7139 BR | x | x | 1.2 | |
| Grundig 40 VLE 7335 BR | x | x | 1.2 | |
| Grundig 40 VLE 7335 WR | x | x | 1.2 | |
| Grundig 40 VLE 7339 BR | x | x | 1.2 | |
| Grundig 40 VLE 7339 WR | x | x | 1.2 | |
| Grundig 40 VLE 7435 BR | x | x | 1.3 | x |
| Grundig 40 VLE 7435 WR | x | x | 1.3 | x |
| Grundig 40 VLE 7630 BP | x | x | 1.3 | x |
| Grundig 40 VLE 7630 WP | x | x | 1.3 | x |
| Grundig 40 VLE 8160 BP | x | x | 1.2 | |
| Grundig 40 VLE 8160 CP | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Grundig 40 VLE 8270 | x | x | 1.2 | |
| Grundig 40 VLE 8335 BP | x | x | 1.2 | |
| Grundig 40 VLE 8335 WP | x | x | 1.2 | |
| Grundig 40 VLE 8435 BP | x | x | 1.3 | x |
| Grundig 40 VLE 8439 BP | x | x | 1.3 | x |
| Grundig 40 VLX 7720 BP | x | x | 1.3 | x |
| Grundig 40 VLX 7730 BP | x | x | 1.3 | x |
| Grundig 40 VLX 7730 WP | x | x | 1.3 | x |
| GRUNDIG 40 VLX 7810 BP | x | x | 1.3 | |
| Grundig 42 VLC 6122 T2 | x | x | 1.2 | x |
| Grundig 42 VLC 9142 T2 | x | x | 1.2 | x |
| Grundig 42 VLE 7525 BP | x | x | 1.3 | x |
| Grundig 42 VLE 7525 BP | x | x | 1.3 | x |
| Grundig 42 VLE 8370 BP | x | x | 1.2 | |
| Grundig 42 VLE 8370 BP | x | x | 1.2 | |
| Grundig 42 VLE 8375 BP | x | x | 1.2 | |
| Grundig 42 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 42 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 42 VLE 9375 BP | x | x | 1.2 | |
| Grundig 42 VLE 9375 WP | x | x | 1.2 | |
| Grundig 42 VLE 9379 BP | x | x | 1.2 | |
| Grundig 42 VLE 9379 BP | x | x | 1.2 | |
| Grundig 42 VLE 9379 WP | x | x | 1.2 | |
| Grundig 42 VLE 9379 WP | x | x | 1.2 | |
| Grundig 42 VLE 9385 SP | x | x | 1.2 | |
| Grundig 43 VLE 4720 BN | x | x | 1.3 | |
| Grundig 43 VLE 5620 BN | x | x | 1.3 | x |
| Grundig 43 VLE 5723 BN | x | x | 1.3 | |
| Grundig 43 VLE 5730 BN | x | x | 1.3 | |
| Grundig 43 VLE 6620 BP | x | x | 1.3 | x |
| Grundig 43 VLE 6625 BP | x | x | 1.3 | x |
| Grundig 43 VLE 6629 BR | x | x | 1.3 | x |
| Grundig 43 VLE 6725 BP | x | x | 1.3 | x |
| Grundig 43 VLE 6730 BP | x | x | 1.3 | x |
| Grundig 43 VLX 6740 BP | x | x | 1.3 | x |
| GRUNDIG 43 VLX 6820 BP | x | x | 1.3 | |
| Grundig 43 VLX 6950 BP | x | x | 1.4 | |
| Grundig 43 VLX 7730 BP | x | x | 1.3 | x |
| Grundig 43 VLX 7730 WP | x | x | 1.3 | x |
| GRUNDIG 43 VLX 7800 BP | x | x | 1.3 | |
| GRUNDIG 43 VLX 7810 BP | x | x | 1.3 | |
| Grundig 43 VLX 7850 BP | x | x | 1.4 | |
| Grundig 46 VLE 6239 BM | x | x | 1.2 | x |
| Grundig 46 VLE 7130 BM | x | x | 1.2 | x |
| Grundig 46 VLE 7130 WM | x | x | 1.2 | x |
| Grundig 46 VLE 7139 BR | x | x | 1.2 | |
| Grundig 46 VLE 8160 BP | x | x | 1.2 | |
| Grundig 46 VLE 8160 CP | x | x | 1.2 | |
| Grundig 47 VLE 8370 BP | x | x | 1.2 | |
| Grundig 47 VLE 8370 BP | x | x | 1.2 | |
| Grundig 47 VLE 8375 BP | x | x | 1.2 | |
| Grundig 47 VLE 9375 BP | x | x | 1.2 | |
| Grundig 47 VLE 9375 WP | x | x | 1.2 | |
| Grundig 47 VLE 9379 BP | x | x | 1.2 | |
| Grundig 47 VLE 9379 WP | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Grundig 47 VLE 9385 SP | x | x | 1.2 | |
| Grundig 48 VLE 4420 BM | x | x | 1.3 | x |
| Grundig 48 VLE 4520 BM | x | x | 1.3 | x |
| Grundig 48 VLE 5420 BN | x | x | 1.3 | x |
| Grundig 48 VLE 5429 BP | x | x | 1.3 | x |
| Grundig 48 VLE 5520 BN | x | x | 1.3 | x |
| Grundig 48 VLE 6425 BR | x | x | 1.3 | x |
| Grundig 48 VLE 6439 BR | x | x | 1.3 | x |
| Grundig 48 VLE 6520 BP | x | x | 1.3 | x |
| Grundig 48 VLE 6520 BP | x | x | 1.3 | x |
| Grundig 48 VLE 7435 BR | x | x | 1.3 | x |
| Grundig 48 VLE 7435 WR | x | x | 1.3 | x |
| Grundig 48 VLE 8435 BP | x | x | 1.3 | x |
| Grundig 48 VLX 8545 BP | x | x | 1.3 | x |
| Grundig 48 VLX 8555 BP | x | x | 1.3 | x |
| Grundig 48 VLX 8572 BP | x | x | 1.3 | x |
| Grundig 48 VLX 8573 BP | x | x | 1.3 | x |
| Grundig 48 VLX 8581 BP | x | x | 1.3 | x |
| Grundig 48 VLX 8581 SP | x | x | 1.3 | x |
| Grundig 48 VLX 8581 WP | x | x | 1.3 | x |
| Grundig 48 VLX 8582 BP | x | x | 1.3 | x |
| Grundig 48 VLX 8582 SP | x | x | 1.3 | x |
| Grundig 48 VLX 8582 WP | x | x | 1.3 | x |
| Grundig 48 VLX 9470 BP | x | x | 1.3 | x |
| Grundig 48 VLX 9470 BP | x | x | 1.3 | x |
| Grundig 48 VLX 9570 BP | x | x | 1.3 | x |
| Grundig 48 VLX 9570 WP | x | x | 1.3 | x |
| Grundig 49 GUB 8678 | x | x | 1.3 | x |
| Grundig 49 VLE 5620 BN | x | x | 1.3 | x |
| Grundig 49 VLE 5723 BN | x | x | 1.3 | |
| Grundig 49 VLE 6620 BP | x | x | 1.3 | x |
| Grundig 49 VLE 6625 BP | x | x | 1.3 | x |
| Grundig 49 VLE 6629 BR | x | x | 1.3 | x |
| Grundig 49 VLE 6725 BP | x | x | 1.3 | x |
| Grundig 49 VLE 7525 BP | x | x | 1.3 | x |
| Grundig 49 VLE 7525 BP | x | x | 1.3 | x |
| Grundig 49 VLE 7629 WP | x | x | 1.3 | x |
| Grundig 49 VLE 7630 BP | x | x | 1.3 | x |
| Grundig 49 VLE 7630 WP | x | x | 1.3 | x |
| Grundig 49 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 49 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 49 VLX 6740 BP | x | x | 1.3 | x |
| GRUNDIG 49 VLX 6820 BP | x | x | 1.3 | |
| Grundig 49 VLX 6950 BP | x | x | 1.4 | |
| Grundig 49 VLX 7720 BP | x | x | 1.3 | x |
| Grundig 49 VLX 7730 BP | x | x | 1.3 | x |
| Grundig 49 VLX 7730 WP | x | x | 1.3 | x |
| GRUNDIG 49 VLX 7800 BP | x | x | 1.3 | |
| GRUNDIG 49 VLX 7810 BP | x | x | 1.3 | |
| Grundig 49 VLX 7850 BP | x | x | 1.4 | |
| Grundig 49 VLX 8670 AT | x | x | 1.3 | x |
| Grundig 49 VLX 8770 AT | x | x | 1.3 | x |
| Grundig 55 GUS 9689 New York | x | x | 1.3 | x |
| Grundig 55 VLE 5620 BN | x | x | 1.3 | x |
| Grundig 55 VLE 6620 BP | x | x | 1.3 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Grundig 55 VLE 6625 BP | x | x | 1.3 | x |
| Grundig 55 VLE 6725 BP | x | x | 1.3 | x |
| Grundig 55 VLE 7525 BP | x | x | 1.3 | x |
| Grundig 55 VLE 7525 BP | x | x | 1.3 | x |
| Grundig 55 VLE 7630 BP | x | x | 1.3 | x |
| Grundig 55 VLE 7630 WP | x | x | 1.3 | x |
| Grundig 55 VLE 8370 BP | x | x | 1.2 | |
| Grundig 55 VLE 8370 BP | x | x | 1.2 | |
| Grundig 55 VLE 8375 BP | x | x | 1.2 | |
| Grundig 55 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 55 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 55 VLE 8560 BP | x | x | 1.3 | x |
| Grundig 55 VLE 8560 BP | x | x | 1.3 | x |
| Grundig 55 VLE 8560 WP | x | x | 1.3 | x |
| Grundig 55 VLE 9375 BP | x | x | 1.2 | |
| Grundig 55 VLE 9375 WP | x | x | 1.2 | |
| Grundig 55 VLE 9379 BP | x | x | 1.2 | |
| Grundig 55 VLE 9379 WP | x | x | 1.2 | |
| Grundig 55 VLE 9385 SP | x | x | 1.2 | |
| Grundig 55 VLX 6740 BP | x | x | 1.3 | x |
| GRUNDIG 55 VLX 6820 BP | x | x | 1.3 | |
| Grundig 55 VLX 6950 BP | x | x | 1.4 | |
| Grundig 55 VLX 7720 BP | x | x | 1.3 | x |
| Grundig 55 VLX 7730 BP | x | x | 1.3 | x |
| Grundig 55 VLX 7730 WP | x | x | 1.3 | x |
| GRUNDIG 55 VLX 7800 BP | x | x | 1.3 | |
| GRUNDIG 55 VLX 7810 BP | x | x | 1.3 | |
| Grundig 55 VLX 7850 BP | x | x | 1.4 | |
| Grundig 55 VLX 8545 BP | x | x | 1.3 | x |
| Grundig 55 VLX 8555 BP | x | x | 1.3 | x |
| Grundig 55 VLX 8572 BP | x | x | 1.3 | x |
| Grundig 55 VLX 8573 BP | x | x | 1.3 | x |
| Grundig 55 VLX 8581 BP | x | x | 1.3 | x |
| Grundig 55 VLX 8581 SP | x | x | 1.3 | x |
| Grundig 55 VLX 8581 WP | x | x | 1.3 | x |
| Grundig 55 VLX 8582 BP | x | x | 1.3 | x |
| Grundig 55 VLX 8582 SP | x | x | 1.3 | x |
| Grundig 55 VLX 8582 WP | x | x | 1.3 | x |
| Grundig 55 VLX 8670 AT | x | x | 1.3 | x |
| Grundig 55 VLX 8770 AT | x | x | 1.3 | x |
| Grundig 55 VLX 9470 BP | x | x | 1.3 | x |
| Grundig 55 VLX 9470 BP | x | x | 1.3 | x |
| Grundig 55 VLX 9570 BP | x | x | 1.3 | x |
| Grundig 55 VLX 9570 WP | x | x | 1.3 | x |
| Grundig 65 VLE 7630 BP | x | x | 1.3 | x |
| Grundig 65 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 65 VLE 8460 BP | x | x | 1.3 | x |
| Grundig 65 VLO 9795 SP | x | x | 1.3 | x |
| Grundig 65 VLX 6950 BP | x | x | 1.4 | |
| Grundig 65 VLX 7730 BP | x | x | 1.3 | x |
| Grundig 65 VLX 7850 BP | x | x | 1.4 | |
| Grundig 65 VLX 8670 AT | x | x | 1.3 | x |
| Grundig 65 VLX 8725 BP | x | x | 1.3 | x |
| Grundig 65 VLX 8770 AT | x | x | 1.3 | x |
| Grundig 65 VLX 9590 BP | x | x | 1.3 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Grundig Atlanta 48 CLX 8586 SP | x | x | 1.3 | x |
| Grundig Atlanta 55 CLX 8586 SP | x | x | 1.3 | x |
| Grundig BERLIN 40 CLE 6220 BM | x | x | 1.2 | x |
| Grundig Berlin 40 CLE 6325 BR | x | x | 1.2 | |
| Grundig Berlin 40 CLE 6425 BR | x | x | 1.3 | x |
| Grundig BERLIN 43 CLX 6950 BP | x | x | 1.4 | |
| Grundig BERLIN 46 CLE 6320 BM | x | x | 1.2 | x |
| Grundig Berlin 48 CLE 6425 BR | x | x | 1.3 | x |
| Grundig BERLIN 49 CLX 6950 BP | x | x | 1.4 | |
| Grundig BERLIN 55 CLX 6950 BP | x | x | 1.4 | |
| Grundig BERLIN 65 CLX 6950 BP | x | x | 1.4 | |
| Grundig COPENHAGEN 43 CLE 6620 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 43 CLE 6625 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 43 CLE 6725 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 49 CLE 6620 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 49 CLE 6625 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 49 CLE 6725 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 55 CLE 6620 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 55 CLE 6625 BP | x | x | 1.3 | x |
| Grundig COPENHAGEN 55 CLE 6725 BP | x | x | 1.3 | x |
| Grundig FINE ARTS 55 FLX 9490 SP | x | x | 1.3 | x |
| Grundig FINE ARTS 55 FLX 9492 SP | x | x | 1.3 | x |
| Grundig Fine Arts 55 FLX 9590 SP | x | x | 1.3 | x |
| Grundig Fine Arts 55 FLX 9690 SP | x | x | 1.3 | x |
| Grundig Fine Arts 65 FLX 9490 SP | x | x | 1.3 | x |
| Grundig FINE ARTS 65 FLX 9492 SP | x | x | 1.3 | x |
| Grundig Fine Arts 65 FLX 9580 SR | x | x | 1.3 | x |
| Grundig Fine Arts 65 FLX 9590 SP | x | x | 1.3 | x |
| Grundig Fine Arts 65 FLX 9690 SP | x | x | 1.3 | x |
| Grundig FineArts 32 FLE 9130 BP | x | x | 1.2 | |
| Grundig FineArts 32 FLE 9130 SP | x | x | 1.2 | |
| Grundig FineArts 40 FLE 9170 BP | x | x | 1.2 | |
| Grundig FineArts 40 FLE 9170 SP | x | x | 1.2 | |
| Grundig FineArts 46 FLE 9170 BP | x | x | 1.2 | |
| Grundig FineArts 46 FLE 9170 SP | x | x | 1.2 | |
| Grundig FineArts 55 FLE 9170 BP | x | x | 1.2 | |
| Grundig FineArts 55 FLE 9170 SP | x | x | 1.2 | |
| Grundig G48L 9562 5B | x | x | 1.3 | x |
| Grundig G55L 9562 5B | x | x | 1.3 | x |
| Grundig Hamburg 22 VLE 2102 T2 | x | x | 1.2 | x |
| Grundig Hamburg 26 VLC 8101 T2 | x | x | 1.2 | x |
| Grundig Hamburg 26 VLC 8101 T2 | x | x | 1.2 | x |
| Grundig Lugano 48 CLX 8586 SP | x | x | 1.3 | x |
| Grundig Lugano 55 CLX 8586 SP | x | x | 1.3 | x |
| Grundig New York 32 CLE 9130 SP | x | x | 1.2 | |
| Grundig New York 40 CLE 9170 SP | x | x | 1.2 | |
| Grundig New York 46 CLE 9170 SP | x | x | 1.2 | |
| Grundig New York 55 CLE 9170 SP | x | x | 1.2 | |
| Grundig RIO 40 VLE 8435 BP | x | x | 1.3 | x |
| Grundig RIO 48 VLE 8435 BP | x | x | 1.3 | x |
| Grundig RIO 49 CLX 8670 AT | x | x | 1.3 | x |
| Grundig RIO 55 CLX 8670 AT | x | x | 1.3 | x |
| Grundig RIO 65 CLX 8670 AT | x | x | 1.3 | x |
| Grundig Rom 32 CLE 8130 BP | x | x | 1.2 | |
| Grundig Rom 40 CLE 8160 BP | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Grundig Rom 46 CLE 8160 BP | x | x | 1.2 | |
| Grundig Rome 42 CLE 8560 BP | x | x | 1.3 | x |
| Grundig Rome 49 CLE 8560 BP | x | x | 1.3 | x |
| Grundig Rome 55 CLE 8560 BP | x | x | 1.3 | x |
| Grundig Rome 55 CLE 8565 BP GRUNDIG | x | x | 1.3 | x |
| Grundig Salzburg 55 CLE 8555 SL | x | x | 1.3 | x |
| Grundig Stockholm 40 CLE 6520 BP | x | x | 1.3 | x |
| Grundig STOCKHOLM 40 CLX 7730 BP | x | x | 1.3 | x |
| Grundig STOCKHOLM 43 CLX 7730 BP | x | x | 1.3 | x |
| Grundig Stockholm 48 CLE 6520 BP | x | x | 1.3 | x |
| Grundig STOCKHOLM 49 CLX 7730 BP | x | x | 1.3 | x |
| Grundig STOCKHOLM 55 CLX 7730 BP | x | x | 1.3 | x |
| Grundig Sydney 42 CLE 9376 BP | x | x | 1.2 | |
| Grundig Sydney 42 CLE 9376 BP | x | x | 1.2 | |
| Grundig Sydney 42 CLE 9377 BP | x | x | 1.2 | |
| Grundig Sydney 47 CLE 9376 BP | x | x | 1.2 | |
| Grundig Sydney 47 CLE 9376 BP | x | x | 1.2 | |
| Grundig Sydney 47 CLE 9377 BP | x | x | 1.2 | |
| Grundig Sydney 55 CLE 9376 BP | x | x | 1.2 | |
| Grundig Sydney 55 CLE 9376 BP | x | x | 1.2 | |
| Grundig Sydney 55 CLE 9377 BP | x | x | 1.2 | |
| Grundig Toronto 32 CLE 6645 AL | x | x | 1.3 | x |
| Grundig Vision 22-2101 H | x | x | 1.2 | x |
| Grundig Vision 22-2101 H | x | x | 1.2 | x |
| Grundig Vision 26-4101 H | x | x | 1.2 | x |
| Grundig Vision 32-4101 H | x | x | 1.2 | x |
| HITACHI 22HE3001 | x | x | 1.3 | |
| HITACHI 22HE4000 | x | x | 1.3 | |
| HITACHI 22HE4001 | x | x | 1.3 | |
| Hitachi 24F501HB1T05 | x | x | 1.2 | |
| Hitachi 24HB1T05C | x | x | 1.2 | |
| Hitachi 24HB1T65 | x | x | 1.2 | |
| HITACHI 24HB4J65 | x | x | 1.3 | |
| HITACHI 24HB4T65 H | x | x | 1.3 | |
| HITACHI 24HB4T65 K | x | x | 1.3 | |
| HITACHI 24HE1000 | x | x | 1.3 | |
| HITACHI 24HE2000 | x | x | 1.3 | |
| HITACHI 24HE2001 | x | x | 1.3 | |
| HITACHI 24HE2003 | x | x | 1.3 | |
| HITACHI 32F501HB4T61 | x | x | 1.3 | |
| HITACHI 32F501HB4T62 | x | x | 1.3 | |
| HITACHI 32F501HB4T62 H | x | x | 1.3 | |
| HITACHI 32F52HE1000 | x | x | 1.3 | |
| HITACHI 32FBHE2000 | x | x | 1.3 | |
| HITACHI 32FK5HE4000 | x | x | 1.3 | |
| Hitachi 32HB4T41 | x | x | 1.3 | |
| HITACHI 32HB4T41 A | x | x | 1.3 | |
| HITACHI 32HB4T61 | x | x | 1.3 | |
| HITACHI 32HB4T61 H | x | x | 1.3 | |
| HITACHI 32HB4T61 K | x | x | 1.3 | |
| HITACHI 32HB4T62 | x | x | 1.3 | |
| HITACHI 32HB4T62 H | x | x | 1.3 | |
| HITACHI 32HB4T62 K | x | x | 1.3 | |
| HITACHI 32HB5W66 | x | x | 1.3 | |
| Hitachi 32HB6T61 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Hitachi 32HBT01 A | x | x | 1.2 | |
| Hitachi 32HBT41 A | x | x | 1.2 | |
| Hitachi 32HBT41W | x | x | 1.2 | |
| HITACHI 32HE1000 | x | x | 1.3 | |
| HITACHI 32HE1810-FTR | x | x | 1.3 | |
| HITACHI 32HE2000 | x | x | 1.3 | |
| HITACHI 32HE3000 | x | x | 1.3 | |
| HITACHI 32HE4000 | x | x | 1.3 | |
| HITACHI 32HE4500 | x | x | 1.3 | |
| HITACHI 32HE4500K | x | x | 1.3 | |
| HITACHI 32HL4001 | x | x | 1.3 | |
| HITACHI 39HB4T62 | x | x | 1.3 | |
| HITACHI 39HB4T62 H | x | x | 1.3 | |
| Hitachi 39HB5T62 | x | x | 1.3 | |
| Hitachi 40F501HB1T62 | x | x | 1.2 | |
| HITACHI 40HB4W62 | x | x | 1.3 | |
| Hitachi 40HB6T62 | x | x | 1.2 | |
| HITACHI 40HB6T62 L | x | x | 1.3 | |
| Hitachi 40HBT42 A | x | x | 1.2 | |
| Hitachi 40HBT42W | x | x | 1.2 | |
| HITACHI 40HE3000 | x | x | 1.3 | |
| HITACHI 40HE4000 | x | x | 1.3 | |
| HITACHI 40HE4001 | x | x | 1.3 | |
| HITACHI 40HE4002 | x | x | 1.3 | |
| HITACHI 43F501HK5000 | x | x | 1.3 | |
| HITACHI 43F501HK6000 | x | x | 1.3 | |
| HITACHI 43F52HK6000i | x | x | 1.3 | |
| HITACHI 43FK5HK6500 | x | x | 1.3 | |
| Hitachi 43HB5T62 | x | x | 1.3 | |
| HITACHI 43HB5T62 H | x | x | 1.3 | |
| Hitachi 43HB6T62 | x | x | 1.2 | |
| Hitachi 43HBT42 A | x | x | 1.2 | |
| HITACHI 43HE4000 | x | x | 1.3 | |
| HITACHI 43HE4600 | x | x | 1.3 | |
| Hitachi 43HGW69 | x | x | 1.3 | |
| HITACHI 43HK5000 | x | x | 1.3 | |
| HITACHI 43HK5W64 | x | x | 1.3 | |
| HITACHI 43HK5W64 H | x | x | 1.3 | |
| HITACHI 43HK6000 | x | x | 1.3 | |
| HITACHI 43HK6001 | x | x | 1.3 | |
| HITACHI 43HK6001W | x | x | 1.3 | |
| HITACHI 43HK6002 | x | x | 1.3 | |
| HITACHI 43HK6002W | x | x | 1.3 | |
| HITACHI 43HK6003W | x | x | 1.3 | |
| HITACHI 43HK6500 | x | x | 1.3 | |
| HITACHI 43HK7000 | x | x | 1.3 | |
| HITACHI 43HK7500 | x | x | 1.3 | |
| HITACHI 43HL15W64 | x | x | 1.3 | |
| HITACHI 43HL5T64 | x | x | 1.3 | |
| HITACHI 43HL5W69 | x | x | 1.3 | |
| HITACHI 43HL7000 | x | x | 1.3 | |
| HITACHI 43HL8000 | x | x | 1.3 | |
| HITACHI 43HL8000K | x | x | 1.3 | |
| HITACHI 48HB6W62 A | x | x | 1.3 | |
| HITACHI 48HB6W62 H | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| HITACHI 48HE4000 | x | x | 1.3 | |
| HITACHI 49F501HK5000 | x | x | 1.3 | |
| HITACHI 49F501HL5T64 | x | x | 1.3 | |
| HITACHI 49F566W654 | x | x | 1.3 | |
| Hitachi 49HB5W62 | x | x | 1.3 | |
| Hitachi 49HBT62 A | x | x | 1.2 | |
| HITACHI 49HE4000 | x | x | 1.3 | |
| Hitachi 49HGW69 | x | x | 1.3 | |
| HITACHI 49HK5000 | x | x | 1.3 | |
| HITACHI 49HK5W64 | x | x | 1.3 | |
| HITACHI 49HK5W64 H | x | x | 1.3 | |
| HITACHI 49HK6000 | x | x | 1.3 | |
| HITACHI 49HK6001 | x | x | 1.3 | |
| HITACHI 49HK6001W | x | x | 1.3 | |
| HITACHI 49HK6002 | x | x | 1.3 | |
| HITACHI 49HK6002W | x | x | 1.3 | |
| HITACHI 49HK6003W | x | x | 1.3 | |
| HITACHI 49HK6500 | x | x | 1.3 | |
| HITACHI 49HK7000 | x | x | 1.3 | |
| HITACHI 49HK7500 | x | x | 1.3 | |
| HITACHI 49HL15W64 | x | x | 1.3 | |
| HITACHI 49HL15W64 A | x | x | 1.3 | |
| HITACHI 49HL5T64 | x | x | 1.3 | |
| HITACHI 49HL5W69 | x | x | 1.3 | |
| HITACHI 49HL7000 | x | x | 1.3 | |
| HITACHI 49HL8000 | x | x | 1.3 | |
| HITACHI 50HB5T62 | x | x | 1.3 | |
| HITACHI 50HB5W62 | x | x | 1.3 | |
| HITACHI 50HB5W62 H | x | x | 1.3 | |
| HITACHI 50HE4000 | x | x | 1.3 | |
| HITACHI 50HK5000 | x | x | 1.3 | |
| HITACHI 50HK5W64I | x | x | 1.3 | |
| HITACHI 50HK6000 | x | x | 1.3 | |
| HITACHI 50HK6500 | x | x | 1.3 | |
| HITACHI 50HZT66 | x | x | 1.2 | |
| HITACHI 55F501HK5000 | x | x | 1.3 | |
| HITACHI 55F501HL5T64 | x | x | 1.3 | |
| HITACHI 55F52HK6000 | x | x | 1.3 | |
| Hitachi 55HBW62 | x | x | 1.2 | |
| Hitachi 55HGW69 | x | x | 1.3 | |
| HITACHI 55HK5000 | x | x | 1.3 | |
| HITACHI 55HK5W64 | x | x | 1.3 | |
| HITACHI 55HK5W64 A | x | x | 1.3 | |
| HITACHI 55HK5W64 H | x | x | 1.3 | |
| HITACHI 55HK6000 | x | x | 1.3 | |
| HITACHI 55HK6001 | x | x | 1.3 | |
| HITACHI 55HK6001W | x | x | 1.3 | |
| HITACHI 55HK6002 | x | x | 1.3 | |
| HITACHI 55HK6002W | x | x | 1.3 | |
| HITACHI 55HK6003W | x | x | 1.3 | |
| HITACHI 55HK6500 | x | x | 1.3 | |
| HITACHI 55HK7000 | x | x | 1.3 | |
| HITACHI 55HK7500 | x | x | 1.3 | |
| HITACHI 55HL15W64 | x | x | 1.3 | |
| HITACHI 55HL15W64 A | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| HITACHI 55HL5T64 | x | x | 1.3 | |
| HITACHI 55HL5W69 | x | x | 1.3 | |
| HITACHI 55HL7000 | x | x | 1.3 | |
| HITACHI 55HL8000 | x | x | 1.3 | |
| HITACHI 55HL8000K | x | x | 1.3 | |
| HITACHI 55HZT66 | x | x | 1.2 | |
| HITACHI 58HK6000 | x | x | 1.3 | |
| HITACHI 65F501HL5W64 | x | x | 1.3 | |
| HITACHI 65F501HZ6W69 | x | x | 1.3 | |
| HITACHI 65HK6500 | x | x | 1.3 | |
| HITACHI 65HK7000 | x | x | 1.3 | |
| HITACHI 65HK7500 | x | x | 1.3 | |
| HITACHI 65HL15W64 B | x | x | 1.3 | |
| HITACHI 65HL5W64 | x | x | 1.3 | |
| HITACHI 65HL7000 | x | x | 1.3 | |
| HITACHI 65HL7000 A | x | x | 1.3 | |
| HITACHI 65HL8000 | x | x | 1.3 | |
| HITACHI 65HL8000 A | x | x | 1.3 | |
| HITACHI 65HL8000 B | x | x | 1.3 | |
| HITACHI 65HL8000T | x | x | 1.3 | |
| HITACHI 65HL8500T | x | x | 1.3 | |
| Hitachi 65HZ6W69 | x | x | 1.3 | |
| HITACHI 65HZ6W69 A | x | x | 1.3 | |
| HITACHI 65HZ6W69 B | x | x | 1.3 | |
| HITACHI 65HZT663D | x | x | 1.2 | |
| HITACHI 75HL7000 | x | x | 1.3 | |
| HITACHI F32L4001 | x | x | 1.3 | |
| Humax BXR-HD | x | x | | x |
| Humax BXR-HD+ | x | x | | x |
| Humax BXR-HD+2 | x | x | | x |
| Humax BXR-HD2 | x | x | | x |
| IKEA Uppleva L32U4000FNE | x | x | 1.2 | |
| IKEA Uppleva L32U4010FNE | x | x | 1.2 | |
| IKEA Uppleva L40U4000ZNE | x | x | 1.2 | |
| IKEA Uppleva L40U4010ZNE | x | x | 1.2 | |
| IKEA Uppleva L46U4000ZNE | x | x | 1.2 | |
| IKEA Uppleva L46U4010ZNE | x | x | 1.2 | |
| JVC LT-19E320 | x | x | 1.2 | |
| JVC LT-19E33B | x | x | 1.2 | |
| JVC LT-19E33W | x | x | 1.2 | |
| JVC LT-22E520 | x | x | 1.2 | |
| JVC LT-22E53B | x | x | 1.2 | |
| JVC LT-22E53W | x | x | 1.2 | |
| JVC LT-24E45B | x | x | 1.3 | |
| JVC LT-24E520 | x | x | 1.2 | |
| JVC LT-24E53B | x | x | 1.2 | |
| JVC LT-24E53W | x | x | 1.2 | |
| JVC LT-28E320 | x | x | 1.2 | |
| JVC LT-32E320 | x | x | 1.2 | |
| JVC LT-32E33B | x | x | 1.2 | |
| JVC LT-32E33W | x | x | 1.2 | |
| JVC LT-32E35B | x | x | 1.3 | |
| JVC LT-32E35W | x | x | 1.3 | |
| JVC LT-32E54B | x | x | 1.2 | |
| JVC LT-32E54W | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| JVC LT-40E71 | x | x | 1.2 | |
| JVC LT-40E710 | x | x | 1.2 | |
| JVC LT-40TG52N | x | x | 1.2 | |
| JVC LT-42E55B | x | x | 1.3 | |
| JVC LT-42E55W | x | x | 1.3 | |
| JVC LT-46TG52N | x | x | 1.2 | |
| JVC LT-50E55B | x | x | 1.3 | |
| JVC LT-50E55W | x | x | 1.3 | |
| JVC LT-50E73 | x | x | 1.2 | |
| JVC LT-55E55B | x | x | 1.3 | |
| JVC LT-55E55W | x | x | 1.3 | |
| JVC LT-55E73 | x | x | 1.2 | |
| JVC LT-65E55B | x | x | 1.3 | |
| JVC LT-65E75 | x | x | 1.2 | |
| LG 105UC9V.AEN | x | x | 1.2 | |
| LG 19LS350T-ZA | x | x | 1.2 | |
| LG 22LB450U.AEN | x | x | 1.2 | |
| LG 22LB457U.AEN | x | x | 1.2 | |
| LG 22LB490U.AEN | x | x | 1.2 | |
| LG 22LB491U.AEN | x | x | 1.2 | |
| LG 22LB498U.AEN | x | x | 1.2 | |
| LG 22LN450U | x | x | 1.2 | |
| LG 22LN457U | x | x | 1.2 | |
| LG 22LS350T-ZA | x | x | 1.2 | |
| LG 22LS540T | x | x | 1.2 | |
| LG 22LS540T-ZA | x | x | 1.2 | |
| LG 22MA33V | x | x | 1.2 | |
| LG 22MA53V | x | x | 1.2 | |
| LG 23MA53V | x | x | 1.2 | |
| LG 23MA73V | x | x | 1.2 | |
| LG 24LB450U.AEN | x | x | 1.2 | |
| LG 24LB457U.AEN | x | x | 1.2 | |
| LG 24MA53V | x | x | 1.2 | |
| LG 24MN33V | x | x | 1.2 | |
| LG 24MN43T | x | x | 1.2 | |
| LG 26CS460T-ZA | x | x | 1.2 | |
| LG 26LN450U | x | x | 1.2 | |
| LG 26LN457U | x | x | 1.2 | |
| LG 26LN460U | x | x | 1.2 | |
| LG 26LS350T-ZA | x | x | 1.2 | |
| LG 26LS351T-ZA | x | x | 1.2 | |
| LG 26LS359T-ZC | x | x | 1.2 | |
| LG 26MA33V | x | x | 1.2 | |
| LG 27LS540T | x | x | 1.2 | |
| LG 27LS540T-ZA | x | x | 1.2 | |
| LG 27MA43T | x | x | 1.2 | |
| LG 27MA53V | x | x | 1.2 | |
| LG 27MA73V | x | x | 1.2 | |
| LG 28LB450U.AEN | x | x | 1.2 | |
| LG 28LB457U.AEN | x | x | 1.2 | |
| LG 28LB490U.AEN | x | x | 1.2 | |
| LG 28LB491U.AEN | x | x | 1.2 | |
| LG 28LB498U.AEN | x | x | 1.2 | |
| LG 28LN450U | x | x | 1.2 | |
| LG 28LN457U | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 29LN450U | x | x | 1.2 | |
| LG 29LN457U | x | x | 1.2 | |
| LG 29LN460U | x | x | 1.2 | |
| LG 29MN33V | x | x | 1.2 | |
| LG 32CS460T-ZA | x | x | 1.2 | |
| LG 32CS460-ZA | x | x | 1.2 | |
| LG 32LA615V | x | x | 1.2 | |
| LG 32LA616V | x | x | 1.2 | |
| LG 32LA620V | x | x | 1.2 | |
| LG 32LA640V | x | x | 1.2 | |
| LG 32LA641V | x | x | 1.2 | |
| LG 32LA660V | x | x | 1.2 | |
| LG 32LA662V | x | x | 1.2 | |
| LG 32LA667V | x | x | 1.2 | |
| LG 32LB550U.AEN | x | x | 1.2 | |
| LG 32LB561U.AEN | x | x | 1.2 | |
| LG 32LB561V.AEN | x | x | 1.2 | |
| LG 32LB570U.AEN | x | x | 1.2 | |
| LG 32LB570V.AEN | x | x | 1.2 | |
| LG 32LB572U.AEN | x | x | 1.2 | |
| LG 32LB572V.AEN | x | x | 1.2 | |
| LG 32LB580U.AEN | x | x | 1.2 | |
| LG 32LB580V.AEN | x | x | 1.2 | |
| LG 32LB582U.AEN | x | x | 1.2 | |
| LG 32LB582V.AEN | x | x | 1.2 | |
| LG 32LB650V.AEN | x | x | 1.2 | |
| LG 32LB652V.AEN | x | x | 1.2 | |
| LG 32LB653V.AEN | x | x | 1.2 | |
| LG 32LF560V | x | x | 1.3 | |
| LG 32LF5923 | x | x | 1.3 | |
| LG 32LF592U | x | x | 1.3 | |
| LG 32LF630V | x | x | 1.3 | |
| LG 32LF631V | x | x | 1.3 | |
| LG 32LF633V | x | x | 1.3 | |
| LG 32LF650V | x | x | 1.3 | |
| LG 32LF653V | x | x | 1.3 | |
| LG 32LF655V | x | x | 1.3 | |
| LG 32LH510U | x | x | 1.3 | |
| LG 32LH570U | x | x | 1.3 | |
| LG 32LH590U | x | x | 1.3 | |
| LG 32LH6047 | x | x | 1.3 | |
| LG 32LH604V | x | x | 1.3 | |
| LG 32LJ590U | x | x | 1.3 | |
| LG 32LJ610V | x | x | 1.3 | |
| LG 32LJ614V | x | x | 1.3 | |
| LG 32LK6100PLB | x | x | 1.4 | |
| LG 32LK610BPLB | x | x | 1.4 | |
| LG 32LK6200PLA | x | x | 1.4 | |
| LG 32LM3400-ZA | x | x | 1.2 | |
| LG 32LM340T-ZA | x | x | 1.2 | |
| LG 32LM440T-ZA | x | x | 1.2 | |
| LG 32LM570T-ZA | x | x | 1.2 | |
| LG 32LM580T-ZA | x | x | 1.2 | |
| LG 32LM611C-ZE | x | x | 1.2 | |
| LG 32LM611H-ZA | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 32LM611T-ZE | x | x | 1.2 | |
| LG 32LM620T-ZE | x | x | 1.2 | |
| LG 32LM621T-ZD | x | x | 1.2 | |
| LG 32LM660T-ZA | x | x | 1.2 | |
| LG 32LM669T-ZC | x | x | 1.2 | |
| LG 32LN540U | x | x | 1.2 | |
| LG 32LN540V | x | x | 1.2 | |
| LG 32LN541V | x | x | 1.2 | |
| LG 32LN542V | x | x | 1.2 | |
| LG 32LN570V | x | x | 1.2 | |
| LG 32LN575U | x | x | 1.2 | |
| LG 32LN575V | x | x | 1.2 | |
| LG 32LN577V | x | x | 1.2 | |
| LG 32LN578V | x | x | 1.2 | |
| LG 32LN610V | x | x | 1.2 | |
| LG 32LN613V | x | x | 1.2 | |
| LG 32LS3400-ZA | x | x | 1.2 | |
| LG 32LS340T-ZA | x | x | 1.2 | |
| LG 32LS345T-ZA | x | x | 1.2 | |
| LG 32LS350T-ZA | x | x | 1.2 | |
| LG 32LS351T-ZA | x | x | 1.2 | |
| LG 32LS359T-ZC | x | x | 1.2 | |
| LG 32LS440T-ZA | x | x | 1.2 | |
| LG 32LS5600-ZC | x | x | 1.2 | |
| LG 32LS560T-ZA | x | x | 1.2 | |
| LG 32LS561T-ZA | x | x | 1.2 | |
| LG 32LS570T-ZB | x | x | 1.2 | |
| LG 32LS575T-ZB | x | x | 1.2 | |
| LG 32LS575T-ZD | x | x | 1.2 | |
| LG 32LV375W | x | x | 1.2 | |
| LG 32LV550W | x | x | 1.2 | |
| LG 32LW550W | x | x | 1.2 | |
| LG 37LM340T-ZA | x | x | 1.2 | |
| LG 37LM440T-ZA | x | x | 1.2 | |
| LG 37LM570T-ZA | x | x | 1.2 | |
| LG 37LM611C-ZE | x | x | 1.2 | |
| LG 37LM611H-ZA | x | x | 1.2 | |
| LG 37LM611T-ZE | x | x | 1.2 | |
| LG 37LM620T-ZE | x | x | 1.2 | |
| LG 37LM621T-ZD | x | x | 1.2 | |
| LG 37LN540U | x | x | 1.2 | |
| LG 37LS340T-ZA | x | x | 1.2 | |
| LG 37LS440T-ZA | x | x | 1.2 | |
| LG 37LS560T-ZA | x | x | 1.2 | |
| LG 37LS570T-ZB | x | x | 1.2 | |
| LG 37LS575T-ZB | x | x | 1.2 | |
| LG 37LS575T-ZD | x | x | 1.2 | |
| LG 37LV375W | x | x | 1.2 | |
| LG 37LV550W | x | x | 1.2 | |
| LG 39LA620V | x | x | 1.2 | |
| LG 39LB561V.AEN | x | x | 1.2 | |
| LG 39LB570V.AEN | x | x | 1.2 | |
| LG 39LB572V.AEN | x | x | 1.2 | |
| LG 39LB580V.AEN | x | x | 1.2 | |
| LG 39LB650V.AEN | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 39LN540V | x | x | 1.2 | |
| LG 39LN575V | x | x | 1.2 | |
| LG 39LN577V | x | x | 1.2 | |
| LG 39LN578V | x | x | 1.2 | |
| LG 40LF573V | x | x | 1.3 | |
| LG 40LF630V | x | x | 1.3 | |
| LG 40LF631V | x | x | 1.3 | |
| LG 40LF633V | x | x | 1.3 | |
| LG 40LJ624V | x | x | 1.3 | |
| LG 40UB800V | x | x | 1.3 | |
| LG 40UF7707 | x | x | 1.3 | |
| LG 40UF7727 | x | x | 1.3 | |
| LG 40UF7767 | x | x | 1.3 | |
| LG 40UF7787 | x | x | 1.3 | |
| LG 40UF778V | x | x | 1.3 | |
| LG 40UH630V | x | x | 1.3 | |
| LG 42CS460T-ZA | x | x | 1.2 | |
| LG 42CS460-ZA | x | x | 1.2 | |
| LG 42LA615V | x | x | 1.2 | |
| LG 42LA616V | x | x | 1.2 | |
| LG 42LA620V | x | x | 1.2 | |
| LG 42LA640V | x | x | 1.2 | |
| LG 42LA641V | x | x | 1.2 | |
| LG 42LA660V | x | x | 1.2 | |
| LG 42LA662V | x | x | 1.2 | |
| LG 42LA667V | x | x | 1.2 | |
| LG 42LA669V | x | x | 1.2 | |
| LG 42LA690V | x | x | 1.2 | |
| LG 42LA691V | x | x | 1.2 | |
| LG 42LA692V | x | x | 1.2 | |
| LG 42LA740V | x | x | 1.2 | |
| LG 42LA790W | x | x | 1.2 | |
| LG 42LA860W | x | x | 1.2 | |
| LG 42LB550V.AEN | x | x | 1.2 | |
| LG 42LB561V.AEN | x | x | 1.2 | |
| LG 42LB570V.AEN | x | x | 1.2 | |
| LG 42LB572V.AEN | x | x | 1.2 | |
| LG 42LB580V.AEN | x | x | 1.2 | |
| LG 42LB582V.AEN | x | x | 1.2 | |
| LG 42LB620V.AEN | x | x | 1.2 | |
| LG 42LB630V.AEN | x | x | 1.2 | |
| LG 42LB631V.AEN | x | x | 1.2 | |
| LG 42LB650V.AEN | x | x | 1.2 | |
| LG 42LB652V.AEN | x | x | 1.2 | |
| LG 42LB653V.AEN | x | x | 1.2 | |
| LG 42LB670V.AEN | x | x | 1.2 | |
| LG 42LB671V.AEN | x | x | 1.2 | |
| LG 42LB673V.AEN | x | x | 1.2 | |
| LG 42LB675V.AEN | x | x | 1.2 | |
| LG 42LB677V.AEN | x | x | 1.2 | |
| LG 42LB679V.AEN | x | x | 1.2 | |
| LG 42LB680V.AEN | x | x | 1.2 | |
| LG 42LB690V.AEN | x | x | 1.2 | |
| LG 42LB700V.AEN | x | x | 1.2 | |
| LG 42LB701V.AEN | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 42LB720V.AEN | x | x | 1.2 | |
| LG 42LB730V.AEN | x | x | 1.2 | |
| LG 42LB731V.AEN | x | x | 1.2 | |
| LG 42LF560V | x | x | 1.3 | |
| LG 42LF650V | x | x | 1.3 | |
| LG 42LF653V | x | x | 1.3 | |
| LG 42LF655V | x | x | 1.3 | |
| LG 42LF670V | x | x | 1.3 | |
| LG 42LF673V | x | x | 1.3 | |
| LG 42LF675V | x | x | 1.3 | |
| LG 42LF720V | x | x | 1.3 | |
| LG 42LM3400-ZA | x | x | 1.2 | |
| LG 42LM340T-ZA | x | x | 1.2 | |
| LG 42LM440T-ZA | x | x | 1.2 | |
| LG 42LM570T-ZA | x | x | 1.2 | |
| LG 42LM580T-ZA | x | x | 1.2 | |
| LG 42LM615C-ZE | x | x | 1.2 | |
| LG 42LM615H-ZE | x | x | 1.2 | |
| LG 42LM615T-ZE | x | x | 1.2 | |
| LG 42LM620T-ZE | x | x | 1.2 | |
| LG 42LM621T-ZD | x | x | 1.2 | |
| LG 42LM640T-ZA | x | x | 1.2 | |
| LG 42LM660T-ZA | x | x | 1.2 | |
| LG 42LM669T-ZC | x | x | 1.2 | |
| LG 42LM670T-ZA | x | x | 1.2 | |
| LG 42LM671T-ZB | x | x | 1.2 | |
| LG 42LM760T-ZB | x | x | 1.2 | |
| LG 42LM761T-ZA | x | x | 1.2 | |
| LG 42LM765T-ZD | x | x | 1.2 | |
| LG 42LM860V | x | x | 1.2 | |
| LG 42LM860W | x | x | 1.2 | |
| LG 42LN540V | x | x | 1.2 | |
| LG 42LN541V | x | x | 1.2 | |
| LG 42LN542V | x | x | 1.2 | |
| LG 42LN570V | x | x | 1.2 | |
| LG 42LN575V | x | x | 1.2 | |
| LG 42LN577V | x | x | 1.2 | |
| LG 42LN578V | x | x | 1.2 | |
| LG 42LN610V | x | x | 1.2 | |
| LG 42LN613V | x | x | 1.2 | |
| LG 42LN650V | x | x | 1.2 | |
| LG 42LS3400-ZA | x | x | 1.2 | |
| LG 42LS340T-ZA | x | x | 1.2 | |
| LG 42LS440T-ZA | x | x | 1.2 | |
| LG 42LS5600-ZC | x | x | 1.2 | |
| LG 42LS560T-ZA | x | x | 1.2 | |
| LG 42LS561T-ZA | x | x | 1.2 | |
| LG 42LS570T-ZB | x | x | 1.2 | |
| LG 42LS575T-ZB | x | x | 1.2 | |
| LG 42LS575T-ZD | x | x | 1.2 | |
| LG 42LV375W | x | x | 1.2 | |
| LG 42LV550W | x | x | 1.2 | |
| LG 42LW550W | x | x | 1.2 | |
| LG 42LW650W | x | x | 1.2 | |
| LG 42LW770W | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 42PA450T-ZF | x | x | 1.2 | |
| LG 42PM470T-Z* | x | x | 1.2 | |
| LG 42PN450D-ZA | x | x | 1.2 | |
| LG 42UB820V | x | x | 1.3 | |
| LG 43LF540V | x | x | 1.3 | |
| LG 43LF573V | x | x | 1.3 | |
| LG 43LF5909 | x | x | 1.3 | |
| LG 43LF590V | x | x | 1.3 | |
| LG 43LF630V | x | x | 1.3 | |
| LG 43LF631V | x | x | 1.3 | |
| LG 43LF632V | x | x | 1.3 | |
| LG 43LF633V | x | x | 1.3 | |
| LG 43LH510V | x | x | 1.3 | |
| LG 43LH540V | x | x | 1.3 | |
| LG 43LH570V | x | x | 1.3 | |
| LG 43LH590V | x | x | 1.3 | |
| LG 43LH6047 | x | x | 1.3 | |
| LG 43LH604V | x | x | 1.3 | |
| LG 43LH610V | x | x | 1.3 | |
| LG 43LJ594V | x | x | 1.3 | |
| LG 43LJ614V | x | x | 1.3 | |
| LG 43LK5900PLA | x | x | 1.4 | |
| LG 43LK6100PLB | x | x | 1.4 | |
| LG 43UF6407 | x | x | 1.3 | |
| LG 43UF6409 | x | x | 1.3 | |
| LG 43UF640V | x | x | 1.3 | |
| LG 43UF671V | x | x | 1.3 | |
| LG 43UF675V | x | x | 1.3 | |
| LG 43UF6807 | x | x | 1.3 | |
| LG 43UF680V | x | x | 1.3 | |
| LG 43UF7707 | x | x | 1.3 | |
| LG 43UF770V | x | x | 1.3 | |
| LG 43UF7727 | x | x | 1.3 | |
| LG 43UF772V | x | x | 1.3 | |
| LG 43UF7767 | x | x | 1.3 | |
| LG 43UF776V | x | x | 1.3 | |
| LG 43UF7787 | x | x | 1.3 | |
| LG 43UF778V | x | x | 1.3 | |
| LG 43UH610V | x | x | 1.3 | |
| LG 43UH620V | x | x | 1.3 | |
| LG 43UH650V | x | x | 1.3 | |
| LG 43UH661V | x | x | 1.3 | |
| LG 43UH664V | x | x | 1.3 | |
| LG 43UH668V | x | x | 1.3 | |
| LG 43UH750V | x | x | 1.3 | |
| LG 43UJ630V | x | x | 1.3 | |
| LG 43UJ634V | x | x | 1.3 | |
| LG 43UJ651V | x | x | 1.3 | |
| LG 43UJ670V | x | x | 1.3 | |
| LG 43UJ701V | x | x | 1.3 | |
| LG 43UJ750V | x | x | 1.3 | |
| LG 43UK6200PLA | x | x | 1.4 | |
| LG 43UK6300PLB | x | x | 1.4 | |
| LG 43UK6400PLF | x | x | 1.4 | |
| LG 43UK6470PLC | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 43UK6500PLA | x | x | 1.4 | |
| LG 43UK6750PLD | x | x | 1.4 | |
| LG 43UK6950PLB | x | x | 1.4 | |
| LG 47EA880W | x | x | 1.2 | |
| LG 47LA615V | x | x | 1.2 | |
| LG 47LA616V | x | x | 1.2 | |
| LG 47LA620V | x | x | 1.2 | |
| LG 47LA640V | x | x | 1.2 | |
| LG 47LA641V | x | x | 1.2 | |
| LG 47LA660V | x | x | 1.2 | |
| LG 47LA662V | x | x | 1.2 | |
| LG 47LA667V | x | x | 1.2 | |
| LG 47LA669V | x | x | 1.2 | |
| LG 47LA690V | x | x | 1.2 | |
| LG 47LA691V | x | x | 1.2 | |
| LG 47LA692V | x | x | 1.2 | |
| LG 47LA710V | x | x | 1.2 | |
| LG 47LA740V | x | x | 1.2 | |
| LG 47LA790W | x | x | 1.2 | |
| LG 47LA860W | x | x | 1.2 | |
| LG 47LA960W | x | x | 1.2 | |
| LG 47LB561V.AEN | x | x | 1.2 | |
| LG 47LB570V.AEN | x | x | 1.2 | |
| LG 47LB572V.AEN | x | x | 1.2 | |
| LG 47LB580V.AEN | x | x | 1.2 | |
| LG 47LB582V.AEN | x | x | 1.2 | |
| LG 47LB610V.AEN | x | x | 1.2 | |
| LG 47LB630V.AEN | x | x | 1.2 | |
| LG 47LB631V.AEN | x | x | 1.2 | |
| LG 47LB650V.AEN | x | x | 1.2 | |
| LG 47LB652V.AEN | x | x | 1.2 | |
| LG 47LB653V.AEN | x | x | 1.2 | |
| LG 47LB670V.AEN | x | x | 1.2 | |
| LG 47LB671V.AEN | x | x | 1.2 | |
| LG 47LB673V.AEN | x | x | 1.2 | |
| LG 47LB675V.AEN | x | x | 1.2 | |
| LG 47LB677V.AEN | x | x | 1.2 | |
| LG 47LB679V.AEN | x | x | 1.2 | |
| LG 47LB680V.AEN | x | x | 1.2 | |
| LG 47LB690V.AEN | x | x | 1.2 | |
| LG 47LB700V.AEN | x | x | 1.2 | |
| LG 47LB701V.AEN | x | x | 1.2 | |
| LG 47LB720V.AEN | x | x | 1.2 | |
| LG 47LB730V.AEN | x | x | 1.2 | |
| LG 47LB731V.AEN | x | x | 1.2 | |
| LG 47LM460T-ZA | x | x | 1.2 | |
| LG 47LM570T-ZA | x | x | 1.2 | |
| LG 47LM580T-ZA | x | x | 1.2 | |
| LG 47LM615C-ZE | x | x | 1.2 | |
| LG 47LM615T-ZE | x | x | 1.2 | |
| LG 47LM620T-ZE | x | x | 1.2 | |
| LG 47LM621T-ZD | x | x | 1.2 | |
| LG 47LM640T-ZA | x | x | 1.2 | |
| LG 47LM660T-ZA | x | x | 1.2 | |
| LG 47LM669T-ZC | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 47LM670T-ZA | x | x | 1.2 | |
| LG 47LM671T-ZB | x | x | 1.2 | |
| LG 47LM760T-ZB | x | x | 1.2 | |
| LG 47LM761T-ZA | x | x | 1.2 | |
| LG 47LM765T-ZD | x | x | 1.2 | |
| LG 47LM860V | x | x | 1.2 | |
| LG 47LM860W | x | x | 1.2 | |
| LG 47LM940V | x | x | 1.2 | |
| LG 47LM960V | x | x | 1.2 | |
| LG 47LM960W | x | x | 1.2 | |
| LG 47LN540V | x | x | 1.2 | |
| LG 47LN541V | x | x | 1.2 | |
| LG 47LN542V | x | x | 1.2 | |
| LG 47LN570V | x | x | 1.2 | |
| LG 47LN575V | x | x | 1.2 | |
| LG 47LN577V | x | x | 1.2 | |
| LG 47LN578V | x | x | 1.2 | |
| LG 47LN610V | x | x | 1.2 | |
| LG 47LN613V | x | x | 1.2 | |
| LG 47LN650V | x | x | 1.2 | |
| LG 47LS5600-ZC | x | x | 1.2 | |
| LG 47LS560T-ZA | x | x | 1.2 | |
| LG 47LS561T-ZA | x | x | 1.2 | |
| LG 47LV375W | x | x | 1.2 | |
| LG 47LV550W | x | x | 1.2 | |
| LG 47LW550W | x | x | 1.2 | |
| LG 47LW650W | x | x | 1.2 | |
| LG 47LW770W | x | x | 1.2 | |
| LG 47LW950W | x | x | 1.2 | |
| LG 47LW980W | x | x | 1.2 | |
| LG 49JL900V.AEN | x | x | 1.2 | |
| LG 49LB550V.AEN | x | x | 1.2 | |
| LG 49LB620V.AEN | x | x | 1.2 | |
| LG 49LB860V.AEN | x | x | 1.2 | |
| LG 49LB870V.AEN | x | x | 1.2 | |
| LG 49LF540V | x | x | 1.3 | |
| LG 49LF5909 | x | x | 1.3 | |
| LG 49LF590V | x | x | 1.3 | |
| LG 49LF630V | x | x | 1.3 | |
| LG 49LF631V | x | x | 1.3 | |
| LG 49LF632V | x | x | 1.3 | |
| LG 49LF633V | x | x | 1.3 | |
| LG 49LH510V | x | x | 1.3 | |
| LG 49LH540V | x | x | 1.3 | |
| LG 49LH570V | x | x | 1.3 | |
| LG 49LH590V | x | x | 1.3 | |
| LG 49LH604V | x | x | 1.3 | |
| LG 49LJ594V | x | x | 1.3 | |
| LG 49LJ624V | x | x | 1.3 | |
| LG 49LK5900PLA | x | x | 1.4 | |
| LG 49LK6100PLB | x | x | 1.4 | |
| LG 49SJ800V | x | x | 1.3 | |
| LG 49SK7900PLA | x | x | 1.4 | |
| LG 49SK8000PLB | x | x | 1.4 | |
| LG 49SK8100PLA | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 49SK8500PLA | x | x | 1.4 | |
| LG 49UB820V | x | x | 1.3 | |
| LG 49UB830V | x | x | 1.3 | |
| LG 49UB850V.AEN | x | x | 1.2 | |
| LG 49UF6407 | x | x | 1.3 | |
| LG 49UF6409 | x | x | 1.3 | |
| LG 49UF640V | x | x | 1.3 | |
| LG 49UF671V | x | x | 1.3 | |
| LG 49UF675V | x | x | 1.3 | |
| LG 49UF6807 | x | x | 1.3 | |
| LG 49UF680V | x | x | 1.3 | |
| LG 49UF7707 | x | x | 1.3 | |
| LG 49UF770V | x | x | 1.3 | |
| LG 49UF7727 | x | x | 1.3 | |
| LG 49UF772V | x | x | 1.3 | |
| LG 49UF7767 | x | x | 1.3 | |
| LG 49UF776V | x | x | 1.3 | |
| LG 49UF7787 | x | x | 1.3 | |
| LG 49UF778V | x | x | 1.3 | |
| LG 49UF8407 | x | x | 1.3 | |
| LG 49UF840V | x | x | 1.3 | |
| LG 49UF850V | x | x | 1.3 | |
| LG 49UF853V | x | x | 1.3 | |
| LG 49UH610V | x | x | 1.3 | |
| LG 49UH620V | x | x | 1.3 | |
| LG 49UH650V | x | x | 1.3 | |
| LG 49UH661V | x | x | 1.3 | |
| LG 49UH664V | x | x | 1.3 | |
| LG 49UH668V | x | x | 1.3 | |
| LG 49UH750V | x | x | 1.3 | |
| LG 49UH770V | x | x | 1.3 | |
| LG 49UH790V | x | x | 1.3 | |
| LG 49UH850V | x | x | 1.3 | |
| LG 49UJ630V | x | x | 1.3 | |
| LG 49UJ634V | x | x | 1.3 | |
| LG 49UJ651V | x | x | 1.3 | |
| LG 49UJ670V | x | x | 1.3 | |
| LG 49UJ701V | x | x | 1.3 | |
| LG 49UJ750V | x | x | 1.3 | |
| LG 49UK6200PLA | x | x | 1.4 | |
| LG 49UK6300PLB | x | x | 1.4 | |
| LG 49UK6400PLF | x | x | 1.4 | |
| LG 49UK6470PLC | x | x | 1.4 | |
| LG 49UK7550PLA | x | x | 1.4 | |
| LG 50LA620V | x | x | 1.2 | |
| LG 50LA640V | x | x | 1.2 | |
| LG 50LA660V | x | x | 1.2 | |
| LG 50LA667V | x | x | 1.2 | |
| LG 50LB561V.AEN | x | x | 1.2 | |
| LG 50LB570V.AEN | x | x | 1.2 | |
| LG 50LB580V.AEN | x | x | 1.2 | |
| LG 50LB582V.AEN | x | x | 1.2 | |
| LG 50LB610V.AEN | x | x | 1.2 | |
| LG 50LB650V.AEN | x | x | 1.2 | |
| LG 50LB653V.AEN | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 50LB670V.AEN | x | x | 1.2 | |
| LG 50LB671V.AEN | x | x | 1.2 | |
| LG 50LB675V.AEN | x | x | 1.2 | |
| LG 50LB677V.AEN | x | x | 1.2 | |
| LG 50LF560V | x | x | 1.3 | |
| LG 50LF650V | x | x | 1.3 | |
| LG 50LF653V | x | x | 1.3 | |
| LG 50LN540V | x | x | 1.2 | |
| LG 50LN541V | x | x | 1.2 | |
| LG 50LN542V | x | x | 1.2 | |
| LG 50LN570V | x | x | 1.2 | |
| LG 50LN575V | x | x | 1.2 | |
| LG 50LN577V | x | x | 1.2 | |
| LG 50LN578V | x | x | 1.2 | |
| LG 50PA450T-ZF | x | x | 1.2 | |
| LG 50PA550T-ZB | x | x | 1.2 | |
| LG 50PA650T-ZA | x | x | 1.2 | |
| LG 50PB560U.AEN | x | x | 1.2 | |
| LG 50PB560V.AEN | x | x | 1.2 | |
| LG 50PB660V.AEN | x | x | 1.2 | |
| LG 50PB690V.AEN | x | x | 1.2 | |
| LG 50PH660V | x | x | 1.2 | |
| LG 50PH670V | x | x | 1.2 | |
| LG 50PH672V | x | x | 1.2 | |
| LG 50PM470T-Z* | x | x | 1.2 | |
| LG 50PM670T-Z* | x | x | 1.2 | |
| LG 50PM680T-Z* | x | x | 1.2 | |
| LG 50PM690T-Z* | x | x | 1.2 | |
| LG 50PM970T-Z* | x | x | 1.2 | |
| LG 50PN450D-ZA | x | x | 1.2 | |
| LG 50PN650T-ZA | x | x | 1.2 | |
| LG 50PZ570W | x | x | 1.2 | |
| LG 50PZ750W | x | x | 1.2 | |
| LG 50PZ950W | x | x | 1.2 | |
| LG 50UF8307 | x | x | 1.3 | |
| LG 50UF830V | x | x | 1.3 | |
| LG 50UH635V | x | x | 1.3 | |
| LG 50UK6300PLB | x | x | 1.4 | |
| LG 50UK6410PLC | x | x | 1.4 | |
| LG 50UK6470PLC | x | x | 1.4 | |
| LG 50UK6500PLA | x | x | 1.4 | |
| LG 50UK6750PLD | x | x | 1.4 | |
| LG 50UK6950PLB | x | x | 1.4 | |
| LG 55EA880W | x | x | 1.2 | |
| LG 55EA980W | x | x | 1.2 | |
| LG 55EF9509 | x | x | 1.3 | |
| LG 55EF950V | x | x | 1.3 | |
| LG 55EG9209 | x | x | 1.3 | |
| LG 55EG920V | x | x | 1.3 | |
| LG 55EG960V | x | x | 1.3 | |
| LG 55EG965V | x | x | 1.3 | |
| LG 55JL900V.AEN | x | x | 1.2 | |
| LG 55LA620V | x | x | 1.2 | |
| LG 55LA640V | x | x | 1.2 | |
| LG 55LA641V | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 55LA660V | x | x | 1.2 | |
| LG 55LA662V | x | x | 1.2 | |
| LG 55LA667V | x | x | 1.2 | |
| LG 55LA690V | x | x | 1.2 | |
| LG 55LA691V | x | x | 1.2 | |
| LG 55LA692V | x | x | 1.2 | |
| LG 55LA710V | x | x | 1.2 | |
| LG 55LA740V | x | x | 1.2 | |
| LG 55LA790W | x | x | 1.2 | |
| LG 55LA860W | x | x | 1.2 | |
| LG 55LA960W | x | x | 1.2 | |
| LG 55LA970W | x | x | 1.2 | |
| LG 55LB561V.AEN | x | x | 1.2 | |
| LG 55LB580V.AEN | x | x | 1.2 | |
| LG 55LB582V.AEN | x | x | 1.2 | |
| LG 55LB610V.AEN | x | x | 1.2 | |
| LG 55LB620V.AEN | x | x | 1.2 | |
| LG 55LB630V.AEN | x | x | 1.2 | |
| LG 55LB631V.AEN | x | x | 1.2 | |
| LG 55LB650V.AEN | x | x | 1.2 | |
| LG 55LB652V.AEN | x | x | 1.2 | |
| LG 55LB653V.AEN | x | x | 1.2 | |
| LG 55LB670V.AEN | x | x | 1.2 | |
| LG 55LB671V.AEN | x | x | 1.2 | |
| LG 55LB673V.AEN | x | x | 1.2 | |
| LG 55LB675V.AEN | x | x | 1.2 | |
| LG 55LB679V.AEN | x | x | 1.2 | |
| LG 55LB680V.AEN | x | x | 1.2 | |
| LG 55LB690V.AEN | x | x | 1.2 | |
| LG 55LB700V.AEN | x | x | 1.2 | |
| LG 55LB701V.AEN | x | x | 1.2 | |
| LG 55LB720V.AEN | x | x | 1.2 | |
| LG 55LB730V.AEN | x | x | 1.2 | |
| LG 55LB731V.AEN | x | x | 1.2 | |
| LG 55LB860V.AEN | x | x | 1.2 | |
| LG 55LB870V.AEN | x | x | 1.2 | |
| LG 55LF560V | x | x | 1.3 | |
| LG 55LF5929 | x | x | 1.3 | |
| LG 55LF592V | x | x | 1.3 | |
| LG 55LF630V | x | x | 1.3 | |
| LG 55LF631V | x | x | 1.3 | |
| LG 55LF650V | x | x | 1.3 | |
| LG 55LF655V | x | x | 1.3 | |
| LG 55LF670V | x | x | 1.3 | |
| LG 55LF673V | x | x | 1.3 | |
| LG 55LF675V | x | x | 1.3 | |
| LG 55LF720V | x | x | 1.3 | |
| LG 55LH545V | x | x | 1.3 | |
| LG 55LH604V | x | x | 1.3 | |
| LG 55LH610V | x | x | 1.3 | |
| LG 55LJ550V | x | x | 1.3 | |
| LG 55LJ615V | x | x | 1.3 | |
| LG 55LJ625V | x | x | 1.3 | |
| LG 55LM460T-ZA | x | x | 1.2 | |
| LG 55LM570T-ZA | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 55LM580T-ZA | x | x | 1.2 | |
| LG 55LM615C-ZE | x | x | 1.2 | |
| LG 55LM615T-ZE | x | x | 1.2 | |
| LG 55LM620T-ZE | x | x | 1.2 | |
| LG 55LM621T-ZD | x | x | 1.2 | |
| LG 55LM640T-ZA | x | x | 1.2 | |
| LG 55LM660T-ZA | x | x | 1.2 | |
| LG 55LM670T-ZA | x | x | 1.2 | |
| LG 55LM671T-ZB | x | x | 1.2 | |
| LG 55LM760T-ZB | x | x | 1.2 | |
| LG 55LM761T-ZA | x | x | 1.2 | |
| LG 55LM765T-ZD | x | x | 1.2 | |
| LG 55LM860V | x | x | 1.2 | |
| LG 55LM860W | x | x | 1.2 | |
| LG 55LM940V | x | x | 1.2 | |
| LG 55LM960V | x | x | 1.2 | |
| LG 55LM960W | x | x | 1.2 | |
| LG 55LN575V | x | x | 1.2 | |
| LG 55LN578V | x | x | 1.2 | |
| LG 55LN650V | x | x | 1.2 | |
| LG 55LW550W | x | x | 1.2 | |
| LG 55LW650W | x | x | 1.2 | |
| LG 55LW770W | x | x | 1.2 | |
| LG 55LW950W | x | x | 1.2 | |
| LG 55LW980W | x | x | 1.2 | |
| LG 55SJ800V | x | x | 1.3 | |
| LG 55SJ850V | x | x | 1.3 | |
| LG 55SJ950V | x | x | 1.3 | |
| LG 55SK7900PLA | x | x | 1.4 | |
| LG 55SK8000PLB | x | x | 1.4 | |
| LG 55SK8100PLA | x | x | 1.4 | |
| LG 55SK8500PLA | x | x | 1.4 | |
| LG 55SK9500PLA | x | x | 1.4 | |
| LG 55UB820V | x | x | 1.3 | |
| LG 55UB830V | x | x | 1.3 | |
| LG 55UB850V.AEN | x | x | 1.2 | |
| LG 55UB950V.AEN | x | x | 1.2 | |
| LG 55UC970V.AEN | x | x | 1.2 | |
| LG 55UF671V | x | x | 1.3 | |
| LG 55UF675V | x | x | 1.3 | |
| LG 55UF6807 | x | x | 1.3 | |
| LG 55UF680V | x | x | 1.3 | |
| LG 55UF7707 | x | x | 1.3 | |
| LG 55UF770V | x | x | 1.3 | |
| LG 55UF7727 | x | x | 1.3 | |
| LG 55UF772V | x | x | 1.3 | |
| LG 55UF7767 | x | x | 1.3 | |
| LG 55UF776V | x | x | 1.3 | |
| LG 55UF7787 | x | x | 1.3 | |
| LG 55UF778V | x | x | 1.3 | |
| LG 55UF8407 | x | x | 1.3 | |
| LG 55UF840V | x | x | 1.3 | |
| LG 55UF850V | x | x | 1.3 | |
| LG 55UF851V | x | x | 1.3 | |
| LG 55UF852V | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 55UF853V | x | x | 1.3 | |
| LG 55UF855V | x | x | 1.3 | |
| LG 55UF856V | x | x | 1.3 | |
| LG 55UF857V | x | x | 1.3 | |
| LG 55UF940V | x | x | 1.3 | |
| LG 55UF950V | x | x | 1.3 | |
| LG 55UF955V | x | x | 1.3 | |
| LG 55UG870V | x | x | 1.3 | |
| LG 55UG871V | x | x | 1.3 | |
| LG 55UH615V | x | x | 1.3 | |
| LG 55UH6257 | x | x | 1.3 | |
| LG 55UH625V | x | x | 1.3 | |
| LG 55UH650V | x | x | 1.3 | |
| LG 55UH661V | x | x | 1.3 | |
| LG 55UH664V | x | x | 1.3 | |
| LG 55UH668V | x | x | 1.3 | |
| LG 55UH750V | x | x | 1.3 | |
| LG 55UH770V | x | x | 1.3 | |
| LG 55UH790V | x | x | 1.3 | |
| LG 55UH850V | x | x | 1.3 | |
| LG 55UH950V | x | x | 1.3 | |
| LG 55UJ630V | x | x | 1.3 | |
| LG 55UJ634V | x | x | 1.3 | |
| LG 55UJ651V | x | x | 1.3 | |
| LG 55UJ670V | x | x | 1.3 | |
| LG 55UJ701V | x | x | 1.3 | |
| LG 55UJ750V | x | x | 1.3 | |
| LG 55UK6200PLA | x | x | 1.4 | |
| LG 55UK6300PLB | x | x | 1.4 | |
| LG 55UK6400PLF | x | x | 1.4 | |
| LG 55UK6470PLC | x | x | 1.4 | |
| LG 55UK6500PLA | x | x | 1.4 | |
| LG 55UK6750PLD | x | x | 1.4 | |
| LG 55UK6950PLB | x | x | 1.4 | |
| LG 55UK7550PLA | x | x | 1.4 | |
| LG 58UF8307 | x | x | 1.3 | |
| LG 58UF830V | x | x | 1.3 | |
| LG 58UH635V | x | x | 1.3 | |
| LG 60JL900V.AEN | x | x | 1.2 | |
| LG 60LA620V | x | x | 1.2 | |
| LG 60LA640V | x | x | 1.2 | |
| LG 60LA740V | x | x | 1.2 | |
| LG 60LA860W | x | x | 1.2 | |
| LG 60LB561V.AEN | x | x | 1.2 | |
| LG 60LB580V.AEN | x | x | 1.2 | |
| LG 60LB610V.AEN | x | x | 1.2 | |
| LG 60LB650V.AEN | x | x | 1.2 | |
| LG 60LB680V.AEN | x | x | 1.2 | |
| LG 60LB720V.AEN | x | x | 1.2 | |
| LG 60LB730V.AEN | x | x | 1.2 | |
| LG 60LB860V.AEN | x | x | 1.2 | |
| LG 60LB870V.AEN | x | x | 1.2 | |
| LG 60LM640T-ZA | x | x | 1.2 | |
| LG 60LN575V | x | x | 1.2 | |
| LG 60LN578V | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 60LN610V | x | x | 1.2 | |
| LG 60PA550T-ZB | x | x | 1.2 | |
| LG 60PA650T-ZA | x | x | 1.2 | |
| LG 60PB560V.AEN | x | x | 1.2 | |
| LG 60PB660V.AEN | x | x | 1.2 | |
| LG 60PB690V.AEN | x | x | 1.2 | |
| LG 60PH660V | x | x | 1.2 | |
| LG 60PH670V | x | x | 1.2 | |
| LG 60PH672V | x | x | 1.2 | |
| LG 60PM670T-Z* | x | x | 1.2 | |
| LG 60PM680T-Z* | x | x | 1.2 | |
| LG 60PM690T-Z* | x | x | 1.2 | |
| LG 60PM970T-Z* | x | x | 1.2 | |
| LG 60PN650T-ZA | x | x | 1.2 | |
| LG 60PZ570W | x | x | 1.2 | |
| LG 60PZ750W | x | x | 1.2 | |
| LG 60PZ950W | x | x | 1.2 | |
| LG 60SJ800V | x | x | 1.3 | |
| LG 60SJ850V | x | x | 1.3 | |
| LG 60UB820V.AEN | x | x | 1.2 | |
| LG 60UF671V | x | x | 1.3 | |
| LG 60UF675V | x | x | 1.3 | |
| LG 60UF770V | x | x | 1.3 | |
| LG 60UF772V | x | x | 1.3 | |
| LG 60UF776V | x | x | 1.3 | |
| LG 60UF778V | x | x | 1.3 | |
| LG 60UF850V | x | x | 1.3 | |
| LG 60UF853V | x | x | 1.3 | |
| LG 60UH615V | x | x | 1.3 | |
| LG 60UH6257 | x | x | 1.3 | |
| LG 60UH625V | x | x | 1.3 | |
| LG 60UH650V | x | x | 1.3 | |
| LG 60UH770V | x | x | 1.3 | |
| LG 60UH850V | x | x | 1.3 | |
| LG 60UJ630V | x | x | 1.3 | |
| LG 60UJ634V | x | x | 1.3 | |
| LG 60UJ651V | x | x | 1.3 | |
| LG 60UJ750V | x | x | 1.3 | |
| LG 60UK6200PLA | x | x | 1.4 | |
| LG 65EC970V.AEN | x | x | 1.2 | |
| LG 65EF9509 | x | x | 1.3 | |
| LG 65EF950V | x | x | 1.3 | |
| LG 65EF980V | x | x | 1.3 | |
| LG 65EG960V | x | x | 1.3 | |
| LG 65EG965V | x | x | 1.3 | |
| LG 65EG990V | x | x | 1.3 | |
| LG 65LA970W | x | x | 1.2 | |
| LG 65LB680V.AEN | x | x | 1.2 | |
| LG 65LB730V.AEN | x | x | 1.2 | |
| LG 65LM620T-ZB | x | x | 1.2 | |
| LG 65LM621T-ZA | x | x | 1.2 | |
| LG 65SJ800V | x | x | 1.3 | |
| LG 65SJ850V | x | x | 1.3 | |
| LG 65SJ950V | x | x | 1.3 | |
| LG 65SK7900PLA | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 65SK8000PLB | x | x | 1.4 | |
| LG 65SK8100PLA | x | x | 1.4 | |
| LG 65SK8500PLA | x | x | 1.4 | |
| LG 65SK9500PLA | x | x | 1.4 | |
| LG 65UB920V | x | x | 1.3 | |
| LG 65UB950V.AEN | x | x | 1.2 | |
| LG 65UB980V.AEN | x | x | 1.2 | |
| LG 65UC970V.AEN | x | x | 1.2 | |
| LG 65UF671V | x | x | 1.3 | |
| LG 65UF675V | x | x | 1.3 | |
| LG 65UF6807 | x | x | 1.3 | |
| LG 65UF680V | x | x | 1.3 | |
| LG 65UF770V | x | x | 1.3 | |
| LG 65UF772V | x | x | 1.3 | |
| LG 65UF776V | x | x | 1.3 | |
| LG 65UF778V | x | x | 1.3 | |
| LG 65UF850V | x | x | 1.3 | |
| LG 65UF851V | x | x | 1.3 | |
| LG 65UF852V | x | x | 1.3 | |
| LG 65UF853V | x | x | 1.3 | |
| LG 65UF855V | x | x | 1.3 | |
| LG 65UF856V | x | x | 1.3 | |
| LG 65UF857V | x | x | 1.3 | |
| LG 65UF940V | x | x | 1.3 | |
| LG 65UF950V | x | x | 1.3 | |
| LG 65UF955V | x | x | 1.3 | |
| LG 65UG870V | x | x | 1.3 | |
| LG 65UG871V | x | x | 1.3 | |
| LG 65UH615V | x | x | 1.3 | |
| LG 65UH6257 | x | x | 1.3 | |
| LG 65UH625V | x | x | 1.3 | |
| LG 65UH650V | x | x | 1.3 | |
| LG 65UH661V | x | x | 1.3 | |
| LG 65UH664V | x | x | 1.3 | |
| LG 65UH668V | x | x | 1.3 | |
| LG 65UH750V | x | x | 1.3 | |
| LG 65UH770V | x | x | 1.3 | |
| LG 65UH850V | x | x | 1.3 | |
| LG 65UH950V | x | x | 1.3 | |
| LG 65UJ630V | x | x | 1.3 | |
| LG 65UJ634V | x | x | 1.3 | |
| LG 65UJ651V | x | x | 1.3 | |
| LG 65UJ670V | x | x | 1.3 | |
| LG 65UJ701V | x | x | 1.3 | |
| LG 65UJ750V | x | x | 1.3 | |
| LG 65UK6300PLB | x | x | 1.4 | |
| LG 65UK6400PLF | x | x | 1.4 | |
| LG 65UK6470PLC | x | x | 1.4 | |
| LG 65UK6500PLA | x | x | 1.4 | |
| LG 65UK6750PLD | x | x | 1.4 | |
| LG 65UK6950PLB | x | x | 1.4 | |
| LG 65UK7550PLA | x | x | 1.4 | |
| LG 70LA860W | x | x | 1.2 | |
| LG 70LB650V.AEN | x | x | 1.2 | |
| LG 70UF770V | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG 70UF772V | x | x | 1.3 | |
| LG 70UH700V | x | x | 1.3 | |
| LG 70UJ675V | x | x | 1.3 | |
| LG 70UK6950PLA | x | x | 1.4 | |
| LG 72LM950V | x | x | 1.2 | |
| LG 72LM950W | x | x | 1.2 | |
| LG 72LZ970W | x | x | 1.2 | |
| LG 75EA980W | x | x | 1.2 | |
| LG 75SJ955V | x | x | 1.3 | |
| LG 75SK8100PLA | x | x | 1.4 | |
| LG 75UH775V | x | x | 1.3 | |
| LG 75UH780V | x | x | 1.3 | |
| LG 75UH855V | x | x | 1.3 | |
| LG 75UJ675V | x | x | 1.3 | |
| LG 75UK6200PLA | x | x | 1.4 | |
| LG 75UK6500PLA | x | x | 1.4 | |
| LG 77EC980V.AEN | x | x | 1.2 | |
| LG 77EG990V | x | x | 1.3 | |
| LG 79UB980V.AEN | x | x | 1.2 | |
| LG 79UF770V | x | x | 1.3 | |
| LG 79UF945V | x | x | 1.3 | |
| LG 84LM960V | x | x | 1.2 | |
| LG 84LM960W | x | x | 1.2 | |
| LG 84UB980V.AEN | x | x | 1.2 | |
| LG 86SJ957V | x | x | 1.3 | |
| LG 86UF945V | x | x | 1.3 | |
| LG 86UH955V | x | x | 1.3 | |
| LG 86UK6500PLA | x | x | 1.4 | |
| LG 98UB980V.AEN | x | x | 1.2 | |
| LG DM2352T | x | x | 1.2 | |
| LG DM2752T | x | x | 1.2 | |
| LG HR922N | x | x | 1.2 | x |
| LG HR922N-P | x | x | 1.2 | x |
| LG HR923N | x | x | 1.2 | x |
| LG HR923N-P | x | x | 1.2 | x |
| LG HR925N | x | x | 1.2 | x |
| LG HR925N-P | x | x | 1.2 | x |
| LG HR929N | x | x | 1.2 | x |
| LG HR929N-P | x | x | 1.2 | x |
| LG HR932N | x | x | 1.2 | x |
| LG HR932N-P | x | x | 1.2 | x |
| LG HR933N | x | x | 1.2 | x |
| LG HR933N-P | x | x | 1.2 | x |
| LG HR935N | x | x | 1.2 | x |
| LG HR935N-P | x | x | 1.2 | x |
| LG HR939N | x | x | 1.2 | x |
| LG HR939N-P | x | x | 1.2 | x |
| LG M1931T | x | x | 1.2 | |
| LG M2232T | x | x | 1.2 | |
| LG M2252T | x | x | 1.2 | |
| LG M2255T | x | x | 1.2 | |
| LG M2352T | x | x | 1.2 | |
| LG M2382T | x | x | 1.2 | |
| LG M2432T | x | x | 1.2 | |
| LG M2452T | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LG M2482T | x | x | 1.2 | |
| LG M2631T | x | x | 1.2 | |
| LG M2732T | x | x | 1.2 | |
| LG M2752T | x | x | 1.2 | |
| LG M2755T | x | x | 1.2 | |
| LG OLED55B6V | x | x | 1.3 | |
| LG OLED55B7V | x | x | 1.3 | |
| LG OLED55B8PLA | x | x | 1.4 | |
| LG OLED55B8SLC | x | x | 1.4 | |
| LG OLED55C6V | x | x | 1.3 | |
| LG OLED55C7BOZ | x | x | 1.3 | |
| LG OLED55C8LLA | x | x | 1.4 | |
| LG OLED55C8PLA | x | x | 1.4 | |
| LG OLED55E6V | x | x | 1.3 | |
| LG OLED55E7V | x | x | 1.3 | |
| LG OLED55E8LLA | x | x | 1.4 | |
| LG OLED55E8PLA | x | x | 1.4 | |
| LG OLED65B6V | x | x | 1.3 | |
| LG OLED65B7V | x | x | 1.3 | |
| LG OLED65B8PLA | x | x | 1.4 | |
| LG OLED65B8SLC | x | x | 1.4 | |
| LG OLED65C6V | x | x | 1.3 | |
| LG OLED65C7BOZ | x | x | 1.3 | |
| LG OLED65C7V | x | x | 1.3 | |
| LG OLED65C8LLA | x | x | 1.4 | |
| LG OLED65C8PLA | x | x | 1.4 | |
| LG OLED65E6V | x | x | 1.3 | |
| LG OLED65E7V | x | x | 1.3 | |
| LG OLED65E8LLA | x | x | 1.4 | |
| LG OLED65E8PLA | x | x | 1.4 | |
| LG OLED65G6V | x | x | 1.3 | |
| LG OLED65G7V | x | x | 1.3 | |
| LG OLED65G8PLA | x | x | 1.4 | |
| LG OLED65W7S | x | x | 1.3 | |
| LG OLED65W7V | x | x | 1.3 | |
| LG OLED65W8PLA | x | x | 1.4 | |
| LG OLED77C8LLA | x | x | 1.4 | |
| LG OLED77C8PLA | x | x | 1.4 | |
| LG OLED77G6V | x | x | 1.3 | |
| LG OLED77G7V | x | x | 1.3 | |
| LG OLED77W7V | x | x | 1.3 | |
| LG OLED77W8PLA | x | x | 1.4 | |
| LGE 28MT42VF-PZ | x | x | 1.3 | |
| LGE 32LJ500U-ZB | x | x | 1.3 | |
| LGE 32LJ502U-ZB | x | x | 1.3 | |
| LGE 40LJ500V-ZB | x | x | 1.3 | |
| LGE 43LJ500V-ZB | x | x | 1.3 | |
| LOGIK L19HE13N | x | x | 1.2 | |
| LOGIK L22FE13N | x | x | 1.2 | |
| LOGIK L24FE13N | x | x | 1.2 | |
| LOGIK L29HE13N | x | x | 1.2 | |
| LOGIK L32HE13N | x | x | 1.2 | |
| LOGIK L39FE13N | x | x | 1.2 | |
| Luxor 22LEDDV 902C T2 | x | x | 1.2 | |
| Luxor 26LED 920 T2 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| LUXOR 32LCD 810 T2 | x | x | 1.2 | x |
| LUXOR 32LCD 810 T2/2 | x | x | 1.2 | x |
| LUXOR 32LED 910 T2 | x | x | 1.2 | x |
| Luxor 32LED 920 T2 | x | x | 1.2 | |
| Luxor 32LED DV920 T2 | x | x | 1.2 | |
| Luxor 40 LED 920 T2 | x | x | 1.2 | |
| LUXOR LED24HB/DVD | x | x | 1.3 | |
| LUXOR LED24UL | x | x | 1.3 | |
| Luxor LED28ELT | x | x | 1.2 | |
| Luxor LED32DT | x | x | 1.2 | |
| LUXOR LED32GK | x | x | 1.2 | |
| LUXOR LED32HB | x | x | 1.3 | |
| LUXOR LED32HB550 | x | x | 1.3 | |
| LUXOR LED32HSWW | x | x | 1.2 | |
| Luxor LED32NNB | x | x | 1.2 | |
| Luxor LED32NNW | x | x | 1.2 | |
| LUXOR LED32ONB | x | x | 1.2 | |
| Luxor LED32RZT | x | x | 1.2 | |
| LUXOR LED39DBİ | x | x | 1.3 | |
| LUXOR LED39PDBİ | x | x | 1.3 | |
| Luxor LED39RST | x | x | 1.2 | |
| Luxor LED39RT | x | x | 1.2 | |
| Luxor LED39RZT | x | x | 1.2 | |
| Luxor LED39RZT-W | x | x | 1.2 | |
| LUXOR LED40DBi | x | x | 1.3 | |
| LUXOR LED40DBİH | x | x | 1.3 | |
| Luxor LED42FSB | x | x | 1.2 | |
| LUXOR LED42FSWW | x | x | 1.2 | |
| LUXOR LED43FSB | x | x | 1.3 | |
| LUXOR LED43FSWB | x | x | 1.2 | |
| LUXOR LED43ONB | x | x | 1.2 | |
| LUXOR LED48FSWB | x | x | 1.2 | |
| LUXOR LED50DBi | x | x | 1.3 | |
| LUXOR LED50DBIK | x | x | 1.3 | |
| Luxor LED50RST | x | x | 1.2 | |
| Luxor LED50RZ | x | x | 1.2 | |
| LUXOR LED55DBi | x | x | 1.3 | |
| Luxor LED55FSBI5 | x | x | 1.2 | |
| LUXOR LED65FSWB | x | x | 1.2 | |
| Luxor LED65FSWBR | x | x | 1.2 | |
| LUXOR LED65UHDBi | x | x | 1.3 | |
| Pace DIT8030/13 | x | x | | |
| Panasonic TX-24CS500E | x | x | 1.2 | |
| PANASONIC TX-24CW304E | x | x | 1.2 | |
| Panasonic TX-24DS500E | x | x | 1.3 | |
| Panasonic TX-24DS503E | x | x | 1.3 | |
| Panasonic TX-24DW304 | x | x | 1.2 | |
| Panasonic TX-24ES500E | x | x | 1.3 | |
| Panasonic TX-24ES500ETS | x | x | 1.3 | |
| Panasonic TX-24ES513E | x | x | 1.3 | |
| Panasonic TX-24ES513ETS | x | x | 1.3 | |
| PANASONIC TX-24F300E | x | x | 1.3 | |
| PANASONIC TX-24FS350E | x | x | 1.3 | |
| Panasonic TX-24FS503E | x | x | 1.4 | |
| Panasonic TX-32AS500Y | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-32AS501YTS | x | x | 1.2 | |
| Panasonic TX-32AS520Y | x | x | 1.2 | |
| Panasonic TX-32AS600Y | x | x | 1.2 | |
| Panasonic TX-32AS600YW | x | x | 1.2 | |
| Panasonic TX-32ASX603 | x | x | 1.2 | |
| Panasonic TX-32CS500E | x | x | 1.2 | |
| Panasonic TX-32CS600E | x | x | 1.2 | |
| Panasonic TX-32CS600EW | x | x | 1.2 | |
| PANASONIC TX-32CW304E | x | x | 1.2 | |
| Panasonic TX-32DS500E | x | x | 1.3 | |
| Panasonic TX-32DS500ES | x | x | 1.3 | |
| Panasonic TX-32DS503E | x | x | 1.3 | |
| Panasonic TX-32DS600E | x | x | 1.3 | |
| Panasonic TX-32DW304 | x | x | 1.2 | |
| Panasonic TX-32ES400E | x | x | 1.3 | |
| Panasonic TX-32ES403E | x | x | 1.3 | |
| Panasonic TX-32ES500E | x | x | 1.3 | |
| Panasonic TX-32ES510E | x | x | 1.3 | |
| Panasonic TX-32ES513E | x | x | 1.3 | |
| Panasonic TX-32ES600E | x | x | 1.3 | |
| PANASONIC TX-32F300E | x | x | 1.3 | |
| PANASONIC TX-32FS350E | x | x | 1.3 | |
| Panasonic TX-32FS400E | x | x | 1.4 | |
| Panasonic TX-32FS403E | x | x | 1.4 | |
| Panasonic TX-32FS500E | x | x | 1.4 | |
| Panasonic TX-32FS503E | x | x | 1.4 | |
| Panasonic TX-32FS503ETS | x | x | 1.4 | |
| Panasonic TX-39AS500Y | x | x | 1.2 | |
| Panasonic TX-39AS600Y | x | x | 1.2 | |
| Panasonic TX-39AS600YTS | x | x | 1.2 | |
| Panasonic TX-39AS600YW | x | x | 1.2 | |
| Panasonic TX-39AS650E | x | x | 1.2 | |
| Panasonic TX-39AS750ETS | x | x | 1.2 | |
| Panasonic TX-40AS640E | x | x | 1.2 | |
| Panasonic TX-40AX630E | x | x | 1.2 | |
| Panasonic TX-40CS500E | x | x | 1.2 | |
| Panasonic TX-40CS610E | x | x | 1.2 | |
| Panasonic TX-40CS610ES | x | x | 1.2 | |
| Panasonic TX-40CS610EW | x | x | 1.2 | |
| PANASONIC TX-40CW304E | x | x | 1.2 | |
| PANASONIC TX-40CX300E | x | x | 1.2 | |
| PANASONIC TX-40CXW404E | x | x | 1.2 | |
| Panasonic TX-40DS400E | x | x | 1.3 | |
| Panasonic TX-40DS500E | x | x | 1.3 | |
| Panasonic TX-40DS500ES | x | x | 1.3 | |
| Panasonic TX-40DS500ETS | x | x | 1.3 | |
| Panasonic TX-40DS503E | x | x | 1.3 | |
| Panasonic TX-40DS503ETS | x | x | 1.3 | |
| Panasonic TX-40DS630E | x | x | 1.3 | |
| Panasonic TX-40DS630ETS | x | x | 1.3 | |
| Panasonic TX-40DX600E | x | x | 1.3 | |
| Panasonic TX-40DX603E | x | x | 1.3 | |
| Panasonic TX-40DX650E | x | x | 1.3 | |
| Panasonic TX-40DX653E | x | x | 1.3 | |
| Panasonic TX-40DX700E | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-40DX703E | x | x | 1.3 | |
| Panasonic TX-40DX703ETS | x | x | 1.3 | |
| Panasonic TX-40DX730E | x | x | 1.3 | |
| Panasonic TX-40DXE720 | x | x | 1.3 | |
| Panasonic TX-40DXM710 | x | x | 1.3 | |
| Panasonic TX-40DXU601 | x | x | 1.3 | |
| Panasonic TX-40DXU701 | x | x | 1.3 | |
| Panasonic TX-40ES400E | x | x | 1.3 | |
| Panasonic TX-40ES403E | x | x | 1.3 | |
| Panasonic TX-40ES500E | x | x | 1.3 | |
| Panasonic TX-40ES510E | x | x | 1.3 | |
| Panasonic TX-40ES513E | x | x | 1.3 | |
| Panasonic TX-40EX600E | x | x | 1.3 | |
| Panasonic TX-40EX600ETS | x | x | 1.3 | |
| Panasonic TX-40EX603E | x | x | 1.3 | |
| Panasonic TX-40EX603ETS | x | x | 1.3 | |
| Panasonic TX-40EX610E | x | x | 1.3 | |
| Panasonic TX-40EX613E | x | x | 1.3 | |
| Panasonic TX-40EX620E | x | x | 1.3 | |
| Panasonic TX-40EX633E | x | x | 1.3 | |
| Panasonic TX-40EX700E | x | x | 1.3 | |
| Panasonic TX-40EX703E | x | x | 1.3 | |
| Panasonic TX-40EX730E | x | x | 1.3 | |
| Panasonic TX-40EX730ETS | x | x | 1.3 | |
| Panasonic TX-40FS400E | x | x | 1.4 | |
| Panasonic TX-40FS403E | x | x | 1.4 | |
| Panasonic TX-40FS500E | x | x | 1.4 | |
| Panasonic TX-40FS503E | x | x | 1.4 | |
| Panasonic TX-40FX580E | x | x | 1.4 | |
| Panasonic TX-40FX603ETS | x | x | 1.4 | |
| Panasonic TX-40FX730ETS | x | x | 1.4 | |
| Panasonic TX-40GX700E | x | x | 1.4 | |
| Panasonic TX-40GX710E | x | x | 1.4 | |
| Panasonic TX-40GX800E | x | x | 1.4 | |
| Panasonic TX-40GX810E | x | x | 1.4 | |
| Panasonic TX-40GX820E | x | x | 1.4 | |
| Panasonic TX-40GX830E | x | x | 1.4 | |
| Panasonic TX-42AS500Y | x | x | 1.2 | |
| Panasonic TX-42AS520Y | x | x | 1.2 | |
| Panasonic TX-42AS600Y | x | x | 1.2 | |
| Panasonic TX-42AS600YW | x | x | 1.2 | |
| Panasonic TX-42AS650E | x | x | 1.2 | |
| Panasonic TX-42AS740E | x | x | 1.2 | |
| Panasonic TX-42AS750E | x | x | 1.2 | |
| Panasonic TX-42ASE650 | x | x | 1.2 | |
| Panasonic TX-42ASM651 | x | x | 1.2 | |
| Panasonic TX-42ASX603 | x | x | 1.2 | |
| Panasonic TX-43DW304 | x | x | 1.2 | |
| PANASONIC TX-43F300E | x | x | 1.3 | |
| PANASONIC TX-43FS350E | x | x | 1.3 | |
| PANASONIC TX-43FX550E | x | x | 1.3 | |
| PANASONIC TX-43FX555E | x | x | 1.3 | |
| Panasonic TX-43FX600E | x | x | 1.4 | |
| Panasonic TX-43FX603E | x | x | 1.4 | |
| Panasonic TX-43FX613E | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-43FX620E | x | x | 1.4 | |
| Panasonic TX-43FX623E | x | x | 1.4 | |
| Panasonic TX-43FX633E | x | x | 1.4 | |
| Panasonic TX-47AS650E | x | x | 1.2 | |
| Panasonic TX-47AS740E | x | x | 1.2 | |
| Panasonic TX-47AS750E | x | x | 1.2 | |
| Panasonic TX-47AS800E | x | x | 1.2 | |
| Panasonic TX-47AS800ETS | x | x | 1.2 | |
| Panasonic TX-47ASE650 | x | x | 1.2 | |
| Panasonic TX-47ASM651 | x | x | 1.2 | |
| Panasonic TX-48AS640E | x | x | 1.2 | |
| Panasonic TX-48AX630E | x | x | 1.2 | |
| PANASONIC TX-48CW304E | x | x | 1.2 | |
| PANASONIC TX-48CX300E | x | x | 1.2 | |
| PANASONIC TX-48CXW404E | x | x | 1.2 | |
| Panasonic TX-49DS500E | x | x | 1.3 | |
| Panasonic TX-49DS500ES | x | x | 1.3 | |
| Panasonic TX-49DS503E | x | x | 1.3 | |
| Panasonic TX-49DX600E | x | x | 1.3 | |
| Panasonic TX-49DX603E | x | x | 1.3 | |
| Panasonic TX-49DX650E | x | x | 1.3 | |
| Panasonic TX-49DX653E | x | x | 1.3 | |
| Panasonic TX-49DXU601 | x | x | 1.3 | |
| Panasonic TX-49ES400E | x | x | 1.3 | |
| Panasonic TX-49ES403E | x | x | 1.3 | |
| Panasonic TX-49ES500E | x | x | 1.3 | |
| Panasonic TX-49ES510E | x | x | 1.3 | |
| Panasonic TX-49ES513E | x | x | 1.3 | |
| Panasonic TX-49EX600E | x | x | 1.3 | |
| Panasonic TX-49EX603E | x | x | 1.3 | |
| Panasonic TX-49EX610E | x | x | 1.3 | |
| Panasonic TX-49EX613E | x | x | 1.3 | |
| Panasonic TX-49EX620E | x | x | 1.3 | |
| Panasonic TX-49EX633E | x | x | 1.3 | |
| PANASONIC TX-49F300E | x | x | 1.3 | |
| PANASONIC TX-49FS350E | x | x | 1.3 | |
| Panasonic TX-49FS500E | x | x | 1.4 | |
| Panasonic TX-49FS503E | x | x | 1.4 | |
| PANASONIC TX-49FX550E | x | x | 1.3 | |
| PANASONIC TX-49FX555E | x | x | 1.3 | |
| Panasonic TX-49FX580E | x | x | 1.4 | |
| Panasonic TX-49FX600E | x | x | 1.4 | |
| Panasonic TX-49FX603E | x | x | 1.4 | |
| Panasonic TX-49FX613E | x | x | 1.4 | |
| Panasonic TX-49FX620E | x | x | 1.4 | |
| Panasonic TX-49FX623E | x | x | 1.4 | |
| Panasonic TX-49FX633E | x | x | 1.4 | |
| Panasonic TX-49FX700E | x | x | 1.4 | |
| Panasonic TX-49FX740E | x | x | 1.4 | |
| Panasonic TX-49FX780E | x | x | 1.4 | |
| Panasonic TX-49GX900ETS | x | x | 1.4 | |
| Panasonic TX-49GX904ETS | x | x | 1.4 | |
| Panasonic TX-49GX940E | x | x | 1.4 | |
| Panasonic TX-50AS500Y | x | x | 1.2 | |
| Panasonic TX-50AS520Y | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-50AS600Y | x | x | 1.2 | |
| Panasonic TX-50AS650E | x | x | 1.2 | |
| Panasonic TX-50ASX603 | x | x | 1.2 | |
| Panasonic TX-50AX800E | x | x | 1.2 | |
| Panasonic TX-50CS500E | x | x | 1.2 | |
| Panasonic TX-50CS610E | x | x | 1.2 | |
| Panasonic TX-50CS610ES | x | x | 1.2 | |
| Panasonic TX-50DS630E | x | x | 1.3 | |
| Panasonic TX-50DX700E | x | x | 1.3 | |
| Panasonic TX-50DX703E | x | x | 1.3 | |
| Panasonic TX-50DX730E | x | x | 1.3 | |
| Panasonic TX-50DX750E | x | x | 1.3 | |
| Panasonic TX-50DX780E | x | x | 1.3 | |
| Panasonic TX-50DX800E | x | x | 1.3 | |
| Panasonic TX-50DX900ETS | x | x | 1.3 | |
| Panasonic TX-50DXE720 | x | x | 1.3 | |
| Panasonic TX-50DXM710 | x | x | 1.3 | |
| Panasonic TX-50DXU701 | x | x | 1.3 | |
| Panasonic TX-50EX700E | x | x | 1.3 | |
| Panasonic TX-50EX703E | x | x | 1.3 | |
| Panasonic TX-50EX730E | x | x | 1.3 | |
| Panasonic TX-50EX780E | x | x | 1.3 | |
| PANASONIC TX-50FX550E | x | x | 1.3 | |
| PANASONIC TX-50FX555E | x | x | 1.3 | |
| Panasonic TX-50GX700E | x | x | 1.4 | |
| Panasonic TX-50GX710E | x | x | 1.4 | |
| Panasonic TX-50GX800E | x | x | 1.4 | |
| Panasonic TX-50GX810E | x | x | 1.4 | |
| Panasonic TX-50GX820E | x | x | 1.4 | |
| Panasonic TX-50GX830E | x | x | 1.4 | |
| Panasonic TX-55AS640E | x | x | 1.2 | |
| Panasonic TX-55AS650E | x | x | 1.2 | |
| Panasonic TX-55AS740E | x | x | 1.2 | |
| Panasonic TX-55AS750E | x | x | 1.2 | |
| Panasonic TX-55AS800E | x | x | 1.2 | |
| Panasonic TX-55ASM651 | x | x | 1.2 | |
| Panasonic TX-55AX630E | x | x | 1.2 | |
| Panasonic TX-55AX900E | x | x | 1.2 | |
| PANASONIC TX-55CRW434E | x | x | 1.2 | |
| PANASONIC TX-55CRW454 | x | x | 1.2 | |
| Panasonic TX-55CS500E | x | x | 1.2 | |
| Panasonic TX-55CS610E | x | x | 1.2 | |
| Panasonic TX-55CS610ES | x | x | 1.2 | |
| PANASONIC TX-55CW324E | x | x | 1.2 | |
| PANASONIC TX-55CX300E | x | x | 1.2 | |
| PANASONIC TX-55CXW404E | x | x | 1.2 | |
| Panasonic TX-55DR850E | x | x | 1.3 | |
| Panasonic TX-55DS500E | x | x | 1.3 | |
| Panasonic TX-55DS503E | x | x | 1.3 | |
| Panasonic TX-55DX600E | x | x | 1.3 | |
| Panasonic TX-55DX603E | x | x | 1.3 | |
| Panasonic TX-55DX650E | x | x | 1.3 | |
| Panasonic TX-55DX653E | x | x | 1.3 | |
| Panasonic TX-55DXU601 | x | x | 1.3 | |
| Panasonic TX-55EX600E | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-55EX603E | x | x | 1.3 | |
| Panasonic TX-55EX610E | x | x | 1.3 | |
| Panasonic TX-55EX613E | x | x | 1.3 | |
| Panasonic TX-55EX620E | x | x | 1.3 | |
| Panasonic TX-55EX633E | x | x | 1.3 | |
| Panasonic TX-55EZ950E | x | x | 1.3 | |
| PANASONIC TX-55FX550E | x | x | 1.3 | |
| PANASONIC TX-55FX555E | x | x | 1.3 | |
| Panasonic TX-55FX580E | x | x | 1.4 | |
| Panasonic TX-55FX600E | x | x | 1.4 | |
| Panasonic TX-55FX603E | x | x | 1.4 | |
| Panasonic TX-55FX613E | x | x | 1.4 | |
| Panasonic TX-55FX620E | x | x | 1.4 | |
| Panasonic TX-55FX623E | x | x | 1.4 | |
| Panasonic TX-55FX633E | x | x | 1.4 | |
| Panasonic TX-55FX700E | x | x | 1.4 | |
| Panasonic TX-55FX740E | x | x | 1.4 | |
| Panasonic TX-55FX780E | x | x | 1.4 | |
| Panasonic TX-55FZ800E | x | x | 1.4 | |
| Panasonic TX-55FZ950E | x | x | 1.4 | |
| Panasonic TX-55GX940E | x | x | 1.4 | |
| Panasonic TX-55GZ1000E | x | x | 1.4 | |
| Panasonic TX-55GZ1500E | x | x | 1.4 | |
| Panasonic TX-55GZ2000E | x | x | 1.4 | |
| Panasonic TX-55GZ950E | x | x | 1.4 | |
| Panasonic TX-58AX800E | x | x | 1.2 | |
| Panasonic TX-58DX700E | x | x | 1.3 | |
| Panasonic TX-58DX703E | x | x | 1.3 | |
| Panasonic TX-58DX730E | x | x | 1.3 | |
| Panasonic TX-58DX750E | x | x | 1.3 | |
| Panasonic TX-58DX780E | x | x | 1.3 | |
| Panasonic TX-58DX800E | x | x | 1.3 | |
| Panasonic TX-58DX900E | x | x | 1.3 | |
| Panasonic TX-58DXE720 | x | x | 1.3 | |
| Panasonic TX-58DXM710 | x | x | 1.3 | |
| Panasonic TX-58DXU701 | x | x | 1.3 | |
| Panasonic TX-58EX700E | x | x | 1.3 | |
| Panasonic TX-58EX703E | x | x | 1.3 | |
| Panasonic TX-58EX730E | x | x | 1.3 | |
| Panasonic TX-58EX780E | x | x | 1.3 | |
| Panasonic TX-58GX700E | x | x | 1.4 | |
| Panasonic TX-58GX710E | x | x | 1.4 | |
| Panasonic TX-58GX800E | x | x | 1.4 | |
| Panasonic TX-58GX810E | x | x | 1.4 | |
| Panasonic TX-58GX820E | x | x | 1.4 | |
| Panasonic TX-58GX830E | x | x | 1.4 | |
| Panasonic TX-60AS650E | x | x | 1.2 | |
| Panasonic TX-60AS800E | x | x | 1.2 | |
| Panasonic TX-65AX800E | x | x | 1.2 | |
| Panasonic TX-65AX900E | x | x | 1.2 | |
| Panasonic TX-65CS610E | x | x | 1.2 | |
| PANASONIC TX-65CW324E | x | x | 1.2 | |
| PANASONIC TX-65CXW414E | x | x | 1.2 | |
| PANASONIC TX-65CZ950E | x | x | 1.2 | |
| Panasonic TX-65DR850E | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-65DX750E | x | x | 1.3 | |
| Panasonic TX-65DX780E | x | x | 1.3 | |
| Panasonic TX-65DX900E | x | x | 1.3 | |
| Panasonic TX-65EX600E | x | x | 1.3 | |
| Panasonic TX-65EX603E | x | x | 1.3 | |
| Panasonic TX-65EX610E | x | x | 1.3 | |
| Panasonic TX-65EX613E | x | x | 1.3 | |
| Panasonic TX-65EX700E | x | x | 1.3 | |
| Panasonic TX-65EX703E | x | x | 1.3 | |
| Panasonic TX-65EX730E | x | x | 1.3 | |
| Panasonic TX-65EX780E | x | x | 1.3 | |
| Panasonic TX-65EZ1000E | x | x | 1.3 | |
| Panasonic TX-65EZ950E | x | x | 1.3 | |
| PANASONIC TX-65FX560E | x | x | 1.3 | |
| PANASONIC TX-65FX565E | x | x | 1.3 | |
| Panasonic TX-65FX580E | x | x | 1.4 | |
| Panasonic TX-65FX600E | x | x | 1.4 | |
| Panasonic TX-65FX603E | x | x | 1.4 | |
| Panasonic TX-65FX620E | x | x | 1.4 | |
| Panasonic TX-65FX623E | x | x | 1.4 | |
| Panasonic TX-65FX700E | x | x | 1.4 | |
| Panasonic TX-65FX740E | x | x | 1.4 | |
| Panasonic TX-65FX780E | x | x | 1.4 | |
| Panasonic TX-65FZ800E | x | x | 1.4 | |
| Panasonic TX-65FZ950E | x | x | 1.4 | |
| Panasonic TX-65GX700E | x | x | 1.4 | |
| Panasonic TX-65GX710E | x | x | 1.4 | |
| Panasonic TX-65GX800E | x | x | 1.4 | |
| Panasonic TX-65GX810E | x | x | 1.4 | |
| Panasonic TX-65GX820E | x | x | 1.4 | |
| Panasonic TX-65GX830E | x | x | 1.4 | |
| Panasonic TX-65GX940E | x | x | 1.4 | |
| Panasonic TX-65GZ1000E | x | x | 1.4 | |
| Panasonic TX-65GZ1500E | x | x | 1.4 | |
| Panasonic TX-65GZ2000E | x | x | 1.4 | |
| Panasonic TX-65GZ950E | x | x | 1.4 | |
| Panasonic TX-75EX780E | x | x | 1.3 | |
| Panasonic TX-75FX580E | x | x | 1.4 | |
| Panasonic TX-75FX780E | x | x | 1.4 | |
| Panasonic TX-75GX942E | x | x | 1.4 | |
| Panasonic TX-77EZ1000E | x | x | 1.3 | |
| Panasonic TX-85X940E | x | x | 1.2 | |
| Panasonic TX-L19D35ES | x | ? | 1.2 | |
| Panasonic TX-L19D35EW | x | ? | 1.2 | |
| Panasonic TX-L24D35ES | x | ? | 1.2 | |
| Panasonic TX-L24D35EW | x | ? | 1.2 | |
| Panasonic TX-L32DT30Y | x | ? | 1.2 | |
| Panasonic TX-L32DT35E | x | ? | 1.2 | |
| Panasonic TX-L32E30Y | x | ? | 1.2 | |
| Panasonic TX-L32E5Y | x | x | 1.2 | |
| Panasonic TX-L32E6Y | x | x | 1.2 | |
| Panasonic TX-L32EM6Y | x | x | 1.2 | |
| Panasonic TX-L32ET5Y | x | x | 1.2 | |
| Panasonic TX-L32ET60YTS | x | x | 1.2 | |
| Panasonic TX-L37DT30Y | x | ? | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-L37DT35E | x | ? | 1.2 | |
| Panasonic TX-L37E30Y | x | ? | 1.2 | |
| Panasonic TX-L37E5Y | x | x | 1.2 | |
| Panasonic TX-L37ET5Y | x | x | 1.2 | |
| Panasonic TX-L39E6Y | x | x | 1.2 | |
| Panasonic TX-L39E6YK | x | x | 1.2 | |
| Panasonic TX-L39E6YW | x | x | 1.2 | |
| Panasonic TX-L39EM6Y | x | x | 1.2 | |
| Panasonic TX-L42DT50Y | x | x | 1.2 | |
| Panasonic TX-L42DT60Y | x | x | 1.2 | |
| Panasonic TX-L42DT60YTS | x | x | 1.2 | |
| Panasonic TX-L42E30Y | x | ? | 1.2 | |
| Panasonic TX-L42E5Y | x | x | 1.2 | |
| Panasonic TX-L42E5YTS | x | x | 1.2 | |
| Panasonic TX-L42E6Y | x | x | 1.2 | |
| Panasonic TX-L42E6YK | x | x | 1.2 | |
| Panasonic TX-L42E6YW | x | x | 1.2 | |
| Panasonic TX-L42ET50Y | x | x | 1.2 | |
| Panasonic TX-L42ET5Y | x | x | 1.2 | |
| Panasonic TX-L42ET60Y | x | x | 1.2 | |
| Panasonic TX-L42FT60Y | x | x | 1.2 | |
| Panasonic TX-L42FT60YTS | x | x | 1.2 | |
| Panasonic TX-L42WT50Y | x | x | 1.2 | |
| Panasonic TX-L47DT50Y | x | x | 1.2 | |
| Panasonic TX-L47DT60Y | x | x | 1.2 | |
| Panasonic TX-L47E5Y | x | x | 1.2 | |
| Panasonic TX-L47ET50Y | x | x | 1.2 | |
| Panasonic TX-L47ET5Y | x | x | 1.2 | |
| Panasonic TX-L47ET60Y | x | x | 1.2 | |
| Panasonic TX-L47FT60Y | x | x | 1.2 | |
| Panasonic TX-L47WT50Y | x | x | 1.2 | |
| Panasonic TX-L47WT60Y | x | x | 1.2 | |
| Panasonic TX-L50DT60Y | x | x | 1.2 | |
| Panasonic TX-L50E6Y | x | x | 1.2 | |
| Panasonic TX-L50EM6Y | x | x | 1.2 | |
| Panasonic TX-L50ET60Y | x | x | 1.2 | |
| Panasonic TX-L55DT50Y | x | x | 1.2 | |
| Panasonic TX-L55DT60Y | x | x | 1.2 | |
| Panasonic TX-L55ET5Y | x | x | 1.2 | |
| Panasonic TX-L55ET60Y | x | x | 1.2 | |
| Panasonic TX-L55WT50Y | x | x | 1.2 | |
| Panasonic TX-L55WT60Y | x | x | 1.2 | |
| Panasonic TX-L60DT60Y | x | x | 1.2 | |
| Panasonic TX-P42G30Y | x | ? | 1.2 | |
| Panasonic TX-P42GT30Y | x | ? | 1.2 | |
| Panasonic TX-P42GT50Y | x | x | 1.2 | |
| Panasonic TX-P42GT60Y | x | x | 1.2 | |
| Panasonic TX-P42S30Y | x | ? | 1.2 | |
| Panasonic TX-P42ST32Y | x | ? | 1.2 | |
| Panasonic TX-P42ST50Y | x | x | 1.2 | |
| Panasonic TX-P42ST60Y | x | x | 1.2 | |
| Panasonic TX-P42UT30Y | x | ? | 1.2 | |
| Panasonic TX-P42UT50Y | x | x | 1.2 | |
| Panasonic TX-P42VT30Y | x | ? | 1.2 | |
| Panasonic TX-P42XT50Y | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Panasonic TX-P46G30Y | x | ? | 1.2 | |
| Panasonic TX-P46GT30Y | x | ? | 1.2 | |
| Panasonic TX-P46ST32Y | x | ? | 1.2 | |
| Panasonic TX-P50G30Y | x | ? | 1.2 | |
| Panasonic TX-P50GT30Y | x | ? | 1.2 | |
| Panasonic TX-P50GT50Y | x | x | 1.2 | |
| Panasonic TX-P50GT60Y | x | x | 1.2 | |
| Panasonic TX-P50ST32Y | x | ? | 1.2 | |
| Panasonic TX-P50ST50Y | x | x | 1.2 | |
| Panasonic TX-P50ST60Y | x | x | 1.2 | |
| Panasonic TX-P50UT30Y | x | ? | 1.2 | |
| Panasonic TX-P50UT50Y | x | x | 1.2 | |
| Panasonic TX-P50VT30Y | x | ? | 1.2 | |
| Panasonic TX-P50VT50Y | x | x | 1.2 | |
| Panasonic TX-P50VT60Y | x | x | 1.2 | |
| Panasonic TX-P50XT50Y | x | x | 1.2 | |
| Panasonic TX-P55ST50Y | x | x | 1.2 | |
| Panasonic TX-P55ST60Y | x | x | 1.2 | |
| Panasonic TX-P55VT30Y | x | ? | 1.2 | |
| Panasonic TX-P55VT50Y | x | x | 1.2 | |
| Panasonic TX-P55VT60Y | x | x | 1.2 | |
| Panasonic TX-P60ZT60E | x | x | 1.2 | |
| Panasonic TX-P65ST50Y | x | x | 1.2 | |
| Panasonic TX-P65ST60Y | x | x | 1.2 | |
| Panasonic TX-P65VT30Y | x | ? | 1.2 | |
| Panasonic TX-P65VT50Y | x | x | 1.2 | |
| Panasonic TX-P65VT60Y | x | x | 1.2 | |
| Philips 43PUS6101/12 | x | x | 1.3 | |
| Philips 19PFL3507T/12 | x | x | 1.2 | |
| Philips 22PFL3507T/12 | x | x | 1.2 | |
| Philips 22PFL3517T/12 | x | x | 1.2 | |
| Philips 22PFS4022/12 | x | x | 1.3 | |
| Philips 22PFS4031/12 | x | x | 1.3 | |
| Philips 22PFS4232/12 | x | x | 1.3 | |
| Philips 22PFS5303/12 | x | x | 1.3 | |
| Philips 22PFS5403/12 | x | x | 1.3 | |
| Philips 22PFT4000/12 | x | x | 1.3 | |
| Philips 22PFT4022/12 | x | x | 1.3 | |
| Philips 22PFT4031/12 | x | x | 1.3 | |
| Philips 22PFT4109/12 | x | x | 1.2 | |
| Philips 22PFT4232/12 | x | x | 1.3 | |
| Philips 22PFT5303/12 | x | x | 1.3 | |
| Philips 24PFL3507T/12 | x | x | 1.2 | |
| Philips 24PFL4228T/12 | x | x | 1.2 | |
| Philips 24PFS4022/12 | x | x | 1.3 | |
| Philips 24PFS4032/12 | x | x | 1.3 | |
| Philips 24PFS5231/12 | x | x | 1.3 | |
| Philips 24PFS5303/12 | x | x | 1.3 | |
| Philips 24PFS5603/12 | x | x | 1.3 | |
| Philips 24PFS5703/12 | x | x | 1.3 | |
| Philips 24PFS5863/12 | x | x | 1.3 | |
| Philips 24PFT4022/12 | x | x | 1.3 | |
| Philips 24PFT4032/12 | x | x | 1.3 | |
| Philips 24PFT5211/12 | x | x | 1.3 | |
| Philips 24PFT5303/12 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 24PFT5603/12 | x | x | 1.3 | |
| Philips 24PFT5703/12 | x | x | 1.3 | |
| Philips 24PHS4022/12 | x | x | 1.3 | |
| Philips 24PHS4031/12 | x | x | 1.3 | |
| Philips 24PHS4032/12 | x | x | 1.3 | |
| Philips 24PHS4304/12 | x | x | 1.3 | |
| Philips 24PHS4354/12 | x | x | 1.3 | |
| Philips 24PHT4000/12 | x | x | 1.3 | |
| Philips 24PHT4022/12 | x | x | 1.3 | |
| Philips 24PHT4031/12 | x | x | 1.3 | |
| Philips 24PHT4032/12 | x | x | 1.3 | |
| Philips 24PHT4109/12 | x | x | 1.2 | |
| Philips 24PHT5210/12 | x | x | 1.3 | |
| Philips 24PHT5219/12 | x | x | 1.2 | |
| Philips 32PDL7906T/12 | x | x | 1.2 | |
| Philips 32PFL3007T/12 | x | x | 1.2 | |
| Philips 32PFL3008T/12 | x | x | 1.2 | |
| Philips 32PFL3017T/12 | x | x | 1.2 | |
| Philips 32PFL3018T/12 | x | x | 1.2 | |
| Philips 32PFL3208T/12 | x | x | 1.2 | |
| Philips 32PFL3507T/12 | x | x | 1.2 | |
| Philips 32PFL3517T/12 | x | x | 1.2 | |
| Philips 32PFL4007T/12 | x | x | 1.2 | |
| Philips 32PFL4027T/12 | x | x | 1.2 | |
| Philips 32PFL4037T/12 | x | x | 1.2 | |
| Philips 32PFL4208T/12 | x | x | 1.2 | |
| Philips 32PFL4508T/12 | x | x | 1.2 | |
| Philips 32PFL5007T/12 | x | x | 1.2 | |
| Philips 32PFL5008T/12 | x | x | 1.2 | |
| Philips 32PFL5027T/12 | x | x | 1.2 | |
| Philips 32PFL5037T/12 | x | x | 1.2 | |
| Philips 32PFL5507T/12 | x | x | 1.2 | |
| Philips 32PFL6007T/12 | x | x | 1.2 | |
| Philips 32PFL6087T/12 | x | x | 1.2 | |
| Philips 32PFL6606T/12 | x | x | 1.2 | |
| Philips 32PFL6626T/12 | x | x | 1.2 | |
| Philips 32PFL6636T/12 | x | x | 1.2 | |
| Philips 32PFL7406T/12 | x | x | 1.2 | |
| Philips 32PFL7466T/12 | x | x | 1.2 | |
| Philips 32PFL7476T/12 | x | x | 1.2 | |
| Philips 32PFL7496T/12 | x | x | 1.2 | |
| Philips 32PFL7606T/12 | x | x | 1.2 | |
| Philips 32PFL7696T/12 | x | x | 1.2 | |
| Philips 32PFL9606T/12 | x | x | 1.2 | |
| Philips 32PFS4131/12 | x | x | 1.3 | |
| Philips 32PFS4132/12 | x | x | 1.3 | |
| Philips 32PFS5362/12 | x | x | 1.3 | |
| Philips 32PFS5603/12 | x | x | 1.3 | |
| Philips 32PFS5709/12 | x | x | 1.2 | |
| Philips 32PFS5803/12 | x | x | 1.3 | |
| Philips 32PFS5823/12 | x | x | 1.3 | |
| Philips 32PFS5863/12 | x | x | 1.3 | |
| Philips 32PFS6402/12 | x | x | 1.3 | |
| Philips 32PFT4100/12 | x | x | 1.3 | |
| Philips 32PFT4101/12 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 32PFT4131/12 | x | x | 1.3 | |
| Philips 32PFT4132/12 | x | x | 1.3 | |
| Philips 32PFT5300/12 | x | x | 1.2 | |
| Philips 32PFT5362/12 | x | x | 1.3 | |
| Philips 32PFT5500/12 | x | x | 1.3 | |
| Philips 32PFT5501/12 | x | x | 1.3 | |
| Philips 32PFT5509/12 | x | x | 1.2 | |
| Philips 32PFT5603/12 | x | x | 1.3 | |
| Philips 32PFT6500/12 | x | x | 1.3 | |
| Philips 32PHS4032/12 | x | x | 1.3 | |
| Philips 32PHS4112/12 | x | x | 1.3 | |
| Philips 32PHS4131/12 | x | x | 1.3 | |
| Philips 32PHS4132/12 | x | x | 1.3 | |
| Philips 32PHS4503/12 | x | x | 1.3 | |
| Philips 32PHS4503/12M | x | x | 1.3 | |
| Philips 32PHS4504/12 | x | x | 1.3 | |
| Philips 32PHS5301/12 | x | x | 1.3 | |
| Philips 32PHS5302/12 | x | x | 1.3 | |
| Philips 32PHT4032/12 | x | x | 1.3 | |
| Philips 32PHT4100/12 | x | x | 1.3 | |
| Philips 32PHT4101/12 | x | x | 1.3 | |
| Philips 32PHT4109/12 | x | x | 1.2 | |
| Philips 32PHT4112/12 | x | x | 1.3 | |
| Philips 32PHT4131/12 | x | x | 1.3 | |
| Philips 32PHT4132/12 | x | x | 1.3 | |
| Philips 32PHT4200/12 | x | x | 1.3 | |
| Philips 32PHT4201/12 | x | x | 1.3 | |
| Philips 32PHT4309/12 | x | x | 1.2 | |
| Philips 32PHT4319/12 | x | x | 1.2 | |
| Philips 32PHT4503/12 | x | x | 1.3 | |
| Philips 32PHT4503/12M | x | x | 1.3 | |
| Philips 32PHT5301/12 | x | x | 1.3 | |
| Philips 32PHT5302/12 | x | x | 1.3 | |
| Philips 37PFL3007T/12 | x | x | 1.2 | |
| Philips 37PFL3507T/12 | x | x | 1.2 | |
| Philips 37PFL4007T/12 | x | x | 1.2 | |
| Philips 37PFL6007T/12 | x | x | 1.2 | |
| Philips 37PFL6606T/12 | x | x | 1.2 | |
| Philips 37PFL7606T/12 | x | x | 1.2 | |
| Philips 37PFL7666T/12 | x | x | 1.2 | |
| Philips 37PFL7676T/12 | x | x | 1.2 | |
| Philips 37PFL7696T/12 | x | x | 1.2 | |
| Philips 37PFL9606T/12 | x | x | 1.2 | |
| Philips 39PFL3008T/12 | x | x | 1.2 | |
| Philips 39PFL3108T/12 | x | x | 1.2 | |
| Philips 39PFL3208T/12 | x | x | 1.2 | |
| Philips 39PFL4208T/12 | x | x | 1.2 | |
| Philips 40PFL3008T/12 | x | x | 1.2 | |
| Philips 40PFL3018T/12 | x | x | 1.2 | |
| Philips 40PFL4508T/12 | x | x | 1.2 | |
| Philips 40PFL4528T/12 | x | x | 1.2 | |
| Philips 40PFL5007T/12 | x | x | 1.2 | |
| Philips 40PFL5027T/12 | x | x | 1.2 | |
| Philips 40PFL5037T/12 | x | x | 1.2 | |
| Philips 40PFL5507T/12 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 40PFL5527T/12 | x | x | 1.2 | |
| Philips 40PFL5537T/12 | x | x | 1.2 | |
| Philips 40PFL6606T/12 | x | x | 1.2 | |
| Philips 40PFL6626T/12 | x | x | 1.2 | |
| Philips 40PFL6636T/12 | x | x | 1.2 | |
| Philips 40PFL7007T/12 | x | x | 1.2 | |
| Philips 40PFL8007T/12 | x | x | 1.2 | |
| Philips 40PFL8008S/12 | x | x | 1.2 | |
| Philips 40PFL8606T/12 | x | x | 1.2 | |
| Philips 40PFL9606T/12 | x | x | 1.2 | |
| Philips 40PFS5709/12 | x | x | 1.2 | |
| Philips 40PFS6719/12 | x | x | 1.2 | |
| Philips 40PFS6909/12 | x | x | 1.2 | |
| Philips 40PFT4009/12 | x | x | 1.2 | |
| Philips 40PFT4100/12 | x | x | 1.3 | |
| Philips 40PFT4101 | x | x | 1.3 | |
| Philips 40PFT4101/12 | x | x | 1.3 | |
| Philips 40PFT4109/12 | x | x | 1.2 | |
| Philips 40PFT4200/12 | x | x | 1.3 | |
| Philips 40PFT4201/12 | x | x | 1.3 | |
| Philips 40PFT4309/12 | x | x | 1.2 | |
| Philips 40PFT4319/12 | x | x | 1.2 | |
| Philips 40PFT4509/12 | x | x | 1.2 | |
| Philips 40PFT5300/12 | x | x | 1.2 | |
| Philips 40PFT5500/12 | x | x | 1.3 | |
| Philips 40PFT5501/12 | x | x | 1.3 | |
| Philips 40PFT5509/12 | x | x | 1.2 | |
| Philips 40PFT6300/12 | x | x | 1.3 | |
| Philips 40PFT6510/12 | x | x | 1.3 | |
| Philips 40PFT6550/12 | x | x | 1.3 | |
| Philips 40PUS6809/12 | x | x | 1.2 | |
| Philips 40PUT6400/12 | x | x | 1.3 | |
| Philips 42PDL6907T/12 | x | x | 1.2 | |
| Philips 42PDL7906T/12 | x | x | 1.2 | |
| Philips 42PFL3007T/12 | x | x | 1.2 | |
| Philips 42PFL3108T/12 | x | x | 1.2 | |
| Philips 42PFL3507T/12 | x | x | 1.2 | |
| Philips 42PFL4007T/12 | x | x | 1.2 | |
| Philips 42PFL4208T/12 | x | x | 1.2 | |
| Philips 42PFL4307T/12 | x | x | 1.2 | |
| Philips 42PFL5008T/12 | x | x | 1.2 | |
| Philips 42PFL5038T/12 | x | x | 1.2 | |
| Philips 42PFL6007T/12 | x | x | 1.2 | |
| Philips 42PFL6008S/12 | x | x | 1.2 | |
| Philips 42PFL6057T/12 | x | x | 1.2 | |
| Philips 42PFL6067T/12 | x | x | 1.2 | |
| Philips 42PFL6097T/12 | x | x | 1.2 | |
| Philips 42PFL6158S/12 | x | x | 1.2 | |
| Philips 42PFL6188S/12 | x | x | 1.2 | |
| Philips 42PFL6678S/12 | x | x | 1.2 | |
| Philips 42PFL6877T/12 | x | x | 1.2 | |
| Philips 42PFL6907T/12 | x | x | 1.2 | |
| Philips 42PFL7008S/12 | x | x | 1.2 | |
| Philips 42PFL7406T/12 | x | x | 1.2 | |
| Philips 42PFL7456T/12 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 42PFL7466T/12 | x | x | 1.2 | |
| Philips 42PFL7486T/12 | x | x | 1.2 | |
| Philips 42PFL7496T/12 | x | x | 1.2 | |
| Philips 42PFL7606T/12 | x | x | 1.2 | |
| Philips 42PFL7656T/12 | x | x | 1.2 | |
| Philips 42PFL7666T/12 | x | x | 1.2 | |
| Philips 42PFL7676T/12 | x | x | 1.2 | |
| Philips 42PFL7696T/12 | x | x | 1.2 | |
| Philips 42PFS7109/12 | x | x | 1.2 | |
| Philips 42PFS7189/12 | x | x | 1.2 | |
| Philips 42PFS7199/12 | x | x | 1.2 | |
| Philips 42PFS7509/12 | x | x | 1.2 | |
| Philips 42PFT5609/12 | x | x | 1.2 | |
| Philips 42PFT6109/12 | x | x | 1.2 | |
| Philips 42PFT6309/12 | x | x | 1.2 | |
| Philips 42PUS7809/12 | x | x | 1.2 | |
| Philips 43PFS4112/12 | x | x | 1.3 | |
| Philips 43PFS4131/12 | x | x | 1.3 | |
| Philips 43PFS4132/12 | x | x | 1.3 | |
| Philips 43PFS5301/12 | x | x | 1.3 | |
| Philips 43PFS5302/12 | x | x | 1.3 | |
| Philips 43PFS5503/12 | x | x | 1.3 | |
| Philips 43PFS5503/12M | x | x | 1.3 | |
| Philips 43PFS5803/12 | x | x | 1.3 | |
| Philips 43PFS5823/12 | x | x | 1.3 | |
| Philips 43PFT4112/12 | x | x | 1.3 | |
| Philips 43PFT4131/12 | x | x | 1.3 | |
| Philips 43PFT4132/12 | x | x | 1.3 | |
| Philips 43PFT5301/12 | x | x | 1.3 | |
| Philips 43PFT5302/12 | x | x | 1.3 | |
| Philips 43PFT5503/12 | x | x | 1.3 | |
| Philips 43PFT5503/12M | x | x | 1.3 | |
| Philips 43PUS6031/12 | x | x | 1.3 | |
| Philips 43PUS6162/12 | x | x | 1.3 | |
| Philips 43PUS6201/12 | x | x | 1.3 | |
| Philips 43PUS6262/12 | x | x | 1.3 | |
| Philips 43PUS6412/12 | x | x | 1.3 | |
| Philips 43PUS6432/12 | x | x | 1.3 | |
| Philips 43PUS6452/12 | x | x | 1.3 | |
| Philips 43PUS6501/12 | x | x | 1.3 | |
| Philips 43PUS6503/12 | x | x | 1.3 | |
| Philips 43PUS6504/12 | x | x | 1.4 | |
| Philips 43PUS6523/12 | x | x | 1.3 | |
| Philips 43PUS6551/12 | x | x | 1.3 | |
| Philips 43PUS6554/12 | x | x | 1.4 | |
| Philips 43PUS6703/12 | x | x | 1.3 | |
| Philips 43PUS6704/12 | x | x | 1.4 | |
| Philips 43PUS6753/12 | x | x | 1.3 | |
| Philips 43PUS6754/12 | x | x | 1.4 | |
| Philips 43PUS6804/12 | x | x | 1.4 | |
| Philips 43PUS6814/12 | x | x | 1.4 | |
| Philips 43PUS7100/12 | x | x | 1.3 | |
| Philips 43PUS7202/12 | x | x | 1.3 | |
| Philips 43PUS7303/12 | x | x | 1.3 | |
| Philips 43PUS7304/12 | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 43PUS7334/12 | x | x | 1.4 | |
| Philips 43PUS7354/12 | x | x | 1.4 | |
| Philips 43PUS7363/12 | x | x | 1.3 | |
| Philips 43PUS7373/12 | x | x | 1.3 | |
| Philips 43PUS7383/12 | x | x | 1.3 | |
| Philips 43PUS7393/12 | x | x | 1.3 | |
| Philips 43PUS7394/12 | x | x | 1.4 | |
| PHILIPS 43PUT4900/12 | x | x | 1.2 | |
| Philips 43PUT6101/12 | x | x | 1.3 | |
| Philips 43PUT6162/12 | x | x | 1.3 | |
| Philips 43PUT6201/12 | x | x | 1.3 | |
| Philips 43PUT6262/12 | x | x | 1.3 | |
| Philips 43PUT6401/12 | x | x | 1.3 | |
| Philips 46PDL8908S/12 | x | x | 1.2 | |
| Philips 46PFL3108T/12 | x | x | 1.2 | |
| Philips 46PFL3208T/12 | x | x | 1.2 | |
| Philips 46PFL4208T/12 | x | x | 1.2 | |
| Philips 46PFL4508T/12 | x | x | 1.2 | |
| Philips 46PFL4528T/12 | x | x | 1.2 | |
| Philips 46PFL5007T/12 | x | x | 1.2 | |
| Philips 46PFL5027T/12 | x | x | 1.2 | |
| Philips 46PFL5037T/12 | x | x | 1.2 | |
| Philips 46PFL5507T/12 | x | x | 1.2 | |
| Philips 46PFL5527T/12 | x | x | 1.2 | |
| Philips 46PFL5537T/12 | x | x | 1.2 | |
| Philips 46PFL6606T/12 | x | x | 1.2 | |
| Philips 46PFL6626T/12 | x | x | 1.2 | |
| Philips 46PFL7007T/12 | x | x | 1.2 | |
| Philips 46PFL8007T/12 | x | x | 1.2 | |
| Philips 46PFL8008S/12 | x | x | 1.2 | |
| Philips 46PFL8606T/12 | x | x | 1.2 | |
| Philips 46PFL8686T/12 | x | x | 1.2 | |
| Philips 46PFL9606T/12 | x | x | 1.2 | |
| Philips 46PFL9706T/12 | x | x | 1.2 | |
| Philips 46PFL9707T/12 | x | x | 1.2 | |
| Philips 46PFS8009/12 | x | x | 1.3 | |
| Philips 47PDL6907T/12 | x | x | 1.2 | |
| Philips 47PFL3007T/12 | x | x | 1.2 | |
| Philips 47PFL4007T/12 | x | x | 1.2 | |
| Philips 47PFL4307T/12 | x | x | 1.2 | |
| Philips 47PFL5008T/12 | x | x | 1.2 | |
| Philips 47PFL5038T/12 | x | x | 1.2 | |
| Philips 47PFL6007T/12 | x | x | 1.2 | |
| Philips 47PFL6008S/12 | x | x | 1.2 | |
| Philips 47PFL6057T/12 | x | x | 1.2 | |
| Philips 47PFL6067T/12 | x | x | 1.2 | |
| Philips 47PFL6097T/12 | x | x | 1.2 | |
| Philips 47PFL6158S/12 | x | x | 1.2 | |
| Philips 47PFL6188S/12 | x | x | 1.2 | |
| Philips 47PFL6678S/12 | x | x | 1.2 | |
| Philips 47PFL6877T/12 | x | x | 1.2 | |
| Philips 47PFL6907T/12 | x | x | 1.2 | |
| Philips 47PFL7008S/12 | x | x | 1.2 | |
| Philips 47PFL7108S/12 | x | x | 1.2 | |
| Philips 47PFL7456T/12 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 47PFL7606T/12 | x | x | 1.2 | |
| Philips 47PFL7656T/12 | x | x | 1.2 | |
| Philips 47PFL7666T/12 | x | x | 1.2 | |
| Philips 47PFL7676T/12 | x | x | 1.2 | |
| Philips 47PFL7696T/12 | x | x | 1.2 | |
| Philips 47PFS7109/12 | x | x | 1.2 | |
| Philips 47PFS7189/12 | x | x | 1.2 | |
| Philips 47PFS7199/12 | x | x | 1.2 | |
| Philips 47PFS7509/12 | x | x | 1.2 | |
| Philips 47PFT4109/12 | x | x | 1.2 | |
| Philips 47PFT5209/12 | x | x | 1.2 | |
| Philips 47PFT5609/12 | x | x | 1.2 | |
| Philips 47PFT6109/12 | x | x | 1.2 | |
| Philips 47PFT6309/12 | x | x | 1.2 | |
| Philips 48PFS5709/12 | x | x | 1.2 | |
| Philips 48PFS6409/12 | x | x | 1.2 | |
| Philips 48PFS6609/12 | x | x | 1.2 | |
| Philips 48PFS6719/12 | x | x | 1.2 | |
| Philips 48PFS6909/12 | x | x | 1.2 | |
| Philips 48PFS8109/12 | x | x | 1.3 | |
| Philips 48PFS8159/12 | x | x | 1.3 | |
| Philips 48PFS8209/12 | x | x | 1.3 | |
| Philips 48PFT4100/12 | x | x | 1.3 | |
| Philips 48PFT4101/12 | x | x | 1.3 | |
| Philips 48PFT4309/12 | x | x | 1.2 | |
| Philips 48PFT4319/12 | x | x | 1.2 | |
| Philips 48PFT4509/12 | x | x | 1.2 | |
| Philips 48PFT5500/12 | x | x | 1.3 | |
| Philips 48PFT5509/12 | x | x | 1.2 | |
| Philips 48PFT6300/12 | x | x | 1.3 | |
| Philips 48PUS7600/12 | x | x | 1.3 | |
| Philips 49FFS4132/12 | x | x | 1.3 | |
| Philips 49PFS4131/12 | x | x | 1.3 | |
| Philips 49PFS5301/12 | x | x | 1.3 | |
| Philips 49PFS5302/12 | x | x | 1.3 | |
| Philips 49PFT4131/12 | x | x | 1.3 | |
| Philips 49PFT4132/12 | x | x | 1.3 | |
| Philips 49PFT5301/12 | x | x | 1.3 | |
| Philips 49PFT5501/12 | x | x | 1.3 | |
| Philips 49PUK7909/12 | x | x | 1.3 | |
| Philips 49PUS6031/12 | x | x | 1.3 | |
| Philips 49PUS6101/12 | x | x | 1.3 | |
| Philips 49PUS6162/12 | x | x | 1.3 | |
| Philips 49PUS6262/12 | x | x | 1.3 | |
| Philips 49PUS6412/12 | x | x | 1.3 | |
| Philips 49PUS6432/12 | x | x | 1.3 | |
| Philips 49PUS6452/12 | x | x | 1.3 | |
| Philips 49PUS6482/12 | x | x | 1.3 | |
| Philips 49PUS6501/12 | x | x | 1.3 | |
| Philips 49PUS6551/12 | x | x | 1.3 | |
| Philips 49PUS6561/12 | x | x | 1.3 | |
| Philips 49PUS6581/12 | x | x | 1.3 | |
| Philips 49PUS6803/12 | x | x | 1.3 | |
| Philips 49PUS7100/12 | x | x | 1.3 | |
| Philips 49PUS7101/12 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 49PUS7150/12 | x | x | 1.3 | |
| Philips 49PUS7170/12 | x | x | 1.3 | |
| Philips 49PUS7181/12 | x | x | 1.3 | |
| Philips 49PUS7272/12 | x | x | 1.3 | |
| Philips 49PUS7502/12 | x | x | 1.3 | |
| Philips 49PUS7503/12 | x | x | 1.3 | |
| Philips 49PUS7803/12 | x | x | 1.3 | |
| Philips 49PUS7809/12 | x | x | 1.2 | |
| Philips 49PUS7909/12 | x | x | 1.3 | |
| Philips 49PUS8303/12 | x | x | 1.3 | |
| Philips 49PUS8503/12 | x | x | 1.3 | |
| PHILIPS 49PUT4900/12 | x | x | 1.2 | |
| Philips 49PUT6101/12 | x | x | 1.3 | |
| Philips 49PUT6162/12 | x | x | 1.3 | |
| Philips 49PUT6262/12 | x | x | 1.3 | |
| Philips 49PUT6401/12 | x | x | 1.3 | |
| Philips 50PFL3008T/12 | x | x | 1.2 | |
| Philips 50PFL4208T/12 | x | x | 1.2 | |
| Philips 50PFL5008T/12 | x | x | 1.2 | |
| Philips 50PFL5038T/12 | x | x | 1.2 | |
| Philips 50PFL7956T/12 | x | x | 1.2 | |
| Philips 50PFS5503/12 | x | x | 1.3 | |
| Philips 50PFS5803/12 | x | x | 1.3 | |
| Philips 50PFS5823/12 | x | x | 1.3 | |
| Philips 50PFT4009/12 | x | x | 1.2 | |
| Philips 50PFT4109/12 | x | x | 1.2 | |
| Philips 50PFT4309/12 | x | x | 1.2 | |
| Philips 50PFT4319/12 | x | x | 1.2 | |
| Philips 50PFT5300/12 | x | x | 1.2 | |
| Philips 50PFT5503/12 | x | x | 1.3 | |
| Philips 50PFT6510/12 | x | x | 1.3 | |
| Philips 50PFT6550/12 | x | x | 1.3 | |
| Philips 50PUS6162/12 | x | x | 1.3 | |
| Philips 50PUS6262/12 | x | x | 1.3 | |
| Philips 50PUS6272/12 | x | x | 1.3 | |
| Philips 50PUS6412/12 | x | x | 1.3 | |
| Philips 50PUS6503/12 | x | x | 1.3 | |
| Philips 50PUS6504/12 | x | x | 1.4 | |
| Philips 50PUS6523/12 | x | x | 1.3 | |
| Philips 50PUS6554/12 | x | x | 1.4 | |
| Philips 50PUS6703/12 | x | x | 1.3 | |
| Philips 50PUS6704/12 | x | x | 1.4 | |
| Philips 50PUS6753/12 | x | x | 1.3 | |
| Philips 50PUS6754/12 | x | x | 1.4 | |
| Philips 50PUS6804/12 | x | x | 1.4 | |
| Philips 50PUS6809/12 | x | x | 1.2 | |
| Philips 50PUS6814/12 | x | x | 1.4 | |
| Philips 50PUS7303/12 | x | x | 1.3 | |
| Philips 50PUS7304/12 | x | x | 1.4 | |
| Philips 50PUS7334/12 | x | x | 1.4 | |
| Philips 50PUS7354/12 | x | x | 1.4 | |
| Philips 50PUS7363/12 | x | x | 1.3 | |
| Philips 50PUS7373/12 | x | x | 1.3 | |
| Philips 50PUS7383/12 | x | x | 1.3 | |
| Philips 50PUS7393/12 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 50PUS7394/12 | x | x | 1.4 | |
| Philips 50PUS7504/12 | x | x | 1.4 | |
| Philips 50PUS8204/12 | x | x | 1.4 | |
| Philips 50PUS8804/12 | x | x | 1.4 | |
| Philips 50PUT6162/12 | x | x | 1.3 | |
| Philips 50PUT6262/12 | x | x | 1.3 | |
| Philips 50PUT6400/12 | x | x | 1.3 | |
| Philips 52PFL9606T/12 | x | x | 1.2 | |
| Philips 55OLED754/12 | x | x | 1.4 | |
| Philips 55OLED803/12 | x | x | 1.3 | |
| Philips 55OLED804/12 | x | x | 1.4 | |
| Philips 55OLED854/12 | x | x | 1.4 | |
| Philips 55OLED903/12 | x | x | 1.3 | |
| Philips 55OLED934/12 | x | x | 1.4 | |
| Philips 55PDL8908S/12 | x | x | 1.2 | |
| Philips 55PFL4508T/12 | x | x | 1.2 | |
| Philips 55PFL4528T/12 | x | x | 1.2 | |
| Philips 55PFL5007T/12 | x | x | 1.2 | |
| Philips 55PFL5507T/12 | x | x | 1.2 | |
| Philips 55PFL5527T/12 | x | x | 1.2 | |
| Philips 55PFL5537T/12 | x | x | 1.2 | |
| Philips 55PFL6007T/12 | x | x | 1.2 | |
| Philips 55PFL6008S/12 | x | x | 1.2 | |
| Philips 55PFL6158S/12 | x | x | 1.2 | |
| Philips 55PFL6188S/12 | x | x | 1.2 | |
| Philips 55PFL6606T/12 | x | x | 1.2 | |
| Philips 55PFL6678S/12 | x | x | 1.2 | |
| Philips 55PFL7007T/12 | x | x | 1.2 | |
| Philips 55PFL7008S/12 | x | x | 1.2 | |
| Philips 55PFL7108S/12 | x | x | 1.2 | |
| Philips 55PFL7606T/12 | x | x | 1.2 | |
| Philips 55PFL7696T/12 | x | x | 1.2 | |
| Philips 55PFL8007T/12 | x | x | 1.2 | |
| Philips 55PFL8008S/12 | x | x | 1.2 | |
| Philips 55PFS5709/12 | x | x | 1.2 | |
| Philips 55PFS6409/12 | x | x | 1.2 | |
| Philips 55PFS6609/12 | x | x | 1.2 | |
| Philips 55PFS6909/12 | x | x | 1.2 | |
| Philips 55PFS7109/12 | x | x | 1.2 | |
| Philips 55PFS7189/12 | x | x | 1.2 | |
| Philips 55PFS7199/12 | x | x | 1.2 | |
| Philips 55PFS7509/12 | x | x | 1.2 | |
| Philips 55PFS8109/12 | x | x | 1.3 | |
| Philips 55PFS8159/12 | x | x | 1.3 | |
| Philips 55PFS8209/12 | x | x | 1.3 | |
| Philips 55PFT5109/12 | x | x | 1.2 | |
| Philips 55PFT5209/12 | x | x | 1.2 | |
| Philips 55PFT5500/12 | x | x | 1.3 | |
| Philips 55PFT5509/12 | x | x | 1.2 | |
| Philips 55PFT5609/12 | x | x | 1.2 | |
| Philips 55PFT6109/12 | x | x | 1.2 | |
| Philips 55PFT6300/12 | x | x | 1.3 | |
| Philips 55PFT6309/12 | x | x | 1.2 | |
| Philips 55PFT6510/12 | x | x | 1.3 | |
| Philips 55PFT6550/12 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 55POS9002/12 | x | x | 1.3 | |
| Philips 55POS901F/12 | x | x | 1.3 | |
| Philips 55PUK7909/12 | x | x | 1.3 | |
| Philips 55PUS6031/12 | x | x | 1.3 | |
| Philips 55PUS6101/12 | x | x | 1.3 | |
| Philips 55PUS6162/12 | x | x | 1.3 | |
| Philips 55PUS6201/12 | x | x | 1.3 | |
| Philips 55PUS6262/12 | x | x | 1.3 | |
| Philips 55PUS6272/12 | x | x | 1.3 | |
| Philips 55PUS6412/12 | x | x | 1.3 | |
| Philips 55PUS6432/12 | x | x | 1.3 | |
| Philips 55PUS6452/12 | x | x | 1.3 | |
| Philips 55PUS6482/12 | x | x | 1.3 | |
| Philips 55PUS6501/12 | x | x | 1.3 | |
| Philips 55PUS6503/12 | x | x | 1.3 | |
| Philips 55PUS6523/12 | x | x | 1.3 | |
| Philips 55PUS6551/12 | x | x | 1.3 | |
| Philips 55PUS6554/12 | x | x | 1.4 | |
| Philips 55PUS6561/12 | x | x | 1.3 | |
| Philips 55PUS6581/12 | x | x | 1.3 | |
| Philips 55PUS6703/12 | x | x | 1.3 | |
| Philips 55PUS6704/12 | x | x | 1.4 | |
| Philips 55PUS6753/12 | x | x | 1.3 | |
| Philips 55PUS6754/12 | x | x | 1.4 | |
| Philips 55PUS6803/12 | x | x | 1.3 | |
| Philips 55PUS6804/12 | x | x | 1.4 | |
| Philips 55PUS6814/12 | x | x | 1.4 | |
| Philips 55PUS7100/12 | x | x | 1.3 | |
| Philips 55PUS7101/12 | x | x | 1.3 | |
| Philips 55PUS7150/12 | x | x | 1.3 | |
| Philips 55PUS7170/12 | x | x | 1.3 | |
| Philips 55PUS7181/12 | x | x | 1.3 | |
| Philips 55PUS7272/12 | x | x | 1.3 | |
| Philips 55PUS7303/12 | x | x | 1.3 | |
| Philips 55PUS7304/12 | x | x | 1.4 | |
| Philips 55PUS7334/12 | x | x | 1.4 | |
| Philips 55PUS7354/12 | x | x | 1.4 | |
| Philips 55PUS7363/12 | x | x | 1.3 | |
| Philips 55PUS7373/12 | x | x | 1.3 | |
| Philips 55PUS7383/12 | x | x | 1.3 | |
| Philips 55PUS7393/12 | x | x | 1.3 | |
| Philips 55PUS7394/12 | x | x | 1.4 | |
| Philips 55PUS7502/12 | x | x | 1.3 | |
| Philips 55PUS7503/12 | x | x | 1.3 | |
| Philips 55PUS7504/12 | x | x | 1.4 | |
| Philips 55PUS7600/12 | x | x | 1.3 | |
| Philips 55PUS7803/12 | x | x | 1.3 | |
| Philips 55PUS7809/12 | x | x | 1.2 | |
| Philips 55PUS7909/12 | x | x | 1.3 | |
| Philips 55PUS8204/12 | x | x | 1.4 | |
| Philips 55PUS8303/12 | x | x | 1.3 | |
| Philips 55PUS8503/12 | x | x | 1.3 | |
| PHILIPS 55PUS8601/12 | x | x | 1.3 | |
| Philips 55PUS8602/12 | x | x | 1.3 | |
| Philips 55PUS8804/12 | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 55PUS8809/12 | x | x | 1.3 | |
| Philips 55PUS8909C/12 | x | x | 1.3 | |
| Philips 55PUS9104/12 | x | x | 1.3 | |
| Philips 55PUS9109/12 | x | x | 1.3 | |
| PHILIPS 55PUT4900/12 | x | x | 1.2 | |
| Philips 55PUT6101/12 | x | x | 1.3 | |
| Philips 55PUT6162/12 | x | x | 1.3 | |
| Philips 55PUT6201/12 | x | x | 1.3 | |
| Philips 55PUT6262/12 | x | x | 1.3 | |
| Philips 55PUT6400/12 | x | x | 1.3 | |
| Philips 55PUT6401/12 | x | x | 1.3 | |
| Philips 58PFL9956T/12 | x | x | 1.2 | |
| Philips 58PUS6504/12 | x | x | 1.4 | |
| Philips 58PUS6809/12 | x | x | 1.2 | |
| Philips 58PUS7304/12 | x | x | 1.4 | |
| Philips 60PFL6008S/12 | x | x | 1.2 | |
| Philips 60PFL8908S/12 | x | x | 1.2 | |
| Philips 60PFL9607T/12 | x | x | 1.2 | |
| Philips 65OLED754/12 | x | x | 1.4 | |
| Philips 65OLED803/12 | x | x | 1.3 | |
| Philips 65OLED804/12 | x | x | 1.4 | |
| Philips 65OLED854/12 | x | x | 1.4 | |
| Philips 65OLED873/12 | x | x | 1.3 | |
| Philips 65OLED903/12 | x | x | 1.3 | |
| Philips 65OLED904/12 | x | x | 1.4 | |
| Philips 65OLED973/12 | x | x | 1.3 | |
| Philips 65OLED984/12 | x | x | 1.4 | |
| Philips 65PFL9708S/12 | x | x | 1.2 | |
| Philips 65PFS5909/12 | x | x | 1.2 | |
| Philips 65PFS6659/12 | x | x | 1.2 | |
| Philips 65PFS7559/12 | x | x | 1.2 | |
| Philips 65PFT6520/12 | x | x | 1.3 | |
| Philips 65POS9602/12 | x | x | 1.3 | |
| Philips 65PUS6121/12 | x | x | 1.3 | |
| Philips 65PUS6162/12 | x | x | 1.3 | |
| Philips 65PUS6262/12 | x | x | 1.3 | |
| Philips 65PUS6412/12 | x | x | 1.3 | |
| Philips 65PUS6503/12 | x | x | 1.3 | |
| Philips 65PUS6504/12 | x | x | 1.4 | |
| Philips 65PUS6521/12 | x | x | 1.3 | |
| Philips 65PUS6523/12 | x | x | 1.3 | |
| Philips 65PUS6554/12 | x | x | 1.4 | |
| Philips 65PUS6703/12 | x | x | 1.3 | |
| Philips 65PUS6704/12 | x | x | 1.4 | |
| Philips 65PUS6753/12 | x | x | 1.3 | |
| Philips 65PUS6754/12 | x | x | 1.4 | |
| Philips 65PUS6804/12 | x | x | 1.4 | |
| Philips 65PUS6814/12 | x | x | 1.4 | |
| Philips 65PUS7101/12 | x | x | 1.3 | |
| Philips 65PUS7120/12 | x | x | 1.3 | |
| Philips 65PUS7303/12 | x | x | 1.3 | |
| Philips 65PUS7304/12 | x | x | 1.4 | |
| Philips 65PUS7354/12 | x | x | 1.4 | |
| Philips 65PUS7363/12 | x | x | 1.3 | |
| Philips 65PUS7502/12 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Philips 65PUS7600/12 | x | x | 1.3 | |
| Philips 65PUS7601/12 | x | x | 1.3 | |
| Philips 65PUS7803/12 | x | x | 1.3 | |
| Philips 65PUS8102/12 | x | x | 1.3 | |
| Philips 65PUS8204/12 | x | x | 1.4 | |
| Philips 65PUS8303/12 | x | x | 1.3 | |
| Philips 65PUS8503/12 | x | x | 1.3 | |
| PHILIPS 65PUS8601/12 | x | x | 1.3 | |
| Philips 65PUS8602/12 | x | x | 1.3 | |
| PHILIPS 65PUS8901/12 | x | x | 1.3 | |
| Philips 65PUS9104/12 | x | x | 1.3 | |
| Philips 65PUS9109/12 | x | x | 1.3 | |
| Philips 65PUS9809/12 | x | x | 1.3 | |
| Philips 65PUS9809/12 | x | x | 1.3 | |
| Philips 65PUT6121/12 | x | x | 1.3 | |
| Philips 65PUT6162/12 | x | x | 1.3 | |
| Philips 65PUT6262/12 | x | x | 1.3 | |
| Philips 70PUS6504/12 | x | x | 1.4 | |
| Philips 70PUS6704/12 | x | x | 1.4 | |
| Philips 70PUS7304/12 | x | x | 1.4 | |
| Philips 75PUS6754/12 | x | x | 1.4 | |
| Philips 75PUS7101/12 | x | x | 1.3 | |
| Philips 75PUS7354/12 | x | x | 1.4 | |
| Philips 75PUS7803/12 | x | x | 1.3 | |
| Philips 75PUS8303/12 | x | x | 1.3 | |
| Pioneer L40S3D13N | x | x | 1.2 | |
| Pioneer L46S3D13N | x | x | 1.2 | |
| Pioneer L55S3D13N | x | x | 1.2 | |
| Power LED32YCT | x | x | 1.2 | |
| Power LED40YCT | x | x | 1.2 | |
| PROCASTER LE-24F420H | x | x | 1.3 | |
| PROCASTER LE-24F420WH | x | x | 1.3 | |
| PROCASTER LE-24F430H | x | x | 1.3 | |
| PROCASTER LE-24F430WH | x | x | 1.3 | |
| PROCASTER LE-24F435H | x | x | 1.3 | |
| PROCASTER LE-24F435WH | x | x | 1.3 | |
| PROCASTER LE-32A405 | x | x | 1.2 | |
| Procaster LE-32F408 | x | x | 1.2 | |
| PROCASTER LE-32F409H | x | x | 1.2 | |
| PROCASTER LE-32F410H | x | x | 1.3 | |
| Prosonic 19LED5006D | x | x | 1.2 | |
| Prosonic 19LED5006W22LED5006D | x | x | 1.2 | |
| Prosonic 22LED5006 | x | x | 1.2 | |
| Prosonic 22LED5006DW | x | x | 1.2 | |
| Prosonic 22LED5006W | x | x | 1.2 | |
| Prosonic 22LED5008 | x | x | 1.2 | |
| Prosonic 22LED5008D | x | x | 1.2 | |
| Prosonic 22LED5008DW | x | x | 1.2 | |
| Prosonic 22LED5008W | x | x | 1.2 | |
| Prosonic 24LED500632LED5003W | x | x | 1.2 | |
| Prosonic 24LED5006D | x | x | 1.2 | |
| Prosonic 24LED5006DW | x | x | 1.2 | |
| Prosonic 24LED5006W | x | x | 1.2 | |
| PROSONIC 24LED5008 | x | x | 1.3 | |
| Prosonic 24LED500812V | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| PROSONIC 24LED5008D | x | x | 1.3 | |
| Prosonic 24LED5008D12V | x | x | 1.2 | |
| PROSONIC 24LED5008DW | x | x | 1.3 | |
| PROSONIC 24LED5008W | x | x | 1.3 | |
| Prosonic 24LED5008W12V | x | x | 1.2 | |
| Prosonic 32LED500532LED5003 | x | x | 1.2 | |
| Prosonic 32LED5005DW | x | x | 1.2 | |
| Prosonic 32LED5008 | x | x | 1.2 | |
| PROSONIC 32LED5008D | x | x | 1.3 | |
| PROSONIC 32LED5008SW | x | x | 1.3 | |
| PROSONIC 32LED5008SWH | x | x | 1.3 | |
| Prosonic 32LED600 HD | x | x | 1.2 | |
| Prosonic 32LED800 FHD | x | x | 1.2 | |
| Prosonic 32LED800 FHD W | x | x | 1.2 | |
| Prosonic 40LED5008SW | x | x | 1.2 | |
| Prosonic 40LED6003 | x | x | 1.2 | |
| Prosonic 40LED6005 | x | x | 1.2 | |
| Prosonic 40LED60054 | x | x | 1.2 | |
| Prosonic 40LED6005W | x | x | 1.2 | |
| PROSONIC 40LED6009 | x | x | 1.3 | |
| PROSONIC 40LED6009SW | x | x | 1.3 | |
| Prosonic 40LED800 FHD | x | x | 1.2 | |
| PROSONIC 43LED6008 | x | x | 1.3 | |
| Prosonic 43UHD7008 | x | x | 1.2 | |
| PROSONIC 43UHD7008-1 | x | x | 1.3 | |
| PROSONIC 49LED6008 | x | x | 1.3 | |
| Prosonic 49UHD7008 | x | x | 1.2 | |
| PROSONIC 49UHD7008-1 | x | x | 1.3 | |
| PROSONIC 55LED6008 | x | x | 1.3 | |
| Prosonic 55UHD7008 | x | x | 1.2 | |
| PROSONIC 55UHD7008-1 | x | x | 1.3 | |
| PROSONIC 65UHD7008 | x | x | 1.3 | |
| PROSONIC 65UHD8008 | x | x | 1.3 | |
| PROSONIC 65UHDDLEDUNB | x | x | 1.3 | |
| PROSONIC 75UHDDLEDUNB | x | x | 1.3 | |
| Prosonic Prosonic 32LED600 HD | x | x | 1.2 | |
| Prosonic Prosonic 32LED800 FHD | x | x | 1.2 | |
| Prosonic Prosonic 32LED800 FHD W | x | x | 1.2 | |
| Prosonic Prosonic 40LED800 FHD | x | x | 1.2 | |
| Prosonic PS32HD121 | x | x | 1.2 | x |
| Sagemcom DT90 | x | x | | x |
| Sagemcom DTiW77 | x | x | | |
| Sagemcom RT90-160 HD | x | x | | x |
| Sagemcom RT90-320HD | x | x | | x |
| Sagemcom RT90-500HD | x | x | | x |
| Sagemcom RTI90-160 | x | x | | x |
| Sagemcom RTI90-320 | x | x | | x |
| Sagemcom RTI90-500 | x | x | | x |
| SALORA 20LEDDVD | x | x | 1.2 | |
| Salora 20LEDDVDW | x | x | 1.2 | |
| Salora 22LEDDVD | x | x | 1.2 | |
| Salora 24LED | x | x | 1.2 | |
| Salora 24LEDDVD | x | x | 1.2 | |
| Salora 24LEDDVDW | x | x | 1.2 | |
| Salora 24LEDW | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| SALORA 32LED-K(580012) | x | x | 1.3 | |
| SALORA 39LED-K(580011) | x | x | 1.3 | |
| SALORA LED24DVDT | x | x | 1.2 | |
| SALORA LED24NCB-T | x | x | 1.2 | |
| SALORA LED29DVDT | x | x | 1.2 | |
| SALORA LED32ST | x | x | 1.2 | |
| SALORA LED32UAT | x | x | 1.2 | |
| SALORA LED39ST | x | x | 1.2 | |
| SALORA LED39UAT | x | x | 1.2 | |
| SALORA LED50UAT | x | x | 1.2 | |
| SALORA SMART32LED | x | x | 1.3 | |
| SALORA SMART32LEDW | x | x | 1.3 | |
| Salora SMART40LED | x | x | 1.2 | |
| Salora SMART40LEDW | x | x | 1.2 | |
| SALORA SMART43LE | x | x | 1.3 | |
| SALORA SMART43LED(580003) | x | x | 1.3 | |
| SALORA SMART43LEDW | x | x | 1.3 | |
| SALORA SMART43LED-Wifi-K (580017) | x | x | 1.3 | |
| SALORA SMART43LED-Wifi-KW (580015) | x | x | 1.3 | |
| SALORA SMART43LEDW-WIFI-K (580016) | x | x | 1.3 | |
| SALORA SMART48LED | x | x | 1.2 | |
| SALORA SMART49LED | x | x | 1.3 | |
| Salora SMART49LEDW | x | x | 1.2 | |
| SALORA SMART50LED-Wifi(580002) | x | x | 1.2 | |
| Salora SMART55LED | x | x | 1.2 | |
| SALORA SMART55LED4K-Wifi | x | x | 1.3 | |
| Salora SMART55LEDS | x | x | 1.2 | |
| Salora SMART65LED | x | x | 1.2 | |
| SALORA SMART65LED4K-W | x | x | 1.3 | |
| SALORA SMART65LED4K-Wifi-K | x | x | 1.3 | |
| SALORA SMART65LED4K-Wifi-K (580013) | x | x | 1.3 | |
| Samsung BD-D6900N/XE | x | x | 1.2 | |
| Samsung BD-D8200N/XE | x | x | 1.2 | |
| Samsung BD-D8500N/XE | x | x | 1.2 | |
| Samsung BD-D8900N/XE | x | x | 1.2 | |
| Samsung BD-E8300N | x | x | 1.2 | |
| Samsung BD-E8500N | x | x | 1.2 | |
| Samsung BD-E8900N | x | x | 1.2 | |
| Samsung BD-F8500N | x | x | | |
| Samsung BD-F8900N | x | x | | |
| Samsung BD-H8500N | x | x | 1.2 | |
| Samsung BD-H8900N | x | x | 1.2 | |
| Samsung LT24B750EX/EN | x | x | 1.2 | |
| Samsung LT27B750EX/EN | x | x | 1.2 | |
| Samsung PS43E495B1KXXE | x | x | 1.2 | |
| Samsung PS43F4905AKXXE | x | x | 1.2 | |
| Samsung PS51D7005DKXXE | x | x | 1.2 | |
| Samsung PS51D8005FUXXE | x | x | 1.2 | |
| Samsung PS51E495B1KXXE | x | x | 1.2 | |
| Samsung PS51E555D1KXXE | x | x | 1.2 | |
| Samsung PS51E6505EUXXE | x | x | 1.2 | |
| Samsung PS51F4905AKXXE | x | x | 1.2 | |
| Samsung PS51F5005AKXXE | x | x | 1.2 | |
| Samsung PS51F5505AKXXE | x | x | 1.2 | |
| Samsung PS51F8505STXXE | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung PS59D7005DKXXE | x | x | 1.2 | |
| Samsung PS60E555D1KXXE | x | x | 1.2 | |
| Samsung PS60E6505EUXXE | x | x | 1.2 | |
| Samsung PS60F5005AKXXE | x | x | 1.2 | |
| Samsung PS60F5505AKXXE | x | x | 1.2 | |
| Samsung PS64D8005FUXXE | x | x | 1.2 | |
| Samsung PS64F5005AKXXE | x | x | 1.2 | |
| Samsung PS64F8505STXXE | x | x | 1.2 | |
| Samsung QE49Q6FNATXXC | x | x | 1.4 | |
| Samsung QE49Q7CAMTXXC | x | x | 1.3 | |
| Samsung QE49Q7FAMTXXC | x | x | 1.3 | |
| Samsung QE55Q6FAMTXXC | x | x | 1.3 | |
| Samsung QE55Q6FNATXXC | x | x | 1.4 | |
| Samsung QE55Q7CAMTXXC | x | x | 1.3 | |
| Samsung QE55Q7FAMTXXC | x | x | 1.3 | |
| Samsung QE55Q7FNATXXC | x | x | 1.4 | |
| Samsung QE55Q8CAMTXXC | x | x | 1.3 | |
| Samsung QE55Q8CNATXXC | x | x | 1.4 | |
| Samsung QE55Q8DNATXXC | x | x | 1.4 | |
| Samsung QE55Q8FAMTXXC | x | x | 1.3 | |
| Samsung QE55Q8FNATXXC | x | x | 1.4 | |
| Samsung QE55Q9FNATXXC | x | x | 1.4 | |
| Samsung QE65Q6FAMTXXC | x | x | 1.3 | |
| Samsung QE65Q6FNATXXC | x | x | 1.4 | |
| Samsung QE65Q7CAMTXXC | x | x | 1.3 | |
| Samsung QE65Q7FAMTXXC | x | x | 1.3 | |
| Samsung QE65Q7FNATXXC | x | x | 1.4 | |
| Samsung QE65Q8CAMTXXC | x | x | 1.3 | |
| Samsung QE65Q8CNATXXC | x | x | 1.4 | |
| Samsung QE65Q8DNATXXC | x | x | 1.4 | |
| Samsung QE65Q8FAMTXXC | x | x | 1.3 | |
| Samsung QE65Q8FNATXXC | x | x | 1.4 | |
| Samsung QE65Q900RATXXC | x | x | 1.4 | |
| Samsung QE65Q9FAMTXXC | x | x | 1.3 | |
| Samsung QE65Q9FNATXXC | x | x | 1.4 | |
| Samsung QE75Q6FNATXXC | x | x | 1.4 | |
| Samsung QE75Q7FAMTXXC | x | x | 1.3 | |
| Samsung QE75Q7FNATXXC | x | x | 1.4 | |
| Samsung QE75Q8CAMTXXC | x | x | 1.3 | |
| Samsung QE75Q8DNATXXC | x | x | 1.4 | |
| Samsung QE75Q900RATXXC | x | x | 1.4 | |
| Samsung QE75Q9FNATXXC | x | x | 1.4 | |
| Samsung QE85Q900RATXXC | x | x | 1.4 | |
| Samsung QE88Q9FAMTXXC | x | x | 1.3 | |
| Samsung T-ECPDEUC | x | x | 1.2 | |
| Samsung T-GAx6DEUC | x | x | 1.2 | x |
| Samsung T-NVTE5DEUC | x | x | 1.2 | x |
| Samsung UE22F5005AKXXE | x | x | 1.2 | |
| Samsung UE22F5405AKXXE | x | x | 1.2 | |
| Samsung UE22F5415AKXXE | x | x | 1.2 | |
| Samsung UE22H5005AKXXE | x | x | 1.2 | |
| Samsung UE22H5605AKXXE | x | x | 1.2 | |
| Samsung UE22H5615AKXXE | x | x | 1.2 | |
| Samsung UE22K5005AKXXE | x | x | 1.3 | |
| Samsung UE32D6207TKXXE | x | x | 1.2 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE32D6307SKXXE | x | x | 1.2 | x |
| Samsung UE32D6327SKXXE | x | x | 1.2 | x |
| Samsung UE32D6507VKXXE | x | x | 1.2 | x |
| Samsung UE32D6517WKXXE | x | x | 1.2 | x |
| Samsung UE32D6537WKXXE | x | x | 1.2 | |
| Samsung UE32D6547UKXXE | x | x | 1.2 | x |
| Samsung UE32D6547VKXXE | x | x | 1.2 | x |
| Samsung UE32D6577WKXXE | x | x | 1.2 | x |
| Samsung UE32D6757WKXXE | x | x | 1.2 | x |
| Samsung UE32EH4004WXXE | x | x | 1.2 | x |
| Samsung UE32EH5005KXXE | x | x | 1.2 | |
| Samsung UE32EH5305KXXE | x | x | 1.2 | |
| Samsung UE32EH6035KXXE | x | x | 1.2 | x |
| Samsung UE32ES5505KXXE | x | x | 1.2 | |
| Samsung UE32ES6305UXXE | x | x | 1.2 | |
| Samsung UE32ES6535UXXE | x | x | 1.2 | |
| Samsung UE32ES6545UXXE | x | x | 1.2 | |
| Samsung UE32ES6565UXXE | x | x | 1.2 | |
| Samsung UE32ES6575UXXE | x | x | 1.2 | |
| Samsung UE32ES6715UXXE | x | x | 1.2 | |
| Samsung UE32ES6805UXXE | x | x | 1.2 | |
| Samsung UE32F4505AKXXE | x | x | 1.2 | |
| Samsung UE32F4515AKXXE | x | x | 1.2 | |
| Samsung UE32F5005AKXXE | x | x | 1.2 | |
| Samsung UE32F5305AKXXE | x | x | 1.2 | |
| Samsung UE32F5505AKXXE | x | x | 1.2 | |
| Samsung UE32F6105AKXXE | x | x | 1.2 | |
| Samsung UE32F6275SBXXE | x | x | 1.2 | |
| Samsung UE32F6475SBXXE | x | x | 1.2 | |
| Samsung UE32F6515SBXXE | x | x | 1.2 | |
| Samsung UE32F6805SBXXE | x | x | 1.2 | |
| Samsung UE32H4505AKXXE | x | x | 1.2 | |
| Samsung UE32H4515AKXXE | x | x | 1.2 | |
| Samsung UE32H5005AKXXE | x | x | 1.2 | |
| Samsung UE32H5304AKXXE | x | x | 1.2 | |
| Samsung UE32H5505AKXXE | x | x | 1.2 | |
| Samsung UE32H6275SUXXE | x | x | 1.2 | |
| Samsung UE32H6415SUXXE | x | x | 1.2 | |
| Samsung UE32H6475SUXXE | x | x | 1.2 | |
| Samsung UE32J4004AKXXE | x | x | 1.2 | |
| Samsung UE32J5004AKXXE | x | x | 1.2 | |
| Samsung UE32J5204AKXXE | x | x | 1.2 | |
| Samsung UE32J5505AKXXE | x | x | 1.3 | |
| Samsung UE32J6275SUXXE | x | x | 1.3 | |
| Samsung UE32J6375SUXXE | x | x | 1.3 | |
| Samsung UE32K4105AKXXE | x | x | 1.3 | |
| Samsung UE32K5105AKXXE | x | x | 1.3 | |
| Samsung UE32K5505AKXXE | x | x | 1.3 | |
| Samsung UE32K5605AKXXE | x | x | 1.3 | |
| Samsung UE32M4005AKXXC | x | x | 1.3 | |
| Samsung UE32M5005AKXXC | x | x | 1.3 | |
| Samsung UE32M5505AKXXC | x | x | 1.3 | |
| Samsung UE32M5605AKXXC | x | x | 1.3 | |
| Samsung UE37D6507VKXXE | x | x | 1.2 | x |
| Samsung UE37D6517WKXXE | x | x | 1.2 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE37D6537WKXXE | x | x | 1.2 | |
| Samsung UE37D6547UKXXE | x | x | 1.2 | x |
| Samsung UE37D6577WKXXE | x | x | 1.2 | x |
| Samsung UE37D6757WKXXE | x | x | 1.2 | x |
| Samsung UE37ES5505KXXE | x | x | 1.2 | |
| Samsung UE37ES6305UXXE | x | x | 1.2 | |
| Samsung UE37ES6715UXXE | x | x | 1.2 | |
| Samsung UE39EH5004WXXE | x | x | 1.2 | x |
| Samsung UE40D6207TKXXE | x | x | 1.2 | x |
| Samsung UE40D6307SKXXE | x | x | 1.2 | x |
| Samsung UE40D6327SKXXE | x | x | 1.2 | x |
| Samsung UE40D6507VKXXE | x | x | 1.2 | x |
| Samsung UE40D6517WKXXE | x | x | 1.2 | x |
| Samsung UE40D6537WKXXE | x | x | 1.2 | |
| Samsung UE40D6547UKXXE | x | x | 1.2 | x |
| Samsung UE40D6547VKXXE | x | x | 1.2 | x |
| Samsung UE40D6577WKXXE | x | x | 1.2 | x |
| Samsung UE40D6757WKXXE | x | x | 1.2 | x |
| Samsung UE40D7005LUXXE | x | x | 1.2 | x |
| Samsung UE40D8005YUXXE | x | x | 1.2 | |
| Samsung UE40EH5005KXXE | x | x | 1.2 | |
| Samsung UE40EH5305KXXE | x | x | 1.2 | |
| Samsung UE40EH6035KXXE | x | x | 1.2 | x |
| Samsung UE40ES5505KXXE | x | x | 1.2 | |
| Samsung UE40ES6305UXXE | x | x | 1.2 | |
| Samsung UE40ES6535UXXE | x | x | 1.2 | |
| Samsung UE40ES6545UXXE | x | x | 1.2 | |
| Samsung UE40ES6565UXXE | x | x | 1.2 | |
| Samsung UE40ES6575UXXE | x | x | 1.2 | |
| Samsung UE40ES6715UXXE | x | x | 1.2 | |
| Samsung UE40ES6805UXXE | x | x | 1.2 | |
| Samsung UE40ES6905UXXE | x | x | 1.2 | |
| Samsung UE40ES7005UXXE | x | x | 1.2 | |
| Samsung UE40ES8005UXXE | x | x | 1.2 | |
| Samsung UE40F6105AKXXE | x | x | 1.2 | |
| Samsung UE40F6275SBXXE | x | x | 1.2 | |
| Samsung UE40F6475SBXXE | x | x | 1.2 | |
| Samsung UE40F6505SBXXE | x | x | 1.2 | |
| Samsung UE40F6515SBXXE | x | x | 1.2 | |
| Samsung UE40F6645SBXXE | x | x | 1.2 | |
| Samsung UE40F6655SBXXE | x | x | 1.2 | |
| Samsung UE40F6675SBXXE | x | x | 1.2 | |
| Samsung UE40F6745SBXXE | x | x | 1.2 | |
| Samsung UE40F6805SBXXE | x | x | 1.2 | |
| Samsung UE40F7005STXXE | x | x | 1.2 | |
| Samsung UE40F8005STXXE | x | x | 1.2 | |
| Samsung UE40H5005AKXXE | x | x | 1.2 | |
| Samsung UE40H5035AKXXE | x | x | 1.2 | |
| Samsung UE40H5304AKXXE | x | x | 1.2 | |
| Samsung UE40H5505AKXXE | x | x | 1.2 | |
| Samsung UE40H6204AKXXE | x | x | 1.2 | |
| Samsung UE40H6275SUXXE | x | x | 1.2 | |
| Samsung UE40H6415SUXXE | x | x | 1.2 | |
| Samsung UE40H6475SUXXE | x | x | 1.2 | |
| Samsung UE40H6505STXXE | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE40H6645STXXE | x | x | 1.2 | |
| Samsung UE40H6655STXXE | x | x | 1.2 | |
| Samsung UE40H6675STXXE | x | x | 1.2 | |
| Samsung UE40H7005SQXXE | x | x | 1.2 | |
| Samsung UE40HU6905UXXE | x | x | 1.2 | |
| Samsung UE40J5515AKXXE | x | x | 1.3 | |
| Samsung UE40J5605AKXXE | x | x | 1.3 | |
| Samsung UE40J6275SUXXE | x | x | 1.3 | |
| Samsung UE40J6285SUXXE | x | x | 1.3 | |
| Samsung UE40J6375SUXXE | x | x | 1.3 | |
| Samsung UE40JU6075UXXE | x | x | 1.2 | |
| Samsung UE40JU6415UXXE | x | x | 1.3 | |
| Samsung UE40JU6465UXXE | x | x | 1.3 | |
| Samsung UE40JU6475UXXE | x | x | 1.3 | |
| Samsung UE40JU6515UXXE | x | x | 1.3 | |
| Samsung UE40JU6575UXXE | x | x | 1.3 | |
| Samsung UE40JU6655UXXE | x | x | 1.3 | |
| Samsung UE40JU6675UXXE | x | x | 1.3 | |
| Samsung UE40JU6745UXXE | x | x | 1.3 | |
| Samsung UE40JU7005TXXE | x | x | 1.3 | |
| Samsung UE40K5105AKXXE | x | x | 1.3 | |
| Samsung UE40K5505AKXXE | x | x | 1.3 | |
| Samsung UE40K5515AKXXE | x | x | 1.3 | |
| Samsung UE40K5605AKXXE | x | x | 1.3 | |
| Samsung UE40K6375SUXXE | x | x | 1.3 | |
| Samsung UE40KU6075UXXE | x | x | 1.3 | |
| Samsung UE40KU6095UXXE | x | x | 1.3 | |
| Samsung UE40KU6175UXXE | x | x | 1.3 | |
| Samsung UE40KU6405UXXE | x | x | 1.3 | |
| Samsung UE40KU6455UXXE | x | x | 1.3 | |
| Samsung UE40KU6475UXXE | x | x | 1.3 | |
| Samsung UE40M5005AKXXC | x | x | 1.3 | |
| Samsung UE40MU6105KXXC | x | x | 1.3 | |
| Samsung UE40MU6125KXXC | x | x | 1.3 | |
| Samsung UE40MU6175UXXC | x | x | 1.3 | |
| Samsung UE40MU6195UXXC | x | x | 1.3 | |
| Samsung UE40MU6405UXXC | x | x | 1.3 | |
| Samsung UE40MU6445UXXC | x | x | 1.3 | |
| Samsung UE40MU6455UXXC | x | x | 1.3 | |
| Samsung UE40MU6475UXXC | x | x | 1.3 | |
| Samsung UE40NU7125KXXC | x | x | 1.4 | |
| Samsung UE42F5005AKXXE | x | x | 1.2 | |
| Samsung UE42F5305AKXXE | x | x | 1.2 | |
| Samsung UE42F5505AKXXE | x | x | 1.2 | |
| Samsung UE43J5505AKXXE | x | x | 1.3 | |
| Samsung UE43J5605AKXXE | x | x | 1.3 | |
| Samsung UE43JU6075UXXE | x | x | 1.2 | |
| Samsung UE43KS7505UXXE | x | x | 1.3 | |
| Samsung UE43KU6075UXXE | x | x | 1.3 | |
| Samsung UE43KU6405UXXE | x | x | 1.3 | |
| Samsung UE43KU6505UXXE | x | x | 1.3 | |
| Samsung UE43KU6515UXXE | x | x | 1.3 | |
| Samsung UE43KU6645UXXE | x | x | 1.3 | |
| Samsung UE43KU6655UXXE | x | x | 1.3 | |
| Samsung UE43KU6675UXXE | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE43LS003AUXXC | x | x | 1.3 | |
| Samsung UE43LS03NAUXXC | x | x | 1.4 | |
| Samsung UE43M5505AKXXC | x | x | 1.3 | |
| Samsung UE43M5515AKXXC | x | x | 1.3 | |
| Samsung UE43M5605AKXXC | x | x | 1.3 | |
| Samsung UE43MU6105KXXC | x | x | 1.3 | |
| Samsung UE43MU6175UXXC | x | x | 1.3 | |
| Samsung UE43MU6195UXXC | x | x | 1.3 | |
| Samsung UE43NU6025KXXC | x | x | 1.4 | |
| Samsung UE43NU7125KXXC | x | x | 1.4 | |
| Samsung UE43NU7405UXXC | x | x | 1.4 | |
| Samsung UE43NU7445UXXC | x | x | 1.4 | |
| Samsung UE43NU7455UXXC | x | x | 1.4 | |
| Samsung UE43NU7475UXXC | x | x | 1.4 | |
| Samsung UE46D6207TKXXE | x | x | 1.2 | x |
| Samsung UE46D6307SKXXE | x | x | 1.2 | x |
| Samsung UE46D6327SKXXE | x | x | 1.2 | x |
| Samsung UE46D6507VKXXE | x | x | 1.2 | x |
| Samsung UE46D6517WKXXE | x | x | 1.2 | x |
| Samsung UE46D6537WKXXE | x | x | 1.2 | |
| Samsung UE46D6547UKXXE | x | x | 1.2 | x |
| Samsung UE46D6547VKXXE | x | x | 1.2 | x |
| Samsung UE46D6577WKXXE | x | x | 1.2 | x |
| Samsung UE46D6757WKXXE | x | x | 1.2 | x |
| Samsung UE46D7005LUXXE | x | x | 1.2 | x |
| Samsung UE46D8005YUXXE | x | x | 1.2 | |
| Samsung UE46EH5005KXXE | x | x | 1.2 | |
| Samsung UE46EH5305KXXE | x | x | 1.2 | |
| Samsung UE46EH6035KXXE | x | x | 1.2 | x |
| Samsung UE46ES5505KXXE | x | x | 1.2 | |
| Samsung UE46ES6305UXXE | x | x | 1.2 | |
| Samsung UE46ES6535UXXE | x | x | 1.2 | |
| Samsung UE46ES6545UXXE | x | x | 1.2 | |
| Samsung UE46ES6565UXXE | x | x | 1.2 | |
| Samsung UE46ES6575UXXE | x | x | 1.2 | |
| Samsung UE46ES6715UXXE | x | x | 1.2 | |
| Samsung UE46ES6805UXXE | x | x | 1.2 | |
| Samsung UE46ES6905UXXE | x | x | 1.2 | |
| Samsung UE46ES7005UXXE | x | x | 1.2 | |
| Samsung UE46ES8005UXXE | x | x | 1.2 | |
| Samsung UE46F5005AKXXE | x | x | 1.2 | |
| Samsung UE46F5305AKXXE | x | x | 1.2 | |
| Samsung UE46F5505AKXXE | x | x | 1.2 | |
| Samsung UE46F6105AKXXE | x | x | 1.2 | |
| Samsung UE46F6275SBXXE | x | x | 1.2 | |
| Samsung UE46F6475SBXXE | x | x | 1.2 | |
| Samsung UE46F6505SBXXE | x | x | 1.2 | |
| Samsung UE46F6515SBXXE | x | x | 1.2 | |
| Samsung UE46F6645SBXXE | x | x | 1.2 | |
| Samsung UE46F6655SBXXE | x | x | 1.2 | |
| Samsung UE46F6675SBXXE | x | x | 1.2 | |
| Samsung UE46F6745SBXXE | x | x | 1.2 | |
| Samsung UE46F6805SBXXE | x | x | 1.2 | |
| Samsung UE46F7005STXXE | x | x | 1.2 | |
| Samsung UE46F8005STXXE | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE46F8505STXXE | x | x | 1.2 | |
| Samsung UE46H5304AKXXE | x | x | 1.2 | |
| Samsung UE46H6204AKXXE | x | x | 1.2 | |
| Samsung UE46H7005SQXXE | x | x | 1.2 | |
| Samsung UE48H5005AKXXE | x | x | 1.2 | |
| Samsung UE48H5035AKXXE | x | x | 1.2 | |
| Samsung UE48H5505AKXXE | x | x | 1.2 | |
| Samsung UE48H6275SUXXE | x | x | 1.2 | |
| Samsung UE48H6415SUXXE | x | x | 1.2 | |
| Samsung UE48H6475SUXXE | x | x | 1.2 | |
| Samsung UE48H6505STXXE | x | x | 1.2 | |
| Samsung UE48H6645STXXE | x | x | 1.2 | |
| Samsung UE48H6655STXXE | x | x | 1.2 | |
| Samsung UE48H6675STXXE | x | x | 1.2 | |
| Samsung UE48H6705STXXE | x | x | 1.2 | |
| Samsung UE48H8005SQXXE | x | x | 1.2 | |
| Samsung UE48HU7505TXXE | x | x | 1.2 | |
| Samsung UE48J5505AKXXE | x | x | 1.3 | |
| Samsung UE48J5515AKXXE | x | x | 1.3 | |
| Samsung UE48J5605AKXXE | x | x | 1.3 | |
| Samsung UE48J6275SUXXE | x | x | 1.3 | |
| Samsung UE48J6375SUXXE | x | x | 1.3 | |
| Samsung UE48JS8505TXXE | x | x | 1.3 | |
| Samsung UE48JS9005QXXE | x | x | 1.3 | |
| Samsung UE48JU6415UXXE | x | x | 1.3 | |
| Samsung UE48JU6465UXXE | x | x | 1.3 | |
| Samsung UE48JU6475UXXE | x | x | 1.3 | |
| Samsung UE48JU6515UXXE | x | x | 1.3 | |
| Samsung UE48JU6575UXXE | x | x | 1.3 | |
| Samsung UE48JU6655UXXE | x | x | 1.3 | |
| Samsung UE48JU6675UXXE | x | x | 1.3 | |
| Samsung UE48JU6745UXXE | x | x | 1.3 | |
| Samsung UE48JU7005TXXE | x | x | 1.3 | |
| Samsung UE48JU7505TXXE | x | x | 1.3 | |
| Samsung UE49K5105AKXXE | x | x | 1.3 | |
| Samsung UE49K5505AKXXE | x | x | 1.3 | |
| Samsung UE49K5515AKXXE | x | x | 1.3 | |
| Samsung UE49K5605AKXXE | x | x | 1.3 | |
| Samsung UE49K6375SUXXE | x | x | 1.3 | |
| Samsung UE49KS7005UXXE | x | x | 1.3 | |
| Samsung UE49KS7505UXXE | x | x | 1.3 | |
| Samsung UE49KS8005TXXE | x | x | 1.3 | |
| Samsung UE49KS9005TXXE | x | x | 1.3 | |
| Samsung UE49KU6175UXXE | x | x | 1.3 | |
| Samsung UE49KU6405UXXE | x | x | 1.3 | |
| Samsung UE49KU6455UXXE | x | x | 1.3 | |
| Samsung UE49KU6475UXXE | x | x | 1.3 | |
| Samsung UE49KU6505UXXE | x | x | 1.3 | |
| Samsung UE49KU6515UXXE | x | x | 1.3 | |
| Samsung UE49KU6645UXXE | x | x | 1.3 | |
| Samsung UE49KU6655UXXE | x | x | 1.3 | |
| Samsung UE49KU6675UXXE | x | x | 1.3 | |
| Samsung UE49LS03NAUXXC | x | x | 1.4 | |
| Samsung UE49M5005AKXXC | x | x | 1.3 | |
| Samsung UE49M5505AKXXC | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE49M5515AKXXC | x | x | 1.3 | |
| Samsung UE49M5605AKXXC | x | x | 1.3 | |
| Samsung UE49M6305AKXXC | x | x | 1.3 | |
| Samsung UE49MU6105KXXC | x | x | 1.3 | |
| Samsung UE49MU6175UXXC | x | x | 1.3 | |
| Samsung UE49MU6195UXXC | x | x | 1.3 | |
| Samsung UE49MU6275UXXC | x | x | 1.3 | |
| Samsung UE49MU6405UXXC | x | x | 1.3 | |
| Samsung UE49MU6445UXXC | x | x | 1.3 | |
| Samsung UE49MU6455UXXC | x | x | 1.3 | |
| Samsung UE49MU6475UXXC | x | x | 1.3 | |
| Samsung UE49MU6505UXXC | x | x | 1.3 | |
| Samsung UE49MU6645UXXC | x | x | 1.3 | |
| Samsung UE49MU6655UXXC | x | x | 1.3 | |
| Samsung UE49MU6675UXXC | x | x | 1.3 | |
| Samsung UE49MU7005TXXC | x | x | 1.3 | |
| Samsung UE49MU7045TXXC | x | x | 1.3 | |
| Samsung UE49MU7055TXXC | x | x | 1.3 | |
| Samsung UE49MU7075TXXC | x | x | 1.3 | |
| Samsung UE49MU8005TXXC | x | x | 1.3 | |
| Samsung UE49MU9005TXXC | x | x | 1.3 | |
| Samsung UE49NU7105KXXC | x | x | 1.4 | |
| Samsung UE49NU7305KXXC | x | x | 1.4 | |
| Samsung UE49NU7505UXXC | x | x | 1.4 | |
| Samsung UE49NU7645UXXC | x | x | 1.4 | |
| Samsung UE49NU7655UXXC | x | x | 1.4 | |
| Samsung UE49NU7675UXXC | x | x | 1.4 | |
| Samsung UE49NU8005TXXC | x | x | 1.4 | |
| Samsung UE49NU8045TXXC | x | x | 1.4 | |
| Samsung UE49NU8055TXXC | x | x | 1.4 | |
| Samsung UE49NU8075TXXC | x | x | 1.4 | |
| Samsung UE50EH5305KXXE | x | x | 1.2 | |
| Samsung UE50ES5505 | x | x | 1.2 | |
| Samsung UE50ES6715UXXE | x | x | 1.2 | |
| Samsung UE50ES6905UXXE | x | x | 1.2 | |
| Samsung UE50F5005AKXXE | x | x | 1.2 | |
| Samsung UE50F5305AKXXE | x | x | 1.2 | |
| Samsung UE50F5505AKXXE | x | x | 1.2 | |
| Samsung UE50F6105AKXXE | x | x | 1.2 | |
| Samsung UE50F6275SBXXE | x | x | 1.2 | |
| Samsung UE50F6475SBXXE | x | x | 1.2 | |
| Samsung UE50F6505SBXXE | x | x | 1.2 | |
| Samsung UE50F6645SBXXE | x | x | 1.2 | |
| Samsung UE50F6655SBXXE | x | x | 1.2 | |
| Samsung UE50F6675SBXXE | x | x | 1.2 | |
| Samsung UE50F6745SBXXE | x | x | 1.2 | |
| Samsung UE50F6805SBXXE | x | x | 1.2 | |
| Samsung UE50H5005AKXXE | x | x | 1.2 | |
| Samsung UE50H5304AKXXE | x | x | 1.2 | |
| Samsung UE50H5505AKXXE | x | x | 1.2 | |
| Samsung UE50H6275SUXXE | x | x | 1.2 | |
| Samsung UE50H6475SUXXE | x | x | 1.2 | |
| Samsung UE50HU6905UXXE | x | x | 1.2 | |
| Samsung UE50J5505AKXXE | x | x | 1.3 | |
| Samsung UE50J6175AUXXE | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE50J6275SUXXE | x | x | 1.3 | |
| Samsung UE50J6285SUXXE | x | x | 1.3 | |
| Samsung UE50JU6075UXXE | x | x | 1.2 | |
| Samsung UE50JU6475UXXE | x | x | 1.3 | |
| Samsung UE50JU6875UXXE | x | x | 1.3 | |
| Samsung UE50KU6075UXXE | x | x | 1.3 | |
| Samsung UE50KU6095UXXE | x | x | 1.3 | |
| Samsung UE50MU6125KXXC | x | x | 1.3 | |
| Samsung UE50NU6025KXXC | x | x | 1.4 | |
| Samsung UE50NU7405UXXC | x | x | 1.4 | |
| Samsung UE50NU7445UXXC | x | x | 1.4 | |
| Samsung UE50NU7455UXXC | x | x | 1.4 | |
| Samsung UE50NU7475UXXC | x | x | 1.4 | |
| Samsung UE55D6207TKXXE | x | x | 1.2 | x |
| Samsung UE55D6307SKXXE | x | x | 1.2 | x |
| Samsung UE55D6327SKXXE | x | x | 1.2 | x |
| Samsung UE55D6507VKXXE | x | x | 1.2 | x |
| Samsung UE55D6537WKXXE | x | x | 1.2 | x |
| Samsung UE55D6577WKXXE | x | x | 1.2 | x |
| Samsung UE55D6757WKXXE | x | x | 1.2 | x |
| Samsung UE55D7005LUXXE | x | x | 1.2 | x |
| Samsung UE55D8005YUXXE | x | x | 1.2 | |
| Samsung UE55ES6305UXXE | x | x | 1.2 | |
| Samsung UE55ES6535UXXE | x | x | 1.2 | |
| Samsung UE55ES6545UXXE | x | x | 1.2 | |
| Samsung UE55ES6565UXXE | x | x | 1.2 | |
| Samsung UE55ES6575UXXE | x | x | 1.2 | |
| Samsung UE55ES6805UXXE | x | x | 1.2 | |
| Samsung UE55ES6905UXXE | x | x | 1.2 | |
| Samsung UE55ES7005UXXE | x | x | 1.2 | |
| Samsung UE55ES8005UXXE | x | x | 1.2 | |
| Samsung UE55F6105AKXXE | x | x | 1.2 | |
| Samsung UE55F6475SBXXE | x | x | 1.2 | |
| Samsung UE55F6505SBXXE | x | x | 1.2 | |
| Samsung UE55F6515SBXXE | x | x | 1.2 | |
| Samsung UE55F6645SBXXE | x | x | 1.2 | |
| Samsung UE55F6655SBXXE | x | x | 1.2 | |
| Samsung UE55F6675SBXXE | x | x | 1.2 | |
| Samsung UE55F6745SBXXE | x | x | 1.2 | |
| Samsung UE55F6805SBXXE | x | x | 1.2 | |
| Samsung UE55F7005STXXE | x | x | 1.2 | |
| Samsung UE55F8005STXXE | x | x | 1.2 | |
| Samsung UE55F8505STXXE | x | x | 1.2 | |
| Samsung UE55H6204AKXXE | x | x | 1.2 | |
| Samsung UE55H6275SUXXE | x | x | 1.2 | |
| Samsung UE55H6415SUXXE | x | x | 1.2 | |
| Samsung UE55H6475SUXXE | x | x | 1.2 | |
| Samsung UE55H6505STXXE | x | x | 1.2 | |
| Samsung UE55H6645STXXE | x | x | 1.2 | |
| Samsung UE55H6655STXXE | x | x | 1.2 | |
| Samsung UE55H6675STXXE | x | x | 1.2 | |
| Samsung UE55H6705STXXE | x | x | 1.2 | |
| Samsung UE55H7005SQXXE | x | x | 1.2 | |
| Samsung UE55H8005SQXXE | x | x | 1.2 | |
| Samsung UE55HU6905UXXE | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE55HU7505TXXE | x | x | 1.2 | |
| Samsung UE55HU8205TXXE | x | x | 1.2 | |
| Samsung UE55HU8505QXXE | x | x | 1.2 | |
| Samsung UE55J5505AKXXE | x | x | 1.3 | |
| Samsung UE55J5605AKXXE | x | x | 1.3 | |
| Samsung UE55J6175AUXXE | x | x | 1.2 | |
| Samsung UE55J6275SUXXE | x | x | 1.3 | |
| Samsung UE55J6285SUXXE | x | x | 1.3 | |
| Samsung UE55J6375SUXXE | x | x | 1.3 | |
| Samsung UE55JS8005TXXE | x | x | 1.3 | |
| Samsung UE55JS8505TXXE | x | x | 1.3 | |
| Samsung UE55JS9005QXXE | x | x | 1.3 | |
| Samsung UE55JU6075UXXE | x | x | 1.2 | |
| Samsung UE55JU6415UXXE | x | x | 1.3 | |
| Samsung UE55JU6465UXXE | x | x | 1.3 | |
| Samsung UE55JU6475UXXE | x | x | 1.3 | |
| Samsung UE55JU6515UXXE | x | x | 1.3 | |
| Samsung UE55JU6575UXXE | x | x | 1.3 | |
| Samsung UE55JU6655UXXE | x | x | 1.3 | |
| Samsung UE55JU6675UXXE | x | x | 1.3 | |
| Samsung UE55JU6745UXXE | x | x | 1.3 | |
| Samsung UE55JU6875UXXE | x | x | 1.3 | |
| Samsung UE55JU7005TXXE | x | x | 1.3 | |
| Samsung UE55JU7505TXXE | x | x | 1.3 | |
| Samsung UE55K5105AKXXE | x | x | 1.3 | |
| Samsung UE55K5505AKXXE | x | x | 1.3 | |
| Samsung UE55K5515AKXXE | x | x | 1.3 | |
| Samsung UE55K5605AKXXE | x | x | 1.3 | |
| Samsung UE55K6375SUXXE | x | x | 1.3 | |
| Samsung UE55KS7005UXXE | x | x | 1.3 | |
| Samsung UE55KS7505UXXE | x | x | 1.3 | |
| Samsung UE55KS8005TXXE | x | x | 1.3 | |
| Samsung UE55KS9005TXXE | x | x | 1.3 | |
| Samsung UE55KS9505TXXE | x | x | 1.3 | |
| Samsung UE55KU6075UXXE | x | x | 1.3 | |
| Samsung UE55KU6095UXXE | x | x | 1.3 | |
| Samsung UE55KU6175UXXE | x | x | 1.3 | |
| Samsung UE55KU6405UXXE | x | x | 1.3 | |
| Samsung UE55KU6455UXXE | x | x | 1.3 | |
| Samsung UE55KU6475UXXE | x | x | 1.3 | |
| Samsung UE55KU6505UXXE | x | x | 1.3 | |
| Samsung UE55KU6515UXXE | x | x | 1.3 | |
| Samsung UE55KU6645UXXE | x | x | 1.3 | |
| Samsung UE55KU6655UXXE | x | x | 1.3 | |
| Samsung UE55KU6675UXXE | x | x | 1.3 | |
| Samsung UE55LS003AUXXC | x | x | 1.3 | |
| Samsung UE55LS03NAUXXC | x | x | 1.4 | |
| Samsung UE55M5505AKXXC | x | x | 1.3 | |
| Samsung UE55M5515AKXXC | x | x | 1.3 | |
| Samsung UE55M5605AKXXC | x | x | 1.3 | |
| Samsung UE55M6305AKXXC | x | x | 1.3 | |
| Samsung UE55MU6105KXXC | x | x | 1.3 | |
| Samsung UE55MU6125KXXC | x | x | 1.3 | |
| Samsung UE55MU6175UXXC | x | x | 1.3 | |
| Samsung UE55MU6195UXXC | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE55MU6275UXXC | x | x | 1.3 | |
| Samsung UE55MU6405UXXC | x | x | 1.3 | |
| Samsung UE55MU6445UXXC | x | x | 1.3 | |
| Samsung UE55MU6455UXXC | x | x | 1.3 | |
| Samsung UE55MU6475UXXC | x | x | 1.3 | |
| Samsung UE55MU6505UXXC | x | x | 1.3 | |
| Samsung UE55MU6645UXXC | x | x | 1.3 | |
| Samsung UE55MU6655UXXC | x | x | 1.3 | |
| Samsung UE55MU6675UXXC | x | x | 1.3 | |
| Samsung UE55MU7005TXXC | x | x | 1.3 | |
| Samsung UE55MU7045TXXC | x | x | 1.3 | |
| Samsung UE55MU7055TXXC | x | x | 1.3 | |
| Samsung UE55MU7075TXXC | x | x | 1.3 | |
| Samsung UE55MU8005TXXC | x | x | 1.3 | |
| Samsung UE55MU9005TXXC | x | x | 1.3 | |
| Samsung UE55NU6025KXXC | x | x | 1.4 | |
| Samsung UE55NU6035KXXC | x | x | 1.4 | |
| Samsung UE55NU7105KXXC | x | x | 1.4 | |
| Samsung UE55NU7305KXXC | x | x | 1.4 | |
| Samsung UE55NU7405UXXC | x | x | 1.4 | |
| Samsung UE55NU7445UXXC | x | x | 1.4 | |
| Samsung UE55NU7455UXXC | x | x | 1.4 | |
| Samsung UE55NU7475UXXC | x | x | 1.4 | |
| Samsung UE55NU7505UXXC | x | x | 1.4 | |
| Samsung UE55NU7645UXXC | x | x | 1.4 | |
| Samsung UE55NU7655UXXC | x | x | 1.4 | |
| Samsung UE55NU7675UXXC | x | x | 1.4 | |
| Samsung UE55NU8005TXXC | x | x | 1.4 | |
| Samsung UE55NU8045TXXC | x | x | 1.4 | |
| Samsung UE55NU8055TXXC | x | x | 1.4 | |
| Samsung UE55NU8075TXXC | x | x | 1.4 | |
| Samsung UE55NU8505TXXC | x | x | 1.4 | |
| Samsung UE58MU6125KXXC | x | x | 1.3 | |
| Samsung UE60D8005YUXXE | x | x | 1.2 | x |
| Samsung UE60ES6305UXXE | x | x | 1.2 | |
| Samsung UE60F6105AKXXE | x | x | 1.2 | |
| Samsung UE60F6375SBXXE | x | x | 1.2 | |
| Samsung UE60F7005STXXE | x | x | 1.2 | |
| Samsung UE60H6204AKXX | x | x | 1.2 | |
| Samsung UE60H6275SUXXE | x | x | 1.2 | |
| Samsung UE60H7005SQXXE | x | x | 1.2 | |
| Samsung UE60J6175AUXXE | x | x | 1.2 | |
| Samsung UE60J6275SUXXE | x | x | 1.3 | |
| Samsung UE60J6285SUXXE | x | x | 1.3 | |
| Samsung UE60JU6075UXXE | x | x | 1.2 | |
| Samsung UE60JU6475UXXE | x | x | 1.3 | |
| Samsung UE60JU6875UXXE | x | x | 1.3 | |
| Samsung UE60KS7005UXXE | x | x | 1.3 | |
| Samsung UE60KU6075UXXE | x | x | 1.3 | |
| Samsung UE65ES8005UXXE | x | x | 1.2 | |
| Samsung UE65F6475SBXXE | x | x | 1.2 | |
| Samsung UE65F8005STXXE | x | x | 1.2 | |
| Samsung UE65H6475SUXXE | x | x | 1.2 | |
| Samsung UE65H8005SQXXE | x | x | 1.2 | |
| Samsung UE65HU7505TXXE | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE65HU8205TXXE | x | x | 1.2 | |
| Samsung UE65HU8505QXXE | x | x | 1.2 | |
| Samsung UE65J6295SUXXE | x | x | 1.3 | |
| Samsung UE65JS8505TXXE | x | x | 1.3 | |
| Samsung UE65JS9005QXXE | x | x | 1.3 | |
| Samsung UE65JS9505QXXE | x | x | 1.3 | |
| Samsung UE65JU6075UXXE | x | x | 1.2 | |
| Samsung UE65JU6475UXXE | x | x | 1.3 | |
| Samsung UE65JU6575UXXE | x | x | 1.3 | |
| Samsung UE65JU7005TXXE | x | x | 1.3 | |
| Samsung UE65JU7505TXXE | x | x | 1.3 | |
| Samsung UE65KS7005UXXE | x | x | 1.3 | |
| Samsung UE65KS7505UXXE | x | x | 1.3 | |
| Samsung UE65KS8005TXXE | x | x | 1.3 | |
| Samsung UE65KS9005TXXE | x | x | 1.3 | |
| Samsung UE65KS9505TXXE | x | x | 1.3 | |
| Samsung UE65KU6075UXXE | x | x | 1.3 | |
| Samsung UE65KU6095UXXE | x | x | 1.3 | |
| Samsung UE65KU6175UXXE | x | x | 1.3 | |
| Samsung UE65KU6405UXXE | x | x | 1.3 | |
| Samsung UE65KU6505UXXE | x | x | 1.3 | |
| Samsung UE65KU6685UXXE | x | x | 1.3 | |
| Samsung UE65LS003AUXXC | x | x | 1.3 | |
| Samsung UE65LS03NAUXXC | x | x | 1.4 | |
| Samsung UE65MU6105KXXC | x | x | 1.3 | |
| Samsung UE65MU6125KXXC | x | x | 1.3 | |
| Samsung UE65MU6175UXXC | x | x | 1.3 | |
| Samsung UE65MU6195UXXC | x | x | 1.3 | |
| Samsung UE65MU6275UXXC | x | x | 1.3 | |
| Samsung UE65MU6405UXXC | x | x | 1.3 | |
| Samsung UE65MU6445UXXC | x | x | 1.3 | |
| Samsung UE65MU6455UXXC | x | x | 1.3 | |
| Samsung UE65MU6475UXXC | x | x | 1.3 | |
| Samsung UE65MU6505UXXC | x | x | 1.3 | |
| Samsung UE65MU6645UXXC | x | x | 1.3 | |
| Samsung UE65MU6655UXXC | x | x | 1.3 | |
| Samsung UE65MU6675UXXC | x | x | 1.3 | |
| Samsung UE65MU7005TXXC | x | x | 1.3 | |
| Samsung UE65MU7045TXXC | x | x | 1.3 | |
| Samsung UE65MU7055TXXC | x | x | 1.3 | |
| Samsung UE65MU7075TXXC | x | x | 1.3 | |
| Samsung UE65MU8005TXXC | x | x | 1.3 | |
| Samsung UE65MU9005TXXC | x | x | 1.3 | |
| Samsung UE65NU6025KXXC | x | x | 1.4 | |
| Samsung UE65NU7105KXXC | x | x | 1.4 | |
| Samsung UE65NU7305KXXC | x | x | 1.4 | |
| Samsung UE65NU7405UXXC | x | x | 1.4 | |
| Samsung UE65NU7445UXXC | x | x | 1.4 | |
| Samsung UE65NU7455UXXC | x | x | 1.4 | |
| Samsung UE65NU7475UXXC | x | x | 1.4 | |
| Samsung UE65NU7505UXXC | x | x | 1.4 | |
| Samsung UE65NU7645UXXC | x | x | 1.4 | |
| Samsung UE65NU7655UXXC | x | x | 1.4 | |
| Samsung UE65NU7675UXXC | x | x | 1.4 | |
| Samsung UE65NU8005TXXC | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Samsung UE65NU8045TXXC | x | x | 1.4 | |
| Samsung UE65NU8055TXXC | x | x | 1.4 | |
| Samsung UE65NU8075TXXC | x | x | 1.4 | |
| Samsung UE65NU8505TXXC | x | x | 1.4 | |
| Samsung UE70KU6075UXXE | x | x | 1.3 | |
| Samsung UE75F6475SBXXE | x | x | 1.2 | |
| Samsung UE75F8005STXXE | x | x | 1.2 | |
| Samsung UE75H6475SUXXE | x | x | 1.2 | |
| Samsung UE75HU7505TXXE | x | x | 1.2 | |
| Samsung UE75JU6475UXXE | x | x | 1.3 | |
| Samsung UE75JU7005TXXE | x | x | 1.3 | |
| Samsung UE75KS8005TXXE | x | x | 1.3 | |
| Samsung UE75MU6125KXXC | x | x | 1.3 | |
| Samsung UE75MU6175UXXC | x | x | 1.3 | |
| Samsung UE75MU7005TXXC | x | x | 1.3 | |
| Samsung UE75MU8005TXXC | x | x | 1.3 | |
| Samsung UE75NU7105KXXC | x | x | 1.4 | |
| Samsung UE75NU8005TXXC | x | x | 1.4 | |
| Samsung UE78HU8505QXXE | x | x | 1.2 | |
| Samsung UE78JS9505QXXE | x | x | 1.3 | |
| Samsung UE78JU7505TXXE | x | x | 1.3 | |
| Samsung UE78KS9005TXXE | x | x | 1.3 | |
| Samsung UE78KS9505TXXE | x | x | 1.3 | |
| Samsung UE78KU6505UXXE | x | x | 1.3 | |
| Samsung UE82MU7005TXXC | x | x | 1.3 | |
| Samsung UE82NU8005TXXC | x | x | 1.4 | |
| Samsung UE85HU7505TXXE | x | x | 1.2 | |
| Samsung UE85JU7005TXXE | x | x | 1.3 | |
| Samsung UE88JS9505QXXE | x | x | 1.3 | |
| Samsung UE88KS9805TXXE | x | x | 1.3 | |
| Scansonic 20LEDDV TSW 802S | x | x | 1.2 | |
| SCANSONIC 20LEDTSW902S | x | x | 1.3 | |
| SCANSONIC 22LEDDV 500 BL | x | x | 1.2 | |
| Scansonic 22LEDDV 500 T2 | x | x | 1.2 | |
| SCANSONIC 22LEDDV 500 WH | x | x | 1.2 | |
| Scansonic 22LEDDV TSW 802S | x | x | 1.2 | |
| Scansonic 22LEDDV500T2WH. | x | x | 1.2 | |
| SCANSONIC 22LEDTSW902S | x | x | 1.3 | |
| Scansonic 24LEDDV TSW802S | x | x | 1.2 | |
| SCANSONIC 24LEDTSW902S | x | x | 1.3 | |
| SCANSONIC 26LEDDV 500 BL | x | x | 1.2 | |
| SCANSONIC 26LEDDV 500 WH | x | x | 1.2 | |
| SCANSONIC 28LED DV800 BL | x | x | 1.2 | |
| Scansonic 28LEDDV 800 | x | x | 1.2 | |
| Scansonic 28LEDDV 800 T2 | x | x | 1.2 | |
| Scansonic 32LED TSW 802 | x | x | 1.2 | |
| SCANSONIC 32LEDDV 500 WH | x | x | 1.2 | |
| SCANSONIC 32LEDDV500BLACK | x | x | 1.2 | |
| Scansonic 40LED TSW802S | x | x | 1.2 | |
| SEHMAX 20LED 315-DC T2/C/S2 | x | x | 1.3 | |
| SEHMAX 22LED DV315-DC T2/C BLACK | x | x | 1.3 | |
| SEHMAX 24LED DV315-DC T2/C DVD 12V BL | x | x | 1.3 | |
| SEHMAX 24LED DV315-DC T2/C WHITE | x | x | 1.3 | |
| SEHMAX 32LED 305 T2/C BLACK | x | x | 1.3 | |
| SEHMAX 43LED 355 T2/C/S2 SMART BLACK | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| SEHMAX SM22 325 B | x | x | 1.3 | |
| SEHMAX SM24 325 B | x | x | 1.3 | |
| SEHMAX SM24 325 W | x | x | 1.3 | |
| SEHMAX SM32 315 B | x | x | 1.3 | |
| SEHMAX SM43 355 | x | x | 1.3 | |
| Senz LED24KDT | x | x | 1.2 | |
| Sharp 1T-C24BF0ED1NW | x | x | 1.4 | |
| Sharp 1T-C24BF1ED1NB | x | x | 1.4 | |
| Sharp 1T-C32BD2EM2NB | x | x | 1.4 | |
| Sharp 1T-C32BD4EL2NB | x | x | 1.4 | |
| Sharp 1T-C32BE0EO2NB | x | x | 1.4 | |
| Sharp 1T-C32BE1EE2NB | x | x | 1.4 | |
| Sharp 1T-C32BE2EH2NB | x | x | 1.4 | |
| Sharp 1T-C32BE3EH2NB | x | x | 1.4 | |
| Sharp 1T-C32BE4EH2NB | x | x | 1.4 | |
| Sharp 1T-C32BE5EH2NB | x | x | 1.4 | |
| Sharp 1T-C32BF2EM2NB | x | x | 1.4 | |
| Sharp 1T-C32BF3EJ2NB | x | x | 1.4 | |
| Sharp 1T-C32BF4EL2NB | x | x | 1.4 | |
| Sharp 1T-C32BF5EM2NB | x | x | 1.4 | |
| Sharp 2T-C32BE2EG2NB | x | x | 1.4 | |
| Sharp 2T-C32BE3EG2NB | x | x | 1.4 | |
| Sharp 2T-C32BE4EG2NB | x | x | 1.4 | |
| Sharp 2T-C32BE5EG2NB | x | x | 1.4 | |
| Sharp 2T-C32BF2EM2NB | x | x | 1.4 | |
| Sharp 2T-C32BF3EJ2NB | x | x | 1.4 | |
| Sharp 2T-C32BF4EL2NB | x | x | 1.4 | |
| Sharp 2T-C32BF5EM2NB | x | x | 1.4 | |
| Sharp 2T-C40BE0EO2NB | x | x | 1.4 | |
| Sharp 2T-C40BE1EE2NB | x | x | 1.4 | |
| Sharp 2T-C40BE2EG2NB | x | x | 1.4 | |
| Sharp 2T-C40BE3EG2NB | x | x | 1.4 | |
| Sharp 2T-C40BE4EG2NB | x | x | 1.4 | |
| Sharp 2T-C40BE5EG2NB | x | x | 1.4 | |
| Sharp 2T-C40BF2EM2NB | x | x | 1.4 | |
| Sharp 2T-C40BF3EJ2NB | x | x | 1.4 | |
| Sharp 2T-C40BF4EL2NB | x | x | 1.4 | |
| Sharp 2T-C40BF5EM2NB | x | x | 1.4 | |
| Sharp 2T-C43AE2EG2NB | x | x | 1.4 | |
| Sharp 2T-C43AE3EG2NB | x | x | 1.4 | |
| Sharp 2T-C43BE2EG2NB | x | x | 1.4 | |
| Sharp 2T-C43BE3EG2NB | x | x | 1.4 | |
| Sharp 2T-C43BE4EG2NB | x | x | 1.4 | |
| Sharp 2T-C43BE5EG2NB | x | x | 1.4 | |
| Sharp 2T-C43BF2EM2NB | x | x | 1.4 | |
| Sharp 2T-C43BF3EJ2NB | x | x | 1.4 | |
| Sharp 2T-C43BF4EL2NB | x | x | 1.4 | |
| Sharp 2T-C43BF5EM2NB | x | x | 1.4 | |
| Sharp 2T-C45BE2EG2NB | x | x | 1.4 | |
| Sharp 2T-C45BE3EG2NB | x | x | 1.4 | |
| Sharp 2T-C45BE4EG2NB | x | x | 1.4 | |
| Sharp 2T-C45BE5EG2NB | x | x | 1.4 | |
| Sharp 2T-C45BF2EM2NB | x | x | 1.4 | |
| Sharp 2T-C45BF3EJ2NB | x | x | 1.4 | |
| Sharp 2T-C45BF4EL2NB | x | x | 1.4 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sharp 2T-C45BF5EM2NB | x | x | 1.4 | |
| Sharp 2T-C49BE2EG2NB | x | x | 1.4 | |
| Sharp 2T-C49BE3EG2NB | x | x | 1.4 | |
| Sharp 2T-C49BE4EG2NB | x | x | 1.4 | |
| Sharp 2T-C49BE5EG2NB | x | x | 1.4 | |
| Sharp 2T-C49BF2EM2NB | x | x | 1.4 | |
| Sharp 2T-C49BF3EJ2NB | x | x | 1.4 | |
| Sharp 2T-C49BF4EL2NB | x | x | 1.4 | |
| Sharp 2T-C49BF5EM2NB | x | x | 1.4 | |
| Sharp 2T-C50BE2EG2NB | x | x | 1.4 | |
| Sharp 2T-C50BE3EG2NB | x | x | 1.4 | |
| Sharp 2T-C50BE4EG2NB | x | x | 1.4 | |
| Sharp 2T-C50BE5EG2NB | x | x | 1.4 | |
| Sharp 2T-C50BF2EM2NB | x | x | 1.4 | |
| Sharp 2T-C50BF3EJ2NB | x | x | 1.4 | |
| Sharp 2T-C50BF4EL2NB | x | x | 1.4 | |
| Sharp 2T-C50BF5EM2NB | x | x | 1.4 | |
| Sharp 2T-C55BF5EM2NB | x | x | 1.4 | |
| Sharp LC-24CHF4011E | x | x | 1.3 | |
| Sharp LC-24CHF4012E | x | x | 1.3 | |
| Sharp LC-24CHG5111E | x | x | 1.3 | |
| Sharp LC-24CHG5112E | x | x | 1.3 | |
| Sharp LC-24CHG6001E | x | x | 1.3 | |
| Sharp LC-24CHG6002E | x | x | 1.3 | |
| Sharp LC-24CHG6131E | x | x | 1.3 | |
| Sharp LC-24CHG6132E | x | x | 1.3 | |
| Sharp LC-32CFE5111E | x | x | 1.3 | |
| Sharp LC-32CFE5221E | x | x | 1.3 | |
| Sharp LC-32CFE6131E | x | x | 1.3 | |
| Sharp LC-32CFE6241E | x | x | 1.3 | |
| Sharp LC-32CFE6351E | x | x | 1.3 | |
| Sharp LC-32CFF5221E | x | x | 1.3 | |
| Sharp LC-32CFF5222E | x | x | 1.3 | |
| Sharp LC-32CFG6001E | x | x | 1.3 | |
| Sharp LC-32CFG6002E | x | x | 1.3 | |
| Sharp LC-32CFG6241E | x | x | 1.3 | |
| Sharp LC-32CFG6242E | x | x | 1.3 | |
| Sharp LC-32CFG6352E | x | x | 1.3 | |
| Sharp LC-32CFG6452E | x | x | 1.3 | |
| Sharp LC-32CHE5111E | x | x | 1.3 | |
| Sharp LC-32CHE5200E | x | x | 1.3 | |
| Sharp LC-32CHE5221E | x | x | 1.3 | |
| Sharp LC-32CHE6131E | x | x | 1.3 | |
| Sharp LC-32CHE6241E | x | x | 1.3 | |
| Sharp LC-32CHF5221E | x | x | 1.3 | |
| Sharp LC-32CHF5222E | x | x | 1.3 | |
| Sharp LC-32CHG4041E | x | x | 1.3 | |
| Sharp LC-32CHG4042E | x | x | 1.3 | |
| Sharp LC-32CHG6021E | x | x | 1.3 | |
| Sharp LC-32CHG6022E | x | x | 1.3 | |
| Sharp LC-32CHG6241E | x | x | 1.3 | |
| Sharp LC-32CHG6242E | x | x | 1.3 | |
| Sharp LC-32CHG6352E | x | x | 1.3 | |
| Sharp LC-32CHG6452E | x | x | 1.3 | |
| Sharp LC-32LE341S | x | x | 1.2 | x |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sharp LC-32LE361EN | x | x | 1.2 | |
| Sharp LC-32LE631E | x | x | 1.2 | |
| Sharp LC-32LU631E | x | x | 1.2 | |
| Sharp LC-32LX631E | x | x | 1.2 | |
| Sharp LC-40CFE5111E | x | x | 1.3 | |
| Sharp LC-40CFE5221E | x | x | 1.3 | |
| Sharp LC-40CFE6131E | x | x | 1.3 | |
| Sharp LC-40CFE6241E | x | x | 1.3 | |
| Sharp LC-40CFE6351E | x | x | 1.3 | |
| Sharp LC-40CFF5221E | x | x | 1.3 | |
| Sharp LC-40CFF5222E | x | x | 1.3 | |
| Sharp LC-40CFG4041E | x | x | 1.3 | |
| Sharp LC-40CFG4042E | x | x | 1.3 | |
| Sharp LC-40CFG6001E | x | x | 1.3 | |
| Sharp LC-40CFG6002E | x | x | 1.3 | |
| Sharp LC-40CFG6021E | x | x | 1.3 | |
| Sharp LC-40CFG6022E | x | x | 1.3 | |
| Sharp LC-40CFG6241E | x | x | 1.3 | |
| Sharp LC-40CFG6241K | x | x | 1.3 | |
| Sharp LC-40CFG6242E | x | x | 1.3 | |
| Sharp LC-40CFG6352E | x | x | 1.3 | |
| Sharp LC-40CFG6452E | x | x | 1.3 | |
| Sharp LC-40LE341S | x | x | 1.2 | x |
| Sharp LC-40LE361EN | x | x | 1.2 | |
| Sharp LC-40LE631E | x | x | 1.2 | |
| Sharp LC-40LE831S | x | x | 1.2 | x |
| Sharp LC-40LU631E | x | x | 1.2 | |
| Sharp LC-40LX631E | x | x | 1.2 | |
| Sharp LC-40UK7252E | x | x | 1.3 | |
| Sharp LC-40UK7352E | x | x | 1.3 | |
| Sharp LC-40UK7452E | x | x | 1.3 | |
| Sharp LC-40UK7552E | x | x | 1.3 | |
| Sharp LC-42LE758EN | x | x | 1.2 | |
| Sharp LC-42LE761EN | x | x | 1.2 | |
| Sharp LC-42LE771EN | x | x | 1.2 | |
| Sharp LC-43CFE5111E | x | x | 1.3 | |
| Sharp LC-43CFE5221E | x | x | 1.3 | |
| Sharp LC-43CFE6131E | x | x | 1.3 | |
| Sharp LC-43CFE6241E | x | x | 1.3 | |
| Sharp LC-43CFE6351E | x | x | 1.3 | |
| Sharp LC-43CFF5221E | x | x | 1.3 | |
| Sharp LC-43CFF5222E | x | x | 1.3 | |
| Sharp LC-43CFG4041E | x | x | 1.3 | |
| Sharp LC-43CFG4042E | x | x | 1.3 | |
| Sharp LC-43CFG6001E | x | x | 1.3 | |
| Sharp LC-43CFG6002E | x | x | 1.3 | |
| Sharp LC-43CFG6021E | x | x | 1.3 | |
| Sharp LC-43CFG6022E | x | x | 1.3 | |
| Sharp LC-43CFG6241E | x | x | 1.3 | |
| Sharp LC-43CFG6242E | x | x | 1.3 | |
| Sharp LC-43CFG6352E | x | x | 1.3 | |
| Sharp LC-43CFG6452E | x | x | 1.3 | |
| Sharp LC-43CUF8382E | x | x | 1.3 | |
| Sharp LC-43CUF8462E | x | x | 1.3 | |
| Sharp LC-43SFE7331E | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sharp LC-43SFE7451E | x | x | 1.3 | |
| Sharp LC-43UK7252E | x | x | 1.3 | |
| Sharp LC-43UK7352E | x | x | 1.3 | |
| Sharp LC-43UK7552E | x | x | 1.3 | |
| Sharp LC-43UK8652E | x | x | 1.3 | |
| Sharp LC-43UK8762ES | x | x | 1.3 | |
| Sharp LC-43UK8872ES | x | x | 1.3 | |
| Sharp LC-46LE631E | x | x | 1.2 | |
| Sharp LC-46LE831S | x | x | 1.2 | x |
| Sharp LC-46LU631E | x | x | 1.2 | |
| Sharp LC-46LX631E | x | x | 1.2 | |
| Sharp LC-49CFE5001E | x | x | 1.3 | |
| Sharp LC-49CFE5221E | x | x | 1.3 | |
| Sharp LC-49CFE6031E | x | x | 1.3 | |
| Sharp LC-49CFE6241E | x | x | 1.3 | |
| Sharp LC-49CFE6351E | x | x | 1.3 | |
| Sharp LC-49CFF5221E | x | x | 1.3 | |
| Sharp LC-49CFF5221K | x | x | 1.3 | |
| Sharp LC-49CFF5222E | x | x | 1.3 | |
| Sharp LC-49CFG4041E | x | x | 1.3 | |
| Sharp LC-49CFG4042E | x | x | 1.3 | |
| Sharp LC-49CFG6001E | x | x | 1.3 | |
| Sharp LC-49CFG6002E | x | x | 1.3 | |
| Sharp LC-49CFG6021E | x | x | 1.3 | |
| Sharp LC-49CFG6022E | x | x | 1.3 | |
| Sharp LC-49CFG6241E | x | x | 1.3 | |
| Sharp LC-49CFG6242E | x | x | 1.3 | |
| Sharp LC-49CFG6352E | x | x | 1.3 | |
| Sharp LC-49CFG6452E | x | x | 1.3 | |
| Sharp LC-49CUF8382E | x | x | 1.3 | |
| Sharp LC-49CUF8462E | x | x | 1.3 | |
| Sharp LC-49SFE7331E | x | x | 1.3 | |
| Sharp LC-49SFE7451E | x | x | 1.3 | |
| Sharp LC-49UK7252E | x | x | 1.3 | |
| Sharp LC-49UK7352E | x | x | 1.3 | |
| Sharp LC-49UK7552E | x | x | 1.3 | |
| Sharp LC-49UK8652E | x | x | 1.3 | |
| Sharp LC-49UK8762ES | x | x | 1.3 | |
| Sharp LC-49UK8872ES | x | x | 1.3 | |
| Sharp LC-49XUF8772E | x | x | 1.3 | |
| Sharp LC-50CFE5101E | x | x | 1.3 | |
| Sharp LC-50CFE5111E | x | x | 1.3 | |
| Sharp LC-50CFE6131E | x | x | 1.3 | |
| Sharp LC-50LE758EN | x | x | 1.2 | |
| Sharp LC-50LE761EN | x | x | 1.2 | |
| Sharp LC-50LE771EN | x | x | 1.2 | |
| Sharp LC-50UK7252E | x | x | 1.3 | |
| Sharp LC-50UK7352E | x | x | 1.3 | |
| Sharp LC-50UK7452E | x | x | 1.3 | |
| Sharp LC-50UK7552E | x | x | 1.3 | |
| Sharp LC-52LE831S | x | x | 1.2 | x |
| Sharp LC-55CFE6241E | x | x | 1.3 | |
| Sharp LC-55CFG4041E | x | x | 1.3 | |
| Sharp LC-55CFG4042E | x | x | 1.3 | |
| Sharp LC-55CFG6021E | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sharp LC-55CFG6022E | x | x | 1.3 | |
| Sharp LC-55CFG6241E | x | x | 1.3 | |
| Sharp LC-55CFG6242E | x | x | 1.3 | |
| Sharp LC-55CFG6352E | x | x | 1.3 | |
| Sharp LC-55CFG6452E | x | x | 1.3 | |
| Sharp LC-55CUF8382E | x | x | 1.3 | |
| Sharp LC-55CUF8462E | x | x | 1.3 | |
| Sharp LC-55UK7252E | x | x | 1.3 | |
| Sharp LC-55UK7352E | x | x | 1.3 | |
| Sharp LC-55UK7552E | x | x | 1.3 | |
| Sharp LC-55UK8652E | x | x | 1.3 | |
| Sharp LC-55UK8762ES | x | x | 1.3 | |
| Sharp LC-55UK8872ES | x | x | 1.3 | |
| Sharp LC-55XUF8772E | x | x | 1.3 | |
| Sharp LC-60LE636S | x | x | 1.2 | x |
| Sharp LC-60LE741S | x | x | 1.2 | x |
| Sharp LC-60LE831S | x | x | 1.2 | x |
| Sharp LC-60LE841S | x | x | 1.2 | x |
| Sharp LC-60LE857E | x | x | 1.2 | x |
| Sharp LC-60LE857EN | x | x | 1.2 | x |
| Sharp LC-60UD20EN | x | x | 1.2 | x |
| Sharp LC-60UI7652E | x | x | 1.3 | |
| Sharp LC-60UI9362E | x | x | 1.3 | |
| Sharp LC-60UQ10EN | x | x | 1.2 | x |
| Sharp LC-65UK7252E | x | x | 1.3 | |
| Sharp LC-65UK7352E | x | x | 1.3 | |
| Sharp LC-65UK7552E | x | x | 1.3 | |
| Sharp LC-65XUF8772E | x | x | 1.3 | |
| Sharp LC-70LE741S | x | x | 1.2 | x |
| Sharp LC-70LE747E | x | x | 1.2 | x |
| Sharp LC-70LE747EN | x | x | 1.2 | x |
| Sharp LC-70LE836S | x | x | 1.2 | x |
| Sharp LC-70LE857E | x | x | 1.2 | x |
| Sharp LC-70LE857EN | x | x | 1.2 | x |
| Sharp LC-70UD20EN | x | x | 1.2 | x |
| Sharp LC-70UI7652E | x | x | 1.3 | |
| Sharp LC-70UI9362E | x | x | 1.3 | |
| Sharp LC-70UQ10EN | x | x | 1.2 | x |
| Sharp LC-80LE646S | x | x | 1.2 | x |
| Sharp LC-80LE657E | x | x | 1.2 | x |
| Sharp LC-80LE657EN | x | x | 1.2 | x |
| Sharp LC-80LE857E | x | x | 1.2 | x |
| Sharp LC-80LE857EN | x | x | 1.2 | x |
| Sharp LC-80UQ10EN | x | x | 1.2 | x |
| Sharp LC-90LE757E | x | x | 1.2 | x |
| SKANTİC B2212FHD | x | x | 1.3 | |
| SKANTİC B2411HD | x | x | 1.2 | |
| SKANTİC B2412FHD | x | x | 1.3 | |
| Skantic B3211HD | x | x | 1.2 | |
| SKANTİC B3212HD | x | x | 1.3 | |
| SKANTİC B3912HD | x | x | 1.3 | |
| Skantic B4011FHD | x | x | 1.2 | |
| SKANTİC B4012FHD | x | x | 1.3 | |
| SKANTİC B4312HD | x | x | 1.3 | |
| SKANTİC B4912FHD | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| SKANTİC B5010FHD | x | x | 1.3 | |
| SKANTİC B5012FHD | x | x | 1.3 | |
| SKANTİC B5012FHD-K | x | x | 1.3 | |
| SKANTİC B5512FHD | x | x | 1.3 | |
| Sony KD100ZD9BAEP | x | x | 1.3 | |
| Sony KD43X8305CBAEP | x | x | 1.2 | |
| Sony KD43XD8005BAEP | x | x | 1.3 | |
| Sony KD43XD8305BAEP | x | x | 1.3 | |
| Sony KD43XE7003BAEP | x | x | 1.3 | |
| Sony KD43XE8005BAEP | x | x | 1.3 | |
| Sony KD43XE8077SAEP | x | x | 1.3 | |
| Sony KD43XE8099BAEP | x | x | 1.3 | |
| Sony KD43XF7005BAEP | x | x | 1.3 | |
| Sony KD43XF7077SAEP | x | x | 1.3 | |
| Sony KD43XF7596BAEP | x | x | 1.3 | |
| Sony KD43XF8096BAEP | x | x | 1.3 | |
| Sony KD43XF8505BAEP | x | x | 1.3 | |
| Sony KD43XF8596BAEP | x | x | 1.3 | |
| Sony KD43XF8599BAEP | x | x | 1.3 | |
| Sony KD49X8005CBAEP | x | x | 1.2 | |
| Sony KD49X8305CBAEP | x | x | 1.2 | |
| Sony KD49X8307CSAEP | x | x | 1.2 | |
| Sony KD49X8309CBAEP | x | x | 1.2 | |
| Sony KD49XD7004BAEP | x | x | 1.3 | |
| Sony KD49XD7005BAEP | x | x | 1.3 | |
| Sony KD49XD8005BAEP | x | x | 1.3 | |
| Sony KD49XD8305BAEP | x | x | 1.3 | |
| Sony KD49XE7003BAEP | x | x | 1.3 | |
| Sony KD49XE8005BAEP | x | x | 1.3 | |
| Sony KD49XE8077SAEP | x | x | 1.3 | |
| Sony KD49XE8099BAEP | x | x | 1.3 | |
| Sony KD49XE9005BAEP | x | x | 1.3 | |
| Sony KD49XF7005BAEP | x | x | 1.3 | |
| Sony KD49XF7077SAEP | x | x | 1.3 | |
| Sony KD49XF7596BAEP | x | x | 1.3 | |
| Sony KD49XF8096BAEP | x | x | 1.3 | |
| Sony KD49XF8505BAEP | x | x | 1.3 | |
| Sony KD49XF8577SAEP | x | x | 1.3 | |
| Sony KD49XF8596BAEP | x | x | 1.3 | |
| Sony KD49XF8599BAEP | x | x | 1.3 | |
| Sony KD55A1BAEP | x | x | 1.3 | |
| Sony KD-55AF9BAEP | x | x | 1.3 | |
| Sony KD55S8005CBAEP | x | x | 1.2 | |
| Sony KD55S8505CBAEP | x | x | 1.2 | |
| Sony KD55SD8505BAEP | x | x | 1.2 | |
| Sony KD55X8005CBAEP | x | x | 1.2 | |
| Sony KD55X8505CBAEP | x | x | 1.2 | |
| Sony KD55X8507CSAEP | x | x | 1.2 | |
| Sony KD55X8509CBAEP | x | x | 1.2 | |
| Sony KD-55X9005A | x | x | 1.2 | |
| Sony KD-55X9005ABAEP | x | x | 1.2 | |
| Sony KD55X9005CBAEP | x | x | 1.2 | |
| Sony KD55X9305CBAEP | x | x | 1.2 | |
| Sony KD55XD7004BAEP | x | x | 1.3 | |
| Sony KD55XD7005BAEP | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sony KD55XD8005BAEP | x | x | 1.3 | |
| Sony KD55XD8505BAEP | x | x | 1.2 | |
| Sony KD55XD8577SAEP | x | x | 1.2 | |
| Sony KD55XD8599BAEP | x | x | 1.2 | |
| Sony KD55XD9305BAEP | x | x | 1.2 | |
| Sony KD55XE7003BAEP | x | x | 1.3 | |
| Sony KD55XE8096BAEP | x | x | 1.3 | |
| Sony KD55XE8505BAEP | x | x | 1.3 | |
| Sony KD55XE8577SAEP | x | x | 1.3 | |
| Sony KD55XE8599BAEP | x | x | 1.3 | |
| Sony KD55XE9005BAEP | x | x | 1.3 | |
| Sony KD55XE9305BAEP | x | x | 1.3 | |
| Sony KD55XF7005BAEP | x | x | 1.3 | |
| Sony KD55XF7077SAEP | x | x | 1.3 | |
| Sony KD55XF7596BAEP | x | x | 1.3 | |
| Sony KD55XF8096BAEP | x | x | 1.3 | |
| Sony KD55XF8596BAEP | x | x | 1.3 | |
| Sony KD55XF8599BAEP | x | x | 1.3 | |
| Sony KD55XF9005BAEP | x | x | 1.3 | |
| Sony KD60XF8305BAEP | x | x | 1.3 | |
| Sony KD65A1BAEP | x | x | 1.3 | |
| Sony KD65AF8BAEP | x | x | 1.3 | |
| Sony KD-65AF9BAEP | x | x | 1.3 | |
| Sony KD65S8005CBAEP | x | x | 1.2 | |
| Sony KD65S8505CBAEP | x | x | 1.2 | |
| Sony KD65SD8505BAEP | x | x | 1.2 | |
| Sony KD65X8505CBAEP | x | x | 1.2 | |
| Sony KD65X8507CSAEP | x | x | 1.2 | |
| Sony KD65X8509CBAEP | x | x | 1.2 | |
| Sony KD-65X9005A | x | x | 1.2 | |
| Sony KD-65X9005ABAEP | x | x | 1.2 | |
| Sony KD65X9005CBAEP | x | x | 1.2 | |
| Sony KD65X9305CBAEP | x | x | 1.2 | |
| Sony KD65XD7504BAEP | x | x | 1.3 | |
| Sony KD65XD7505BAEP | x | x | 1.3 | |
| Sony KD65XD8505BAEP | x | x | 1.2 | |
| Sony KD65XD8577SAEP | x | x | 1.2 | |
| Sony KD65XD8599BAEP | x | x | 1.2 | |
| Sony KD65XD9305BAEP | x | x | 1.2 | |
| Sony KD65XE7005BAEP | x | x | 1.3 | |
| Sony KD65XE8505BAEP | x | x | 1.3 | |
| Sony KD65XE8577SAEP | x | x | 1.3 | |
| Sony KD65XE8596BAEP | x | x | 1.3 | |
| Sony KD65XE9005BAEP | x | x | 1.3 | |
| Sony KD65XE9305BAEP | x | x | 1.3 | |
| Sony KD65XF7005BAEP | x | x | 1.3 | |
| Sony KD65XF7005BAEP | x | x | 1.3 | |
| Sony KD65XF7596BAEP | x | x | 1.3 | |
| Sony KD65XF8505BAEP | x | x | 1.3 | |
| Sony KD65XF8577SAEP | x | x | 1.3 | |
| Sony KD65ZD9BAEP | x | x | 1.3 | |
| Sony KD-65ZF9BAEP | x | x | 1.3 | |
| Sony KD70XF8305BAEP | x | x | 1.3 | |
| Sony KD75X8505CBAEP | x | x | 1.2 | |
| Sony KD75X9405CBAEP | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sony KD75XD8505BAEP | x | x | 1.2 | |
| Sony KD75XD9405BAEP | x | x | 1.2 | |
| Sony KD75XE8596BAEP | x | x | 1.3 | |
| Sony KD75XE9005BAEP | x | x | 1.3 | |
| Sony KD75XE9405BAEP | x | x | 1.3 | |
| Sony KD75XF9005BAEP | x | x | 1.3 | |
| Sony KD75ZD9BAEP | x | x | 1.3 | |
| Sony KD-75ZF9BEAP | x | x | 1.3 | |
| Sony KD77A1BAEP | x | x | 1.3 | |
| Sony KD85XD8505BAEP | x | x | 1.2 | |
| Sony KD85XF8596BAEP | x | x | 1.3 | |
| Sony KDL-22EX553 | x | x | 1.2 | |
| Sony KDL-24W605A | x | x | 1.2 | |
| Sony KDL-24W605ABAEP | x | x | 1.2 | |
| Sony KDL-24W605AWAEP | x | x | 1.2 | |
| Sony KDL-26EX553 | x | x | 1.2 | |
| Sony KDL-32CX523 | x | x | 1.2 | |
| Sony KDL-32EX524 | x | x | 1.2 | |
| Sony KDL-32EX603 | x | x | 1.2 | |
| Sony KDL-32EX653 | x | x | 1.2 | |
| Sony KDL-32EX713 | x | x | 1.2 | |
| Sony KDL-32EX723 | x | x | 1.2 | |
| Sony KDL-32EX724 | x | x | 1.2 | |
| Sony KDL-32HX753 | x | x | 1.2 | |
| Sony KDL-32HX755 | x | x | 1.2 | |
| Sony KDL-32R403C | x | x | 1.3 | |
| Sony KDL32R413B | x | x | 1.2 | |
| Sony KDL32R415B | x | x | 1.2 | |
| Sony KDL-32R423ABAEP | x | x | 1.2 | |
| Sony KDL-32R424ABAEP | x | x | 1.2 | |
| Sony KDL32R435B | x | x | 1.2 | |
| Sony KDL-32R503C | x | x | 1.3 | |
| Sony KDL32RD433BAEP | x | x | 1.3 | |
| Sony KDL-32W603A | x | x | 1.2 | |
| Sony KDL-32W603ABAEP | x | x | 1.2 | |
| Sony KDL-32W653A | x | x | 1.2 | |
| Sony KDL-32W653ABAEP | x | x | 1.2 | |
| Sony KDL-32W654A | x | x | 1.2 | |
| Sony KDL-32W654ASAEP | x | x | 1.2 | |
| Sony KDL32W705BBAEP | x | x | 1.2 | |
| Sony KDL32W706BSAEP | x | x | 1.2 | |
| Sony KDL32WD603BAEP | x | x | 1.3 | |
| Sony KDL32WD753BAEP | x | x | 1.3 | |
| Sony KDL32WD757SAEP | x | x | 1.3 | |
| Sony KDL32WE613BAEP | x | x | 1.3 | |
| Sony KDL-37EX524 | x | x | 1.2 | |
| Sony KDL-40CX523 | x | x | 1.2 | |
| Sony KDL-40EX503 | x | x | 1.2 | |
| Sony KDL-40EX524 | x | x | 1.2 | |
| Sony KDL-40EX603 | x | x | 1.2 | |
| Sony KDL-40EX653 | x | x | 1.2 | |
| Sony KDL-40EX713 | x | x | 1.2 | |
| Sony KDL-40EX723 | x | x | 1.2 | |
| Sony KDL-40EX724 | x | x | 1.2 | |
| Sony KDL-40HX723 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sony KDL-40HX753 | x | x | 1.2 | |
| Sony KDL-40HX755 | x | x | 1.2 | |
| Sony KDL-40HX75G | x | x | 1.2 | |
| Sony KDL-40HX803 | x | x | 1.2 | |
| Sony KDL-40HX853 | x | x | 1.2 | |
| Sony KDL-40HX855 | x | x | 1.2 | |
| Sony KDL-40LX903 | x | x | 1.2 | |
| Sony KDL-40NX713 | x | x | 1.2 | |
| Sony KDL-40NX723 | x | x | 1.2 | |
| Sony KDL40R453B | x | x | 1.2 | |
| Sony KDL-40R453C | x | x | 1.3 | |
| Sony KDL40R455B | x | x | 1.2 | |
| Sony KDL-40R473ABAEP | x | x | 1.2 | |
| Sony KDL-40R474ABAEP | x | x | 1.2 | |
| Sony KDL40R483B | x | x | 1.2 | |
| Sony KDL40R485B | x | x | 1.2 | |
| Sony KDL-40R553C | x | x | 1.3 | |
| Sony KDL40RD453BAEP | x | x | 1.3 | |
| Sony KDL40W605BBAEP | x | x | 1.2 | |
| Sony KDL40W608BBAEP | x | x | 1.2 | |
| Sony KDL-40W905A | x | x | 1.2 | |
| Sony KDL-40W90SABAEP | x | x | 1.2 | |
| Sony KDL40WD653BAEP | x | x | 1.3 | |
| Sony KDL40WE663BAEP | x | x | 1.3 | |
| Sony KDL-42W653A | x | x | 1.2 | |
| Sony KDL-42W653ABAEP | x | x | 1.2 | |
| Sony KDL-42W654A | x | x | 1.2 | |
| Sony KDL-42W654ASAEP | x | x | 1.2 | |
| Sony KDL42W705BBAEP | x | x | 1.2 | |
| Sony KDL42W706BSAEP | x | x | 1.2 | |
| Sony KDL-42W805A | x | x | 1.2 | |
| Sony KDL-42W805ABN | x | x | 1.2 | |
| Sony KDL42W805BBN | x | x | 1.2 | |
| Sony KDL-42W807A | x | x | 1.2 | |
| Sony KDL-42W807ABN | x | x | 1.2 | |
| Sony KDL42W815BSN | x | x | 1.2 | |
| Sony KDL42W828BBN | x | x | 1.2 | |
| Sony KDL43RF455BAEP | x | x | 1.3 | |
| Sony KDL43W755CBAEP | x | x | 1.2 | |
| Sony KDL43W805CBAEP | x | x | 1.2 | |
| Sony KDL43W807CSAEP | x | x | 1.2 | |
| Sony KDL43W808CBAEP | x | x | 1.2 | |
| Sony KDL43W809CBAEP | x | x | 1.2 | |
| Sony KDL43WD753BAEP | x | x | 1.3 | |
| Sony KDL43WD757SAEP | x | x | 1.3 | |
| Sony KDL43WE753BAEP | x | x | 1.3 | |
| Sony KDL43WF665BAEP | x | x | 1.3 | |
| Sony KDL46CX523 | x | x | 1.2 | |
| Sony KDL-46EX503 | x | x | 1.2 | |
| Sony KDL-46EX524 | x | x | 1.2 | |
| Sony KDL-46EX653 | x | x | 1.2 | |
| Sony KDL-46EX713 | x | x | 1.2 | |
| Sony KDL-46EX723 | x | x | 1.2 | |
| Sony KDL-46EX724 | x | x | 1.2 | |
| Sony KDL-46HX723 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sony KDL-46HX753 | x | x | 1.2 | |
| Sony KDL-46HX755 | x | x | 1.2 | |
| Sony KDL-46HX75G | x | x | 1.2 | |
| Sony KDL-46HX803 | x | x | 1.2 | |
| Sony KDL-46HX823 | x | x | 1.2 | |
| Sony KDL-46HX853 | x | x | 1.2 | |
| Sony KDL-46HX855 | x | x | 1.2 | |
| Sony KDL-46HX903 | x | x | 1.2 | |
| Sony KDL-46HX923 | x | x | 1.2 | |
| Sony KDL-46NX713 | x | x | 1.2 | |
| Sony KDL-46NX723 | x | x | 1.2 | |
| Sony KDL-46R473ABAEP | x | x | 1.2 | |
| Sony KDL-46W905A | x | x | 1.2 | |
| Sony KDL-46W90SABAEP | x | x | 1.2 | |
| Sony KDL-47W805A | x | x | 1.2 | |
| Sony KDL-47W805ABN | x | x | 1.2 | |
| Sony KDL-47W807A | x | x | 1.2 | |
| Sony KDL-47W807ASN | x | x | 1.2 | |
| Sony KDL-48R553C | x | x | 1.3 | |
| Sony KDL48W585BBAEP | x | x | 1.2 | |
| Sony KDL48W605BBAEP | x | x | 1.2 | |
| Sony KDL48WD653BAEP | x | x | 1.3 | |
| Sony KDL49WD753BAEP | x | x | 1.3 | |
| Sony KDL49WD757SAEP | x | x | 1.3 | |
| Sony KDL49WE663BAEP | x | x | 1.3 | |
| Sony KDL49WE753BAEP | x | x | 1.3 | |
| Sony KDL49X8505BBAEP | x | x | 1.2 | |
| Sony KDL-50W655A | x | x | 1.2 | |
| Sony KDL-50W656ASAEP | x | x | 1.2 | |
| Sony KDL-50W685A | x | x | 1.2 | |
| Sony KDL-50W685ABAEP | x | x | 1.2 | |
| Sony KDL50W705BBN | x | x | 1.2 | |
| Sony KDL50W705BSN | x | x | 1.2 | |
| Sony KDL50W706BSN | x | x | 1.2 | |
| Sony KDL50W755CBAEP | x | x | 1.2 | |
| Sony KDL50W805BBN | x | x | 1.2 | |
| Sony KDL50W805CBAEP | x | x | 1.2 | |
| Sony KDL50W807CSAEP | x | x | 1.2 | |
| Sony KDL50W808CBAEP | x | x | 1.2 | |
| Sony KDL50W809CBAEP | x | x | 1.2 | |
| Sony KDL50W815BSN | x | x | 1.2 | |
| Sony KDL50W828BBN | x | x | 1.2 | |
| Sony KDL50WF665BAEP | x | x | 1.3 | |
| Sony KDL-52HX903 | x | x | 1.2 | |
| Sony KDL-55EX503 | x | x | 1.2 | |
| Sony KDL-55EX713 | x | x | 1.2 | |
| Sony KDL-55EX723 | x | x | 1.2 | |
| Sony KDL-55HX753 | x | x | 1.2 | |
| Sony KDL-55HX755 | x | x | 1.2 | |
| Sony KDL-55HX75G | x | x | 1.2 | |
| Sony KDL-55HX823 | x | x | 1.2 | |
| Sony KDL-55HX853 | x | x | 1.2 | |
| Sony KDL-55HX855 | x | x | 1.2 | |
| Sony KDL-55HX923 | x | x | 1.2 | |
| Sony KDL-55NX723 | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Sony KDL-55NX813 | x | x | 1.2 | |
| Sony KDL55W755CBAEP | x | x | 1.2 | |
| Sony KDL-55W805A | x | x | 1.2 | |
| Sony KDL-55W805ASN | x | x | 1.2 | |
| Sony KDL55W805BBN | x | x | 1.2 | |
| Sony KDL55W805CBAEP | x | x | 1.2 | |
| Sony KDL-55W807A | x | x | 1.2 | |
| Sony KDL-55W807ASN | x | x | 1.2 | |
| Sony KDL55W807CSAEP | x | x | 1.2 | |
| Sony KDL55W808CBAEP | x | x | 1.2 | |
| Sony KDL55W809CBAEP | x | x | 1.2 | |
| Sony KDL55W815BSN | x | x | 1.2 | |
| Sony KDL55W828BBN | x | x | 1.2 | |
| Sony KDL-55W905A | x | x | 1.2 | |
| Sony KDL-55W905ABAEP | x | x | 1.2 | |
| Sony KDL55W955BBAEP | x | x | 1.2 | |
| Sony KDL55X8505BBAEP | x | x | 1.2 | |
| Sony KDL55X9005BBAEP | x | x | 1.2 | |
| Sony KDL-60EX703 | x | x | 1.2 | |
| Sony KDL-60LX903 | x | x | 1.2 | |
| Sony KDL-60NX723 | x | x | 1.2 | |
| Sony KDL60W605BBAEP | x | x | 1.2 | |
| Sony KDL60W855BBAEP | x | x | 1.2 | |
| Sony KDL65HX923 | x | x | 1.2 | |
| Sony KDL-65HX923 | x | x | 1.2 | |
| Sony KDL65HX925 | x | x | 1.2 | |
| Sony KDL65W855CBAEP | x | x | 1.2 | |
| Sony KDL-65W905ABAEP | x | x | 1.2 | |
| Sony KDL65W955BBAEP | x | x | 1.2 | |
| Sony KDL65X8505BBAEP | x | x | 1.2 | |
| Sony KDL65X9005BBAEP | x | x | 1.2 | |
| Sony KDL75W855CBAEP | x | x | 1.2 | |
| Sony KDL79X9005BBAEP | x | x | 1.2 | |
| Sony KDL85X9505BBAEP | x | x | 1.2 | |
| Strong SRT24HZ4003N | x | x | 1.3 | |
| Strong SRT32HZ4003N | x | x | 1.3 | |
| Strong SRT32HZ4003NW | x | x | 1.3 | |
| Strong SRT39HZ4003N | x | x | 1.3 | |
| Strong SRT39HZ4003NW | x | x | 1.3 | |
| Strong SRT40FZ4003N | x | x | 1.3 | |
| Strong SRT42FZ4003N | x | x | 1.3 | |
| TCL F32B3804 | x | x | 1.2 | |
| TCL F32B3814 | x | x | 1.2 | |
| TCL F40B3804 | x | x | 1.2 | |
| TCL F40B3904 | x | x | 1.2 | |
| TCL F40S3804 | x | x | 1.2 | |
| TCL F40S5906 | x | x | 1.3 | |
| TCL F49S5906 | x | x | 1.3 | |
| TCL F50S3804 | x | x | 1.2 | |
| TCL F55S3804 | x | x | 1.2 | |
| TCL F55S5906 | x | x | 1.3 | |
| TCL H24E4404 | x | x | 1.2 | |
| TCL H24E4404R | x | x | 1.2 | |
| TCL H24E4414 | x | x | 1.2 | |
| TCL H24E4414R | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| TCL H24E4434 | x | x | 1.2 | |
| TCL H24E4434R | x | x | 1.2 | |
| TCL H24E4454 | x | x | 1.2 | |
| TCL H24E4454R | x | x | 1.2 | |
| TCL H24E4464 | x | x | 1.2 | |
| TCL H24E4464R | x | x | 1.2 | |
| TCL H32B3804 | x | x | 1.2 | |
| TCL H32B3904 | x | x | 1.2 | |
| TCL H32E4404 | x | x | 1.2 | |
| TCL H32E4414 | x | x | 1.2 | |
| TCL H32E4434 | x | x | 1.2 | |
| TCL H32E4454 | x | x | 1.2 | |
| TCL H32E4464 | x | x | 1.2 | |
| TCL H32S3804 | x | x | 1.2 | |
| TCL L19E4104R | x | x | 1.2 | |
| TCL L24E4104FR | x | x | 1.2 | |
| TCL L24E4234FR | x | x | 1.2 | |
| TCL L32E3004 | x | x | 1.2 | |
| TCL L40E3004F | x | x | 1.2 | |
| TCL L48S4604F | x | x | 1.2 | |
| TCL U40S6806S | x | x | 1.3 | |
| TCL U40S6906 | x | x | 1.3 | |
| TCL U43S6916 | x | x | 1.3 | |
| TCL U49C6916 | x | x | 1.3 | |
| TCL U50S6806S | x | x | 1.3 | |
| TCL U50S6906 | x | x | 1.3 | |
| TCL U50S7806S | x | x | 1.3 | |
| TCL U50S7906 | x | x | 1.3 | |
| TCL U55C6916 | x | x | 1.3 | |
| TCL U55S6006 | x | x | 1.3 | |
| TCL U55S6806S | x | x | 1.3 | |
| TCL U55S6906 | x | x | 1.3 | |
| TCL U55S7906 | x | x | 1.3 | |
| TCL U55S8806DS | x | x | 1.3 | |
| TCL U55S8866S | x | x | 1.3 | |
| TCL U58S7806S | x | x | 1.3 | |
| TCL U65S7906 | x | x | 1.3 | |
| TCL U65S8806DS | x | x | 1.3 | |
| Telefunken 20HE6115 | x | x | 1.2 | |
| TELEFUNKEN 20HW6216 | x | x | 1.3 | |
| TELEFUNKEN 22DV6115 | x | x | 1.2 | |
| TELEFUNKEN 22FW6217 | x | x | 1.3 | |
| TELEFUNKEN 22FW6217 | x | x | 1.3 | |
| TELEFUNKEN 24HE6115 | x | x | 1.3 | |
| TELEFUNKEN 24HE6118 | x | x | 1.3 | |
| TELEFUNKEN 24HW6217 | x | x | 1.3 | |
| Telefunken 32DH5015 | x | x | 1.2 | |
| TELEFUNKEN 32DH5018 | x | x | 1.3 | |
| TELEFUNKEN 32FW6015 | x | x | 1.3 | |
| TELEFUNKEN 40FS5917 | x | x | 1.2 | |
| TELEFUNKEN 40FW6016 | x | x | 1.3 | |
| Telefunken 42FW6015 | x | x | 1.2 | |
| TELEFUNKEN 43FW5917 | x | x | 1.3 | |
| TELEFUNKEN 43FW5917/2 | x | x | 1.3 | |
| TELEFUNKEN 43FW5918 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| TELEFUNKEN 43UH6927 | x | x | 1.3 | |
| TELEFUNKEN 49UH6927 | x | x | 1.3 | |
| Telefunken 49UH7816 | x | x | 1.2 | |
| TELEFUNKEN 49UH7916 | x | x | 1.3 | |
| TELEFUNKEN 50FD5517 | x | x | 1.3 | |
| TELEFUNKEN 55FH6017 | x | x | 1.2 | |
| Telefunken 55FW6015 | x | x | 1.2 | |
| TELEFUNKEN 55UH7916 | x | x | 1.3 | |
| Telefunken 65FW6015 | x | x | 1.2 | |
| Telefunken CAMP20DVD | x | x | 1.2 | |
| Telefunken CAMP22DVD | x | x | 1.2 | |
| TELEFUNKEN CAMP22SMART | x | x | 1.3 | |
| Telefunken CAMP24DVD | x | x | 1.2 | |
| TELEFUNKEN CAMP24SMART | x | x | 1.3 | |
| Thomson 19HW4334W | x | x | 1.2 | |
| Thomson 24HA4244 | x | x | 1.2 | |
| Thomson 28HA3204 | x | x | 1.2 | |
| Thomson 32FB4406 | x | x | 1.3 | |
| Thomson 32FU5554 | x | x | 1.2 | |
| Thomson 32FU5554W | x | x | 1.2 | |
| Thomson 32HA3104 | x | x | 1.2 | |
| Thomson 32HA3204 | x | x | 1.2 | |
| Thomson 32HB3104 | x | x | 1.2 | |
| THOMSON 32HW3324 | x | x | 1.2 | |
| Thomson 39FU5554C | x | x | 1.2 | |
| Thomson 39FU5554CW | x | x | 1.2 | |
| Thomson 40FA3104 | x | x | 1.2 | |
| Thomson 40FA3204 | x | x | 1.2 | |
| Thomson 40FB3104 | x | x | 1.2 | |
| Thomson 40FB5406 | x | x | 1.3 | |
| Thomson 40FB5406W | x | x | 1.3 | |
| Thomson 40FB5416 | x | x | 1.3 | |
| Thomson 40FW3324 | x | x | 1.2 | |
| THOMSON 40FW3324 | x | x | 1.2 | |
| Thomson 40FW5554 | x | x | 1.2 | |
| Thomson 40UA6406 | x | x | 1.3 | |
| Thomson 40UB6406 | x | x | 1.3 | |
| Thomson 40US6006 | x | x | 1.3 | |
| Thomson 42FU5554 | x | x | 1.2 | |
| Thomson 42FU5554W | x | x | 1.2 | |
| Thomson 46FU5554 | x | x | 1.2 | |
| Thomson 46FU5554C | x | x | 1.2 | |
| Thomson 46FU5554W | x | x | 1.2 | |
| Thomson 46FW5564 | x | x | 1.2 | |
| Thomson 48FA3204 | x | x | 1.2 | |
| Thomson 49UA7706 | x | x | 1.3 | |
| Thomson 50FW5564 | x | x | 1.2 | |
| Thomson 50UA6406 | x | x | 1.3 | |
| Thomson 50UA6406W | x | x | 1.3 | |
| Thomson 50UB6406 | x | x | 1.3 | |
| Thomson 50UB6416 | x | x | 1.3 | |
| Thomson 50UW9766 | x | x | 1.2 | |
| Thomson 55FA3204 | x | x | 1.2 | |
| Thomson 55FZ3234 | x | x | 1.2 | |
| Thomson 55UA6404 | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Thomson 55UA6404W | x | x | 1.3 | |
| Thomson 55UA6406 | x | x | 1.3 | |
| Thomson 55UA6406B | x | x | 1.3 | |
| Thomson 55UA6406W | x | x | 1.3 | |
| Thomson 55UA7706 | x | x | 1.3 | |
| Thomson 55UA8586 | x | x | 1.3 | |
| Thomson 55UA8596 | x | x | 1.3 | |
| Thomson 55UA8696 | x | x | 1.3 | |
| Thomson 55UA8796 | x | x | 1.3 | |
| Thomson 55UA9806 | x | x | 1.3 | |
| Thomson 55UB6406 | x | x | 1.3 | |
| Thomson 55UB6416 | x | x | 1.3 | |
| Thomson 55US6006 | x | x | 1.3 | |
| Thomson 55UW9786 | x | x | 1.2 | |
| Thomson 65UA6606 | x | x | 1.3 | |
| Thomson 65UA8696 | x | x | 1.3 | |
| Thomson 65UA8796 | x | x | 1.3 | |
| Thomson 65UB6406 | x | x | 1.3 | |
| Thomson 65UB6416 | x | x | 1.3 | |
| Thomson 65US6006 | x | x | 1.3 | |
| Thomson 78UA8796 | x | x | 1.3 | |
| Thomson 85UZ8876 | x | x | 1.3 | |
| TOSHIBA 22L1665DG | x | x | 1.3 | |
| Toshiba 23RL933N | x | x | 1.2 | |
| TOSHIBA 24D1665DG | x | x | 1.3 | |
| Toshiba 24D1753DB | x | x | 1.3 | |
| Toshiba 24D1754DB | x | x | 1.3 | |
| TOSHIBA 24D3663DG | x | x | 1.3 | |
| TOSHIBA 24D3754DG | x | x | 1.3 | |
| TOSHIBA 24D3763DG | x | x | 1.3 | |
| TOSHIBA 24L2863DG | x | x | 1.3 | |
| TOSHIBA 24L3863DG | x | x | 1.3 | |
| TOSHIBA 24W1665DG | x | x | 1.3 | |
| Toshiba 24W1753DB | x | x | 1.3 | |
| Toshiba 24W1754DB | x | x | 1.3 | |
| TOSHIBA 24W2963DG | x | x | 1.3 | |
| TOSHIBA 24W3663DG | x | x | 1.3 | |
| TOSHIBA 24W3754DG | x | x | 1.3 | |
| TOSHIBA 24W3763DG | x | x | 1.3 | |
| TOSHIBA 24WL2A63DG | x | x | 1.3 | |
| TOSHIBA 28W2863DG | x | x | 1.3 | |
| TOSHIBA 28W3753DG | x | x | 1.3 | |
| TOSHIBA 28W3754DG | x | x | 1.3 | |
| TOSHIBA 28W3763DG | x | x | 1.3 | |
| Toshiba 324353N | x | x | 1.2 | |
| TOSHIBA 32D1665DG | x | x | 1.3 | |
| Toshiba 32D1752DB | x | x | 1.3 | |
| Toshiba 32D1753DB | x | x | 1.3 | |
| Toshiba 32D3453DN | x | x | 1.2 | |
| Toshiba 32D3454DN | x | x | 1.2 | |
| TOSHIBA 32D3663DG | x | x | 1.3 | |
| TOSHIBA 32D3754DG | x | x | 1.3 | |
| TOSHIBA 32D3762DG | x | x | 1.3 | |
| TOSHIBA 32D3763DG | x | x | 1.3 | |
| TOSHIBA 32D3764DG | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Toshiba 32H6453DN | x | x | 1.2 | |
| Toshiba 32L1353N | x | x | 1.2 | |
| Toshiba 32L1753DB | x | x | 1.3 | |
| Toshiba 32L2351DN | x | x | 1.2 | |
| Toshiba 32L2353DN | x | x | 1.2 | |
| Toshiba 32L2357DN | x | x | 1.2 | |
| Toshiba 32L2435DN | x | x | 1.2 | |
| Toshiba 32L2454DN | x | x | 1.2 | |
| TOSHIBA 32L2863DG | x | x | 1.3 | |
| TOSHIBA 32L3663DG | x | x | 1.3 | |
| TOSHIBA 32L3763DG | x | x | 1.3 | |
| TOSHIBA 32L3764DG | x | x | 1.3 | |
| TOSHIBA 32L3863DG | x | x | 1.3 | |
| TOSHIBA 32L3866DG | x | x | 1.3 | |
| Toshiba 32L4363N | x | x | 1.2 | |
| Toshiba 32L6353N | x | x | 1.2 | |
| Toshiba 32L6363N | x | x | 1.2 | |
| Toshiba 32L6453DN | x | x | 1.2 | |
| Toshiba 32L6463DN | x | x | 1.2 | |
| TOSHIBA 32LL2A63DG | x | x | 1.3 | |
| TOSHIBA 32LL3A63DG | x | x | 1.3 | |
| Toshiba 32RL858N | x | x | 1.2 | |
| Toshiba 32RL953N | x | x | 1.2 | |
| Toshiba 32SL863N | x | x | 1.2 | |
| Toshiba 32TL868N | x | x | 1.2 | |
| Toshiba 32TL933N | x | x | 1.2 | |
| Toshiba 32TL963N | x | x | 1.2 | |
| Toshiba 32UL863N | x | x | 1.2 | |
| TOSHIBA 32W1665DG | x | x | 1.3 | |
| Toshiba 32W1753DB | x | x | 1.3 | |
| Toshiba 32W2351DN | x | x | 1.2 | |
| Toshiba 32W2353DN | x | x | 1.2 | |
| Toshiba 32W2357DN | x | x | 1.2 | |
| Toshiba 32W2453DN | x | x | 1.2 | |
| Toshiba 32W2454DN | x | x | 1.2 | |
| TOSHIBA 32W2863DG | x | x | 1.3 | |
| Toshiba 32W3453DN | x | x | 1.2 | |
| TOSHIBA 32W3663DG | x | x | 1.3 | |
| TOSHIBA 32W3753DG | x | x | 1.3 | |
| TOSHIBA 32W3754DG | x | x | 1.3 | |
| TOSHIBA 32W3763DG | x | x | 1.3 | |
| TOSHIBA 32W3764DG | x | x | 1.3 | |
| TOSHIBA 32W3863DG | x | x | 1.3 | |
| TOSHIBA 32W3864DG | x | x | 1.3 | |
| TOSHIBA 32WL3A63DG | x | x | 1.3 | |
| Toshiba 37SL863N | x | x | 1.2 | |
| Toshiba 37UL863N | x | x | 1.2 | |
| TOSHIBA 39D3763DG | x | x | 1.3 | |
| Toshiba 39L2351DN | x | x | 1.2 | |
| Toshiba 39L2353DN | x | x | 1.2 | |
| Toshiba 39L2357DN | x | x | 1.2 | |
| TOSHIBA 39L2863DG | x | x | 1.3 | |
| TOSHIBA 39L3663DG | x | x | 1.3 | |
| TOSHIBA 39L3763DG | x | x | 1.3 | |
| TOSHIBA 39L3863DG | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Toshiba 39L4353N | x | x | 1.2 | |
| Toshiba 39L4363N | x | x | 1.2 | |
| Toshiba 40L1353N | x | x | 1.2 | |
| TOSHIBA 40L1665DG | x | x | 1.3 | |
| Toshiba 40L2435DN | x | x | 1.2 | |
| TOSHIBA 40L2863DG | x | x | 1.3 | |
| Toshiba 40L3451DN | x | x | 1.2 | |
| Toshiba 40L3453DN | x | x | 1.2 | |
| Toshiba 40L3454DN | x | x | 1.2 | |
| TOSHIBA 40L3663DG | x | x | 1.3 | |
| TOSHIBA 40L3863DG | x | x | 1.3 | |
| Toshiba 40L5351DN | x | x | 1.2 | |
| Toshiba 40L5353DN | x | x | 1.2 | |
| Toshiba 40L5355DN | x | x | 1.2 | |
| Toshiba 40L5463DN | x | x | 1.2 | |
| Toshiba 40L6353N | x | x | 1.2 | |
| Toshiba 40L6363N | x | x | 1.2 | |
| Toshiba 40L7353N | x | x | 1.2 | |
| Toshiba 40L7355N | x | x | 1.2 | |
| Toshiba 40L7363N | x | x | 1.2 | |
| Toshiba 40L7365N | x | x | 1.2 | |
| Toshiba 40RL858N | x | x | 1.2 | |
| Toshiba 40RL953N | x | x | 1.2 | |
| Toshiba 40TL868N | x | x | 1.2 | |
| Toshiba 40TL933N | x | x | 1.2 | |
| Toshiba 40TL963N | x | x | 1.2 | |
| TOSHIBA 40V4863DG | x | x | 1.3 | |
| Toshiba 42H6453DN | x | x | 1.2 | |
| Toshiba 42L6453DN | x | x | 1.2 | |
| Toshiba 42L6463DN | x | x | 1.2 | |
| Toshiba 42L7453DN | x | x | 1.2 | |
| Toshiba 42L7463DN | x | x | 1.2 | |
| Toshiba 42SL863N | x | x | 1.2 | |
| Toshiba 42UL863N | x | x | 1.2 | |
| Toshiba 42VL863N | x | x | 1.2 | |
| Toshiba 42WL863N | x | x | 1.2 | |
| Toshiba 42VL963N | x | x | 1.2 | |
| Toshiba 42YL863N | x | x | 1.2 | |
| TOSHIBA 43L1665DG | x | x | 1.3 | |
| Toshiba 43L1753DB | x | x | 1.3 | |
| TOSHIBA 43L2863DG | x | x | 1.3 | |
| TOSHIBA 43L3663DG | x | x | 1.3 | |
| TOSHIBA 43L3763DG | x | x | 1.3 | |
| TOSHIBA 43L3863DG | x | x | 1.3 | |
| TOSHIBA 43LL2A63DG | x | x | 1.3 | |
| TOSHIBA 43LL3A63DG | x | x | 1.3 | |
| TOSHIBA 43T6863DG | x | x | 1.3 | |
| TOSHIBA 43TL5A63DG | x | x | 1.3 | |
| TOSHIBA 43U5663DG | x | x | 1.3 | |
| TOSHIBA 43U5766DG | x | x | 1.3 | |
| TOSHIBA 43U6663DG | x | x | 1.3 | |
| TOSHIBA 43U6763DG | x | x | 1.3 | |
| TOSHIBA 43UL2A63DG | x | x | 1.3 | |
| TOSHIBA 43UL3A63DG | x | x | 1.3 | |
| TOSHIBA 43UL5A63DG | x | x | 1.3 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| TOSHIBA 43VL3A63DG | x | x | 1.3 | |
| Toshiba 46SL863N | x | x | 1.2 | |
| Toshiba 46TL868N | x | x | 1.2 | |
| Toshiba 46TL933N | x | x | 1.2 | |
| Toshiba 46TL963N | x | x | 1.2 | |
| Toshiba 46UL863N | x | x | 1.2 | |
| Toshiba 46WL863N | x | x | 1.2 | |
| Toshiba 46YL863N | x | x | 1.2 | |
| Toshiba 46ZL2N | x | x | 1.2 | |
| Toshiba 47H6453DN | x | x | 1.2 | |
| Toshiba 47L2453DN | x | x | 1.2 | |
| Toshiba 47L6453DN | x | x | 1.2 | |
| Toshiba 47L6463DN | x | x | 1.2 | |
| Toshiba 47L7453DN | x | x | 1.2 | |
| Toshiba 47L7463DN | x | x | 1.2 | |
| Toshiba 47VL863N | x | x | 1.2 | |
| Toshiba 47VL963N | x | x | 1.2 | |
| Toshiba 48L1453DN | x | x | 1.2 | |
| TOSHIBA 48L2863DG | x | x | 1.3 | |
| TOSHIBA 48L3663DG | x | x | 1.3 | |
| Toshiba 48L5463DN | x | x | 1.2 | |
| Toshiba 49L1753DB | x | x | 1.3 | |
| TOSHIBA 49L2863DG | x | x | 1.3 | |
| TOSHIBA 49L3663DG | x | x | 1.3 | |
| TOSHIBA 49L3763DG | x | x | 1.3 | |
| TOSHIBA 49L3863DG | x | x | 1.3 | |
| TOSHIBA 49L3866DG | x | x | 1.3 | |
| TOSHIBA 49LL2A63DG | x | x | 1.3 | |
| TOSHIBA 49LL3A63DG | x | x | 1.3 | |
| TOSHIBA 49T6863DG | x | x | 1.3 | |
| TOSHIBA 49TL5A63DG | x | x | 1.3 | |
| TOSHIBA 49TL7A63DG | x | x | 1.3 | |
| TOSHIBA 49U5663DG | x | x | 1.3 | |
| TOSHIBA 49U5766DG | x | x | 1.3 | |
| TOSHIBA 49U6663DG | x | x | 1.3 | |
| TOSHIBA 49U6763DG | x | x | 1.3 | |
| TOSHIBA 49U6863DA | x | x | 1.3 | |
| TOSHIBA 49U7763DG | x | x | 1.3 | |
| TOSHIBA 49U7766DG | x | x | 1.3 | |
| TOSHIBA 49U7863DG | x | x | 1.3 | |
| TOSHIBA 49UL2A63DG | x | x | 1.3 | |
| TOSHIBA 49UL3A63DG | x | x | 1.3 | |
| TOSHIBA 49UL5A63DG | x | x | 1.3 | |
| TOSHIBA 49UL7A63DG | x | x | 1.3 | |
| TOSHIBA 49VL3A63DG | x | x | 1.3 | |
| TOSHIBA 49VL5A63DG | x | x | 1.3 | |
| Toshiba 50L2351DN | x | x | 1.2 | |
| Toshiba 50L2353DN | x | x | 1.2 | |
| Toshiba 50L2357DN | x | x | 1.2 | |
| Toshiba 50L4353N | x | x | 1.2 | |
| Toshiba 50L4363N | x | x | 1.2 | |
| Toshiba 50L5351DN | x | x | 1.2 | |
| Toshiba 50L5353DN | x | x | 1.2 | |
| Toshiba 50L5355DN | x | x | 1.2 | |
| Toshiba 50L7353N | x | x | 1.2 | |

| BOXER | Stöd för MPEG-4 | Stöd för HDTV (DVB-T2) | CI+ version | +5V till antenn |
|---|---|---|---|---|
| Toshiba 50L7355N | x | x | 1.2 | |
| Toshiba 50L7365N | x | x | 1.2 | |
| TOSHIBA 50VL5A63DG | x | x | 1.3 | |
| TOSHIBA 55L3663DG | x | x | 1.3 | |
| TOSHIBA 55L3763DG | x | x | 1.3 | |
| Toshiba 55L7453DN | x | x | 1.2 | |
| Toshiba 55L7463DN | x | x | 1.2 | |
| TOSHIBA 55T6863DG | x | x | 1.3 | |
| TOSHIBA 55TL5A63DG | x | x | 1.3 | |
| TOSHIBA 55TL7A63DG | x | x | 1.3 | |
| TOSHIBA 55U5766DG | x | x | 1.3 | |
| TOSHIBA 55U6663DG | x | x | 1.3 | |
| TOSHIBA 55U6763DG | x | x | 1.3 | |
| TOSHIBA 55U7763DG | x | x | 1.3 | |
| TOSHIBA 55U7766DG | x | x | 1.3 | |
| TOSHIBA 55UL2A63DG | x | x | 1.3 | |
| TOSHIBA 55UL3A63DG | x | x | 1.3 | |
| TOSHIBA 55UL5A63DG | x | x | 1.3 | |
| TOSHIBA 55UL7A63DG | x | x | 1.3 | |
| TOSHIBA 55VL3A63DG | x | x | 1.3 | |
| Toshiba 55WL863N | x | x | 1.2 | |
| Toshiba 55VL963N | x | x | 1.2 | |
| Toshiba 55YL863N | x | x | 1.2 | |
| Toshiba 55ZL1N | x | x | 1.2 | |
| Toshiba 55ZL2N | x | x | 1.2 | |
| Toshiba 58L5351DN | x | x | 1.2 | |
| Toshiba 58L5353DN | x | x | 1.2 | |
| Toshiba 58L5355DN | x | x | 1.2 | |
| Toshiba 58L7363N | x | x | 1.2 | |
| Toshiba 58L9363N | x | x | 1.2 | |
| TOSHIBA 58UL2163DG | x | x | 1.3 | |
| TOSHIBA 58UL2A63DG | x | x | 1.3 | |
| TOSHIBA 58UL3A63DG | x | x | 1.3 | |
| Toshiba 65L9363N | x | x | 1.2 | |
| TOSHIBA 65U5863DG | x | x | 1.3 | |
| Toshiba 65U6663DG | x | x | 1.3 | |
| TOSHIBA 65U6763DG | x | x | 1.3 | |
| TOSHIBA 65UL2A63DG | x | x | 1.3 | |
| TOSHIBA 65UL3A63DG | x | x | 1.3 | |
| TOSHIBA 65UL5A63DG | x | x | 1.3 | |
| TOSHIBA 65VL5A63DG | x | x | 1.3 | |
| TOSHIBA 65X9763DG | x | x | 1.3 | |
| TOSHIBA 75VL5A63DG | x | x | 1.3 | |
| Toshiba 84L9363N | x | x | 1.2 | |
| Triax T-HD 505 VA | x | x | | x |
| VESTEL 55-FOD-9120 | x | x | 1.3 | |